


Machine Controller MP2400 USER'S MANUAL

Model: JEPMC-MP2400-E



Overview	1
Specifications and Functions	2
Mounting and Wiring	3
System Start Up and Easy Programming	4
Outline of Motion Control Systems	5
Ethernet Communications	6
Maintenance and Inspection	7
Troubleshooting	8
Appendices	A

Using this Manual

The MP2400 is a compact Machine Controller that contains the power supply, the CPU, and the communication functions in one single unit.

Please read this manual to ensure correct usage of the MP2400 system and apply to your manufacturing system for control. Keep this manual in a safe place for future reference.

■ Basic Terms

Unless otherwise specified, the following definitions are used:

- MP2400: MP2400 Machine Controller
- MPE720: The Programming Device Software or a Programming Device (i.e., a personal computer) running the Programming Device Software
- PLC: Programmable Logic Controller

■ Manual Configuration

Read the chapters of this manual as required by the purpose.

Chapter	Selecting Models and Peripheral Devices	Studying Specifications and Ratings	Designing the System	Installation and Wiring	Trial Operation	Maintenance and Inspection
Chapter 1 Overview	√	—	—	—	—	—
Chapter 2 Specifications and Functions	√	√	√	√	—	—
Chapter 3 Mounting and Wiring	—	√	√	√	—	—
Chapter 4 System Start Up and Easy Programming	√	—	—	—	√	—
Chapter 5 Outline of Motion Control Systems	—	—	√	—	√	—
Chapter 6 Ethernet Communications	—	—	√	—	√	—
Chapter 7 Maintenance and Inspection	—	—	√	—	√	√
Chapter 8 Troubleshooting	—	—	√	—	—	√
Appendices A to C	—	—	√	—	√	√

For information on motion parameters and motion commands, refer to *Machine Controller MP2000-series SVB/SVB-01 Motion Module User's Manual* (manual number: SIEP C880700 33).

■ MPE720 Engineering Tool Version Number

In this manual, the operation of MPE720 is described using screen captures of MPE720 version 7.

For this reason, the screen captures and some descriptions may differ for MPE720 version 5 or version 6.

■ Related Manuals

The following table lists the manuals relating to the MP2400. Refer to these manuals as required.

Manual Name	Manual Number	Contents
Machine Controller MP2000 Series SVB/SVB-01 Motion Module User's Manual	SIEP C880700 33	Describes the functions, specifications, and application methods of the MP2000-series Motion Module that is built into the SVB, SVB-01, and SVR Module.
Machine Controller MP2000 Series USER'S MANUAL for Motion Programming	SIEP C880700 38	Describes the motion program language used with the MP2000 Series Machine Controllers.
System Integrated Engineering Tool MPE720 Ver.7 USER'S MANUAL	SIEP C880761 03	Describes the operating procedures for MPE720 Ver.7, which is used as the engineering tool for controllers.
Engineering Tool for MP2000 Series Machine Controller MPE720 Version 6 User's Manual	SIEP C880700 30	Describes the installation and operation of the engineering tools for MP2000-series Machine Controller MPE720 Version 6.
Machine Controller MP900/MP2000 Series MPE720 Software for Programming Device User's Manual	SIEP C880700 05	Describes how to install and operate the MP900/MP2000-series programming system (MPE720).
Σ Series SGM□/SGD User's Manual High-speed Field Network MECHATROLINK-compatible AC Servo Drivers	SIEZ-S800-26.4	Describes the Σ Series SERVOPACK models, specifications, and capacity selection methods.
Σ -II Series SGM□H/SGDM User's Manual	SIEP S800000 15	Describes the installation, wiring, trial operation, function applications methods, maintenance, and inspection of the Σ -II Series SERVOPACKs.
Σ -III Series SGM□H/SGDS User's Manual	SIEP S800000 00	Describes the models, specifications, wiring, trial operation, adjustment, function application methods, maintenance, and inspection of the Σ -III Series SERVOPACKs and Servomotors.
AC Servo Drives Σ -V Series USER'S MANUAL Design and Maintenance Rotational Motor MECHATROLINK-II Communications Reference	SIEP S800000 46	Describes the models, specifications, wiring, trial operation, adjustment, function application methods, maintenance, and inspection of the Σ -V Series SERVOPACKs and Servomotors.
Σ -III Series SGM□S/SGDS Digital Operator Operating Instructions	TOBP S800000 01	Describes the operating methods of the JUSP-OP05A Digital Operator.
Σ -III Series SGM□S/SGDS MECHATROLINK-II SERVOPACKs with Communication User's Manual	SIEP S800000 11	Describes the models, specifications, wiring, trial operation, adjustment, function application methods, maintenance, inspection, and MECHATROLINK communication of the Σ -III Series SERVOPACKs and Servomotors.
Machine Controller MP900/MP2000 Series Linear Servomotor Manual	SIEP C880700 06	Describes the connection methods, setting methods, and other information for Linear Servomotors.
Machine Controller MP900/MP2000 Series User's Manual, MECHATROLINK System	SIEZ-C887-5.1	Describes MECHATROLINK distributed I/O for MP900/MP2000-series Machine Controllers.

■ Terms Used to Describe “Torque”

Although the term “torque” is commonly used when describing rotary servomotors and “force” or “thrust” are used when describing linear servomotors, this manual uses “torque” when describing both (excluding parameters).

■ Copyrights

- DeviceNet is a registered trademark of the ODVA (Open DeviceNet Vendor Association, Inc).
- PROFIBUS is a trademark of the PROFIBUS User Organization.
- Ethernet is a registered trademark of the Xerox Corporation.
- Microsoft, Windows, Windows NT, and Internet Explorer are registered trademarks of the Microsoft Corporation.
- Pentium is a registered trademark of the Intel Corporation.
- Other product names and company names are the trademarks or registered trademarks of the respective company. “TM” and the ® mark do not appear with product or company names in this manual.

■ Indication of Reverse Signals

In this manual, the names of reverse signals (ones that are valid when low) are written with a forward slash (/) before the signal name, as shown in the following example:

Notation Examples

- $\overline{\text{S-ON}}$ = /S-ON
- $\overline{\text{P-CON}}$ = /P-CON

Safety Information

The following conventions are used to indicate precautions in this manual. These precautions are provided to ensure the safe operation of the MP2400 and connected devices. Information marked as shown below is important for the safety of the user. Always read this information and heed the precautions that are provided.

The conventions are as follows:



Indicates precautions that, if not heeded, could possibly result in loss of life, serious injury, or property damage.



Indicates precautions that, if not heeded, could result in relatively serious or minor injury, or property damage.

If not heeded, even precautions classified under  CAUTION can lead to serious results depending on circumstances.



Indicates prohibited actions. Specific prohibitions are indicated inside .

For example,  indicates prohibition of open flame.



Indicates mandatory actions. Specific actions are indicated inside .

For example,  indicates mandatory grounding.

Safety Precautions

The following precautions are for checking products on delivery, storage, transportation, installation, wiring, operation, application, inspection, and disposal. These precautions are important and must be observed.

■ General Precautions



WARNING

- ♦ Before connecting the machine and starting operation, ensure that an emergency stop procedure has been provided and is working correctly.
There is a risk of injury.
- ♦ Do not touch anything inside the MP2400.
There is a risk of electrical shock.
- ♦ Always keep the front cover attached when power is being supplied.
There is a risk of electrical shock.
- ♦ Observe all procedures and precautions given in this manual for trial operation.
Operating mistakes while the servomotor and machine are connected may damage the machine or even cause accidents resulting in injury or death.
There is a risk of electrical shock.
- ♦ Do not remove the front cover, cables, connector, or options while power is being supplied.
There is a risk of electrical shock.
- ♦ Do not damage, pull on, apply excessive force to, place heavy objects on, or pinch cables.
There is a risk of electrical shock, operational failure or burning of the MP2400.
- ♦ Do not attempt to modify the MP2400 in any way.
There is a risk of injury or device damage.
- ♦ Do not approach the machine when there is a momentary interruption to the power supply. When power is restored, the MP2400 and the device connected to it may start operation suddenly. Provide safety measures in advance to ensure human safety in the event that operation restarts suddenly.
There is a risk of injury.
- ♦ Do not allow installation, disassembly, or repairs to be performed by anyone other than specified personnel.
There is a risk of electrical shock or injury.

■ Storage and Transportation

CAUTION

- ♦ Do not store or install the MP2400 in the following locations.
There is a risk of fire, electrical shock, or device damage.
 - ♦ Direct sunlight
 - ♦ Ambient temperature exceeds the storage or operating conditions
 - ♦ Ambient humidity exceeds the storage or operating conditions
 - ♦ Rapid changes in temperature or locations subject to condensation
 - ♦ Corrosive or flammable gas
 - ♦ Excessive dust, dirt, salt, or metallic powder
 - ♦ Water, oil, or chemicals
 - ♦ Vibration or shock
- ♦ Do not overload the MP2400 during transportation.
There is a risk of injury or an accident.
- ♦ Do not subject the MP2400 to halogen gases, such as fluorine, chlorine, bromine, and iodine, at any time even during transportation or installation.
There is a risk of device damage or injury.
- ♦ If disinfectants or insecticides must be used to treat packing materials such as wooden frames, pallets, or plywood, the packing materials must be treated before the product is packaged, and methods other than fumigation must be used.
Example: Heat treatment, where materials are kiln-dried to a core temperature of 56°C for 30 minutes or more.
If the electronic products, which include stand-alone products and products installed in machines, are packed with fumigated wooden materials, the electrical components may be greatly damaged by the gases or fumes resulting from the fumigation process. In particular, disinfectants containing halogen, which includes chlorine, fluorine, bromine, or iodine can contribute to the erosion of the capacitors.

■ Installation

CAUTION

- ♦ Never use the MP2400 in locations subject to water, corrosive atmospheres, or flammable gas, or near burnable objects.
There is a risk of electrical shock or fire.
- ♦ Do not step on the MP2400 or place heavy objects on the MP2400.
There is a risk of injury.
- ♦ Do not block the air exhaust port or allow foreign objects to enter the MP2400.
There is a risk of element deterioration inside, an accident, or fire.
- ♦ Always mount the MP2400 in the specified orientation.
There is a risk of an accident.
- ♦ Do not subject the MP2400 to strong shock.
There is a risk of an accident.

■ Wiring



CAUTION

- ♦ Check the wiring to be sure it has been performed correctly.
There is a risk of motor run-away, injury, or an accident.
- ♦ Always use a power supply of the specified voltage.
There is a risk of burning.
- ♦ In places with poor power supply conditions, take all steps necessary to ensure that the input power supply is within the specified voltage range.
There is a risk of device damage.
- ♦ Install breakers and other safety measure to provide protection against shorts in external wiring.
There is a risk of fire.
- ♦ Provide sufficient shielding when using the MP2400 in the following locations.
There is a risk of device damage.
 - ♦ Noise, such as from static electricity
 - ♦ Strong electromagnetic or magnetic fields
 - ♦ Radiation
 - ♦ Near to power lines
- ♦ When connecting the battery, connect the polarity correctly.
There is a risk of battery damage or explosion.
- ♦ Only qualified safety-trained personnel should replace the battery.
If the battery is replaced incorrectly, machine malfunction or damage, electric shock, or injury may result.
- ♦ When replacing the battery, do not touch the electrodes.
Static electricity may damage the electrodes.


■ Selecting, Separating, and Laying External Cables



CAUTION

- ♦ Consider the following items when selecting the I/O signal lines (external cables) to connect the MP2400 to external devices.
 - ♦ Mechanical strength
 - ♦ Noise interference
 - ♦ Wiring distance
 - ♦ Signal voltage, etc.
- ♦ Separate the I/O signal lines from the power lines both inside and outside the control box to reduce the influence of noise from the power lines.
If the I/O signal lines and power lines are not separated properly, malfunctioning may result.

Example of Separated External Cables



■ Maintenance and Inspection Precautions

CAUTION

- ♦ Do not attempt to disassemble the MP2400.
There is a risk of electrical shock or injury.
- ♦ Do not change wiring while power is being supplied.
There is a risk of electrical shock or injury.
- ♦ When replacing the MP2400, restart operation only after transferring the programs and parameters from the old Module to the new Module.
There is a risk of device damage.

■ Disposal Precautions

CAUTION

- ♦ Correctly discard the product and used batteries as stipulated by regional, local, and municipal laws and regulations. Be sure to include these contents in all labelling and warning notifications on the final product as necessary.



■ General Precautions

Observe the following general precautions to ensure safe application.

- ♦ The products shown in illustrations in this manual are sometimes shown without covers or protective guards. Always replace the cover or protective guard as specified first, and then operate the products in accordance with the manual.
- ♦ The drawings presented in this manual are typical examples and may not match the product you received.
- ♦ If the manual must be ordered due to loss or damage, inform your nearest Yaskawa representative or one of the offices listed on the back of this manual.

Warranty

(1) Details of Warranty

■ Warranty Period

The warranty period for a product that was purchased (hereinafter called “delivered product”) is one year from the time of delivery to the location specified by the customer or 18 months from the time of shipment from the Yaskawa factory, whichever is sooner.

■ Warranty Scope

Yaskawa shall replace or repair a defective product free of charge if a defect attributable to Yaskawa occurs during the warranty period above. This warranty does not cover defects caused by the delivered product reaching the end of its service life and replacement of parts that require replacement or that have a limited service life.

This warranty does not cover failures that result from any of the following causes.

1. Improper handling, abuse, or use in unsuitable conditions or in environments not described in product catalogs or manuals, or in any separately agreed-upon specifications
2. Causes not attributable to the delivered product itself
3. Modifications or repairs not performed by Yaskawa
4. Abuse of the delivered product in a manner in which it was not originally intended
5. Causes that were not foreseeable with the scientific and technological understanding at the time of shipment from Yaskawa
6. Events for which Yaskawa is not responsible, such as natural or human-made disasters

(2) Limitations of Liability

1. Yaskawa shall in no event be responsible for any damage or loss of opportunity to the customer that arises due to failure of the delivered product.
2. Yaskawa shall not be responsible for any programs (including parameter settings) or the results of program execution of the programs provided by the user or by a third party for use with programmable Yaskawa products.
3. The information described in product catalogs or manuals is provided for the purpose of the customer purchasing the appropriate product for the intended application. The use thereof does not guarantee that there are no infringements of intellectual property rights or other proprietary rights of Yaskawa or third parties, nor does it construe a license.
4. Yaskawa shall not be responsible for any damage arising from infringements of intellectual property rights or other proprietary rights of third parties as a result of using the information described in catalogs or manuals.

(3) Suitability for Use

1. It is the customer's responsibility to confirm conformity with any standards, codes, or regulations that apply if the Yaskawa product is used in combination with any other products.
2. The customer must confirm that the Yaskawa product is suitable for the systems, machines, and equipment used by the customer.
3. Consult with Yaskawa to determine whether use in the following applications is acceptable. If use in the application is acceptable, use the product with extra allowance in ratings and specifications, and provide safety measures to minimize hazards in the event of failure.
 - Outdoor use, use involving potential chemical contamination or electrical interference, or use in conditions or environments not described in product catalogs or manuals
 - Nuclear energy control systems, combustion systems, railroad systems, aviation systems, vehicle systems, medical equipment, amusement machines, and installations subject to separate industry or government regulations
 - Systems, machines, and equipment that may present a risk to life or property
 - Systems that require a high degree of reliability, such as systems that supply gas, water, or electricity, or systems that operate continuously 24 hours a day
 - Other systems that require a similar high degree of safety
4. Never use the product for an application involving serious risk to life or property without first ensuring that the system is designed to secure the required level of safety with risk warnings and redundancy, and that the Yaskawa product is properly rated and installed.
5. The circuit examples and other application examples described in product catalogs and manuals are for reference. Check the functionality and safety of the actual devices and equipment to be used before using the product.
6. Read and understand all use prohibitions and precautions, and operate the Yaskawa product correctly to prevent accidental harm to third parties.

(4) Specifications Change

The names, specifications, appearance, and accessories of products in product catalogs and manuals may be changed at any time based on improvements and other reasons. The next editions of the revised catalogs or manuals will be published with updated code numbers. Consult with your Yaskawa representative to confirm the actual specifications before purchasing a product.

Contents

Using this Manual	iii
Safety Information	v
Safety Precautions	vi
Warranty	x
1 Overview	1-1
1.1 MP2400 Features	1-2
1.2 MP2400 Configuration	1-3
1.2.1 Basic Module Appearance	1-3
1.2.2 MP2400 Modules	1-3
1.3 System Configuration	1-4
1.3.1 Example	1-4
1.4 Devices Connectable to MECHATROLINK	1-6
1.4.1 Devices Connectable to MECHATROLINK-I/II	1-6
1.5 Cables and Accessories	1-8
1.5.1 Cables	1-8
1.5.2 Accessories and Options	1-8
1.5.3 Software (Programming Tool)	1-8
2 Specifications and Functions	2-1
2.1 Specifications	2-2
2.1.1 General Specifications	2-2
2.1.2 Product Specifications	2-3
2.1.3 Function Lists	2-4
2.2 Basic Module	2-7
2.2.1 Outline of Functions	2-7
2.2.2 External Appearance, LED Indicators, and Switch Settings	2-8
2.2.3 Specifications	2-11
2.2.4 218IFA Module (Ethernet)	2-12
2.2.5 Built-in SVB Module	2-29
2.2.6 SVR Virtual Motion Module	2-45
2.2.7 M-EXECUTOR Module (Motion Program Executor)	2-48
2.3 External Appearance	2-59
2.3.1 Basic Module	2-59
2.3.2 Basic Module with Metal Fittings	2-60
3 Mounting and Wiring	3-1
3.1 Mounting MP2400	3-2
3.1.1 Method	3-2
3.1.2 MP2400 Mount Direction	3-7
3.1.3 Space Required for Mounting MP2400	3-8
3.2 Basic Module Connections	3-9
3.2.1 Connectors	3-9
3.2.2 Power Supply Connector	3-10
3.2.3 MECHATROLINK Connectors	3-11
3.2.4 Ethernet Connector Details	3-14

3.2.5 RLY OUT Connector Details - - - - -	3-18
3.2.6 System Connection Example - - - - -	3-20
4 System Start Up and Easy Programming - - - - -	4-1
4.1 System Startup Overview - - - - -	4-2
4.2 Preparation (step 1) - - - - -	4-3
4.2.1 Wiring- - - - -	4-3
4.2.2 Self Configuration - - - - -	4-5
4.2.3 Test Operation- - - - -	4-6
4.3 Programming (step 2) - - - - -	4-9
4.3.1 Programming Procedure - - - - -	4-9
4.4 Executing Motion (step 3) - - - - -	4-11
4.4.1 Registering Program Execution - - - - -	4-11
4.4.2 Starting a Motion Program Using the Operation Control Panel- - - - -	4-12
4.5 Starting Motion Program from an External Signal- - - - -	4-13
4.5.1 Overview - - - - -	4-13
4.5.2 Required Equipment - - - - -	4-13
4.5.3 Creation Procedure - - - - -	4-15
5 Outline of Motion Control Systems- - - - -	5-1
5.1 Startup Sequence and Basic Operation - - - - -	5-2
5.1.1 DIP Switch Settings - - - - -	5-2
5.1.2 Startup Sequence - - - - -	5-3
5.1.3 Startup Sequence Operation Details - - - - -	5-4
5.2 User Programs - - - - -	5-5
5.2.1 Types and Execution Timing of User Program - - - - -	5-5
5.2.2 Motion Programs- - - - -	5-6
5.2.3 Sequence Program - - - - -	5-22
5.3 Registers - - - - -	5-25
5.3.1 Types of Registers- - - - -	5-25
5.3.2 Data Types - - - - -	5-27
5.4 Self-configuration - - - - -	5-28
5.4.1 How to Execute Self-Configuration - - - - -	5-29
5.4.2 Definition Information Updated with Self-Configuration - - - - -	5-33
5.5 Precaution on Using MP2400 - - - - -	5-36
5.5.1 Precautions when User Definition File is Configured/Changed- - - - -	5-36
5.5.2 Setting or Changing Module Configuration Definition Files - - - - -	5-37
5.5.3 Setting and Changing the Scan Time - - - - -	5-38
6 Ethernet Communications- - - - -	6-1
6.1 Communication Methods- - - - -	6-2
6.2 Communication with Other MP Series - - - - -	6-3
6.2.1 When the MP2400 Acts as Slave (automatic receive function is used) - - - - -	6-3
6.2.2 When MP2400 Acts as Master (I/O message communication function is used) - - - - -	6-16
6.3 Communication with Touch Panel- - - - -	6-29
6.3.1 When MP2400 Acts as Slave - - - - -	6-29

6.4 Communication with PLC Manufactured by Mitsubishi Electric Corporation (MELSEC protocol) - - - - -	6-39
6.4.1 When the MP2400 Acts as Slave (automatic receive function is used) - - - - -	6-39
6.4.2 When the MP2400 Acts as Master (I/O message communication function is used) - - - - -	6-46
7 Maintenance and Inspection - - - - -	7-1
7.1 Daily Inspections - - - - -	7-2
7.2 Regular Inspections - - - - -	7-3
7.3 Replacing the Basic Module Battery - - - - -	7-4
8 Troubleshooting - - - - -	8-1
8.1 Basic Flow of Troubleshooting - - - - -	8-2
8.2 LED Indicator Meanings - - - - -	8-3
8.3 Problem Classification - - - - -	8-4
8.3.1 Overview - - - - -	8-4
8.3.2 MP2400 Error Check Flowchart - - - - -	8-5
8.4 Troubleshooting Details - - - - -	8-6
8.4.1 Operation Errors - - - - -	8-6
8.4.2 I/O Errors - - - - -	8-9
8.4.3 Watchdog Timer Timeout Errors - - - - -	8-10
8.4.4 Module Synchronization Errors (Ver. 2.75 or Later) - - - - -	8-10
8.4.5 System Errors - - - - -	8-11
Appendices	
Appendix A System Registers Lists - - - - -	A-2
A.1 System Service Registers - - - - -	A-2
A.2 System Status - - - - -	A-6
A.3 System Error Status - - - - -	A-7
A.4 User Operation Error Status - - - - -	A-9
A.5 System Service Execution Status - - - - -	A-10
A.6 User Operation Error Status Details - - - - -	A-11
A.7 System I/O Error Status - - - - -	A-12
A.8 Compact Flash Card-Related System Registers (CPU-02 and CPU-03 Modules for the MP2200 Only) - - - - -	A-13
A.9 Interrupt Status - - - - -	A-14
A.10 Module Information - - - - -	A-15
A.11 MPU-01 System Status - - - - -	A-16
A.12 Motion Program Information - - - - -	A-17
Appendix B Motion Parameter Details - - - - -	A-20
B.1 Fixed Parameter List - - - - -	A-20
B.2 Setting Parameter List - - - - -	A-22
B.3 Monitoring Parameter List - - - - -	A-27
Appendix C Simple Connection Function of the Engineering Tool - - - - -	A-31
C.1 Preparation - - - - -	A-31
C.2 Procedure - - - - -	A-31

INDEX

Revision History

Overview

This chapter explains an overview and features of the MP2400 Machine Controller.

1.1 MP2400 Features	1-2
1.2 MP2400 Configuration	1-3
1.2.1 Basic Module Appearance	1-3
1.2.2 MP2400 Modules	1-3
1.3 System Configuration	1-4
1.3.1 Example	1-4
1.4 Devices Connectable to MECHATROLINK	1-6
1.4.1 Devices Connectable to MECHATROLINK-I/II	1-6
1.5 Cables and Accessories	1-8
1.5.1 Cables	1-8
1.5.2 Accessories and Options	1-8
1.5.3 Software (Programming Tool)	1-8

1.1 MP2400 Features

The MP2400 is a small all-in-one machine controller, and successor to the MP2000 series in function and performance. It is characterized by the following standard features:

■ Standard Feature Motion Network MECHATROLINK-II

- Controls up to 16 axes of servos supporting MECHATROLINK-II.
- Connects up to 21 stations including I/Os.

■ Standard Feature Ethernet (100Mbps)

- Allows high-speed communications with the engineering tool MPE720.
- Enables communication without a ladder program by using a touch panel (automatic receive function).
- Enables communication without a ladder program by using an upper PLC (I/O message communication function).

■ Simple Programming


- The operation procedures needed before performing a motion operation are significantly reduced.
- You can start up a motion program from an upper PLC without the need for programming, simply by creating the motion program and registering execution orders.

1.2 MP2400 Configuration

The MP2400 is configured with one Basic Module.

1.2.1 Basic Module Appearance

The following figure shows the external appearance of the Basic Module with metal fittings for attachment. Also, the values in the figure do not include the length of metal fittings.



1.2.2 MP2400 Modules


The following table shows the names and specifications of the Basic Module.

Group	Name	Description	Model	Specifications
MP2400 Basic Module	Basic Module	MP2400	JPMC-MP2400-E	MECHATROLINK-I and -II Interface Ethernet communications

1.3 System Configuration

1.3.1 Example

The following diagram shows an example of system configuration.



- ♦ For the details on the system configuration example, refer to 4.2.1 (1) *System Layout Model* on page 4-3.
- ♦ Use the connecting cables and connectors recommended by Yaskawa. Always check the device to be used and select the correct cable for the device.
- ♦ Different SERVOPACKs are connected to MECHATROLINK-I (4 Mbps) and MECHATROLINK-II (10 Mbps). Refer to 1.4 *Devices Connectable to MECHATROLINK* on page 1-6 and select the appropriate SERVOPACKs.
- ♦ If devices compatible with MECHATROLINK-I and with MECHATROLINK-II are used together, make the settings for MECHATROLINK-I.
- ♦ The user must supply the 24-VDC power supply.
- ♦ When connecting SERVOPACKs via MECHATROLINK, connect the overtravel, zero point return deceleration limit switch, and external latch signals to the SERVOPACKs. For connection, refer to the SERVOPACK's manual.

1.4 Devices Connectable to MECHATROLINK

1.4.1 Devices Connectable to MECHATROLINK-I/II

The devices that are compatible with MECHATROLINK-I/II and can be connected to the MP2400 and the SVB-01 Module are listed below.

(1) Compatible SERVOPACKs

Model Number	Details	MECHATROLINK-I	MECHATROLINK-II
SGD-□□□N SGDB-□□AN	MECHATROLINK-I-compatible AC SERVOPACK	Yes	No
SGDH-□□□E JUSP-NS100	Σ-II Series SGDH SERVOPACK NS100 MECHATROLINK-I Application Module	Yes	No
SGDH-□□□E JUSP-NS115	Σ-II Series SGDH SERVOPACK NS115 MECHATROLINK-II Application Module	Yes	Yes
SGDS-□□□1□□	Σ-III Series SGDS SERVOPACK	Yes	Yes
SGDX-□□□12□	SGDX SERVOPACK	Yes	Yes
SJDE-□□AN□	SJDE SERVOPACK	No	Yes
SGDV-□□□□1□□	SGDV SERVOPACK	Yes	Yes
SGD7S-□□□□10□	SGD7S SERVOPACK	Yes	Yes

(2) Compatible Inverters

Model Number	Details	MECHATROLINK-I	MECHATROLINK-II
CIMR-G7A□ SI-T	Varispeed G7 Inverter with MECHATROLINK interface	Yes	Yes
CIMR-F7A□ SI-T	Varispeed F7 Inverter with MECHATROLINK interface	Yes	Yes
CIMR-V7AA□ SI-T/V7	VSmini V7 Inverter with MECHATROLINK interface	Yes	Yes
CIMR-A□ SI-T3	High Performance Vector Control Drive A1000 MECHATROLINK-II Option Card	Yes	Yes
CIMR-V□ SI-T3/V	Compact Vector Control Drive V1000 MECHATROLINK-II Option Unit	Yes	Yes

(3) Compatible Modules

Model Number	Details	MECHATROLINK-I	MECHATROLINK-II
JEPMC-IO350	64-point I/O Module 24 VDC, 64 inputs, 64 outputs (sink)	Yes	No
JAMSC-120DDI34330	DC Input Module 12/24 VDC, 16 inputs	Yes	No
JAMSC-120DDO34340	DC Output Module 12/24 VDC, 16 outputs	Yes	No
JAMSC-120DAI53330	AC Input Module 100 VAC, 8 inputs	Yes	No
JAMSC-120DAI73330	AC Input Module 200 VAC, 8 inputs	Yes	No
JAMSC-120DAO83330	AC Output Module 100/200 VAC, 8 outputs	Yes	No
JAMSC-120DRA83030	Relay Module Wide voltage range relay contacts, 8 contact outputs	Yes	No
JAMSC-120AVI02030	A/D Module Analog inputs, -10 to 10 V, 4 channels	Yes	No
JAMSC-120AVO01030	D/A Module Analog outputs, -10 to 10 V, 2 channels	Yes	No
JAMSC-120EHC21140	Counter Module Reversible counter, 2 channels	Yes	No
JAMSC-120MMB20230	Pulse Output Module, Pulse output, 2 channels	Yes	No

(cont'd)

Model Number	Details	MECHATROLINK-I	MECHATROLINK-II
JEPMC-IO2310 JEPMC-IO2310-E	64-point I/O Module 24 VDC, 64 inputs, 64 outputs (sink)	Yes	Yes
JEPMC-IO2330 JEPMC-IO2330-E	64-point I/O Module 24 VDC, 64 inputs, 64 outputs (source)	Yes	Yes
JEPMC-PL2900 JEPMC-PL2900-E	Counter Module Reversible counter, 2 channels	Yes	Yes
JEPMC-PL2910 JEPMC-PL2910-E	Pulse Output Module Pulse output, 2 channels	Yes	Yes
JEPMC-AN2900 JEPMC-AN2900-E	A/D Module Analog inputs, -10 to 10 V, 4 channels	Yes	Yes
JEPMC-AN2910 JEPMC-AN2910-E	D/A Module Analog outputs, -10 to 10 V, 2 channels	Yes	Yes
JAMSC-IO2900-E	DC Input Module 24 VDC, 16 inputs	Yes	Yes
JAMSC-IO2910-E	DC Output Module 24 VDC, 16 outputs	Yes	Yes
JAMSC-IO2920-E	8-point I/O Module 24 VDC, 8 inputs, 8 outputs	Yes	Yes
JAMSC-IO2950-E	Relay Module Wide voltage range relay contacts, 8 contact outputs	Yes	Yes
AB023-M1	MECHATROLINK Bit decentralization I/O terminal (by Anywire Corporation)	Yes	Yes
JAPMC-MC2310 JAPMC-MC2310-E	SVB-01 Motion Module	Yes	Yes
JEPMC-REP2000 JEPMC-REP2000-E	MECHATROLINK-II repeater	No	Yes
JEVSA-YV250 JEVSA-YV250-E	MYVIS YV250 Machine Vision System	Yes	Yes
JEVSA-YV260□□-E	MYVIS YV260 Machine Vision System	Yes	Yes

1.5 Cables and Accessories

1.5.1 Cables

The following table shows the cables that can be connected to the MP2400 Basic Module and Optional Modules.

Module	Connector Name	Application	Model	Specifications
MP2400 Basic Module	Ethernet	Ethernet communication cable	Provided by customers.	–
	M-I/II	MECHATROLINK-II cable	JEPMC-W6002-□□-E *with MECHATROLINK connectors on both ends	Used between the devices listed below SVB and MECHATROLINK-II Compatible Devices
			JEPMC-W6003-□□-E *with MECHATROLINK connectors on both ends, with ferrite core	
		MECHATROLINK-II terminator	JEPMC-W6022-E	–

1.5.2 Accessories and Options

Name	Accessory/Optional	Model	Remarks
Battery	Accessory	JZSP-BA01	ER3VC + exclusive use connector (BA000517)
Power Supply Connector	Accessory	721-203/026	Cable side
RLY OUT Connector	Accessory	734-YE102-2	Cable side
DIN Rail Mounting Parts	Accessory	DIN rail spring	Q'ty: 1
		DIN rail lock	Q'ty: 1
Terminator (Terminating Resistor)	Accessory	JEPMC-W6022-E	Q'ty: 1
Metal Fittings for Attachment	Optional	JEPMC-OP2400-E	–

1.5.3 Software (Programming Tool)

The MPE720, programming tool for MP2400, is available.

Name	Model	Remarks
MPE720 Ver. 6	CPMC-MPE770D (Ver. 6.04 or later)	DVD-ROM (1 disk)
MPE720 Ver. 6 Lite	CPMC-MPE770L (Ver. 6.04 or later)	Can be downloaded from the Yaskawa's products and technical information website (http://www.e-mechatronics.com)
MPE720 Ver. 7	CPMC-MPE780D (All versions)	DVD-ROM (1 disk)
MPE720 Ver. 7 Lite	CPMC-MPE780L (All versions)	Can be downloaded from the Yaskawa's products and technical information website (http://www.e-mechatronics.com)

Specifications and Functions

This chapter explains detailed specifications for the Basic Module and Optional Modules of the MP2400.

2.1 Specifications	2-2
2.1.1 General Specifications	2-2
2.1.2 Product Specifications	2-3
2.1.3 Function Lists	2-4
2.2 Basic Module	2-7
2.2.1 Outline of Functions	2-7
2.2.2 External Appearance, LED Indicators, and Switch Settings	2-8
2.2.3 Specifications	2-11
2.2.4 218IFA Module (Ethernet)	2-12
2.2.5 Built-in SVB Module	2-29
2.2.6 SVR Virtual Motion Module	2-45
2.2.7 M-EXECUTOR Module (Motion Program Executor)	2-48
2.3 External Appearance	2-59
2.3.1 Basic Module	2-59
2.3.2 Basic Module with Metal Fittings	2-60

2.1 Specifications

2.1.1 General Specifications

Item		Specifications
Environmental Conditions	Ambient Operating Temperature	0°C to 55°C
	Ambient Storage Temperature	-25°C to 85°C
	Ambient Operating Humidity	30% to 95% (with no condensation)
	Ambient Storage Humidity	5% to 95% (with no condensation)
	Pollution Level	Pollution level 2 (conforming to JIS B 3502)
	Corrosive Gas	There must be no combustible or corrosive gas.
	Operating Altitude	2,000 m above sea level or lower
Mechanical Operating Conditions	Vibration Resistance	Conforming to JIS B 3502: • 10 to 57 Hz with single-amplitude of 0.075 mm • 57 to 150 Hz with fixed acceleration of 9.8 m/s² • 10 sweeps each in X, Y, and Z directions (sweep time: 1 octave/min.)
	Shock Resistance	Conforming to JIS B 3502: Peak acceleration of 147 m/s ² (15 G) twice for 11 ms each in the X, Y, and Z directions
Electrical Operating Conditions	Noise Resistance	Conforming to EN 61000-6-2, EN 61000-6-4, EN 55011 (Group 1 Class A) and EN61131-2(clause 8,Zone B)
Installation Requirements	Ground	Ground to 100 Ω max.
	Cooling Method	Natural cooling

2.1.2 Product Specifications

The following table shows the product specifications of the MP2400.

Items		MP2400
External Dimensions		45 mm × 130 mm × 108 mm
Number of Control Axes	Maximum Number of Control Axes	16 axes
	Number of Virtual Axis Controlling Axes	16 axes
MECHATROLINK	Communication System	MECHATROLINK-I, MECHATROLINK-II (32 byte), or MECHATROLINK-II (17 byte)
	Communication Cycle (M-II)	0.5 ms, 1 ms, 1.5 ms, or 2 ms
	Maximum Number of Connectable Stations (M-II)	21 stations (up to 16 servo stations)
	Slave Function	√
Scan Interval Setting	High-speed Scan	1.0 ms to 32 ms (per 0.5 ms)
	Low-speed Scan	2.0 ms to 300 ms (per 0.5 ms)
Communication I/F	Ethernet	100Base-TX 1 port
I/O	On-board I/O	– (Optional)
	Output Signal during RUN	√
Memory Capacity	SDRAM	32 MB
	SRAM	512 KB (Battery backup)
	FLASH	8 MB
	Program Capacity	5.5 MB
Programming Language	Ladder Language	–
	Motion Language	√
	Sequence Program	√
	C Language	√

- Symbols in the table mean as follows.

M-I: MECHATROLINK-I, M-II: MECHATROLINK-II

√: Available, –: Not available

2.1.3 Function Lists

(1) PLC Function Specifications

The following table shows the PLC function specifications.

Item	Specifications
Control Method	Sequence: High-speed and low-speed scan methods
Programming Language	Text-type language: Numeric operations, logic operations, etc.
Scan	Two scan levels: High-speed scan and low-speed scan High-speed scan time setting: 1.0 to 32 ms (Integral multiple of MECHATROLINK communication cycle) Low-speed scan time setting: 2 to 300 ms (Integral multiple of MECHATROLINK communication cycle)
Motion Programs	Motion programs and sequence programs: A total of up to 256 Revision history of motion programs Security function for motion programs
Data Memory	Common data (M) registers: 64 kwords System (S) registers: 8 kwords Input (I) registers: 32 kwords (including internal input registers) Output (O) registers: 32 kwords (including internal output registers) Constant (C) registers: 16 kwords
Trace Memory	Data trace: 128 kwords (32 kwords × 4 groups), 16 points defined
Memory Backup	Program memory: Flash memory: 8 MBytes (User area: 5.5 MBytes) definition files, ladder programs, motion programs, etc. Data other than battery backup data Data memory: Battery backup: 512 kbytes, M registers, S registers, alarm history, trace data
Data Types	Bit (relay): ON/OFF Integer: -32768 to +32767 Double-length integer: -2147483648 to +2147483647 Real number: ± (1.175E-38 to 3.402E+38)
Register Designation Method	Register number: Direct designation of register number Symbolic designation: Up to 8 alphanumeric characters (up to 200 symbols per drawing) With automatic number or symbol assignment

(2) Motion Control Function Specifications

The following table lists the motion control function specifications for the MP2400.

Item			Specifications	
Interface			MECHATROLINK-I, MECHATROLINK-II	
Number of Controlled Axes/Module			Up to 16 axes	
Control Specifications	PTP Control		Linear, rotary, and infinite-length	
	Interpolation		Up to 16 linear axes, 2 circular axes, and 3 helical axes	
	Speed Reference Output		Yes (Only with MECHATROLINK-II)	
	Torque Reference Output		Yes (Only with MECHATROLINK-II)	
	Phase Control		Yes (Only with MECHATROLINK-II)	
	Position Control	Positioning		Yes
		External positioning		Yes
		Zero point return		Yes
		Interpolation		Yes
		Interpolation with position detection function		Yes
		JOG operation		Yes
		STEP operation		Yes
		Parameter changes during motion command execution		Yes (Only with MECHATROLINK-II in 32-byte mode)
Reference Unit			mm, inch, deg, or pulse	
Reference Unit Minimum Setting			1, 0.1, 0.01, 0.001, 0.0001, 0.00001	
Maximum Programmable Value			−2147483648 to +2147483647 (signed 32-bit value)	
Speed Reference Unit			Reference unit/s designation: mm/s, inch/s, deg/s, pulse/s Reference unit/min. designation: mm/min., inch/ min., deg/min., pulse/min. Percentage designation: Percentage of rated speed	
Acceleration/Deceleration Type			Linear, asymmetric, S-curve, exponent	
Acceleration/Deceleration Reference Unit			Reference unit/s ² designation: mm/s ² , inch/s ² , deg/s ² , pulse/s ² Acceleration/deceleration time constant: Time from 0 to rated speed (ms)	
Override Function			Positioning: 0.01% to 327.67% by axis	
Coordinate System			Rectangular coordinates	
Zero Point Return	DEC1+ Phase-C pulse		Yes	
	ZERO signal		Yes	
	DEC1+ ZERO signal		Yes	
	Phase-C pulse		Yes	
	Only Phase-C pulse		Yes	
	POT and Phase-C pulse		Yes	
	POT		Yes	
	Home limit switch and Phase-C pulse		Yes	
	HOME		Yes	
	NOT and Phase-C pulse		Yes	
	NOT		Yes	
	INPUT and Phase-C pulse		Yes	
	INPUT		Yes	

2.1 Specifications

2.1.3 Function Lists


Item	Specifications	
Applicable SERVOPACKs	■ MECHATROLINK-I • SERVOPACKs SGD-□□□N SGDB-□□AN SGDH-□□□E + NS100 SGDS-□□□1□□ SGDV-□□□1□□	■ MECHATROLINK-II • SERVOPACKs SGDH-□□□E + NS115 SGDS-□□□1□□ SGDV-□□□1□□ SGD7S-□□□□10
Encoders	• Incremental Encoder • Yaskawa Absolute Encoder	

2.2 Basic Module

This section describes the functions, the external appearance, the LED indicators, the setting switches, and the hardware specifications of the MP2400 Basic Module and also describes the virtual motion module (SVR).


2.2.1 Outline of Functions

The Basic Module is an all-in-one, compact module that combines power supply, CPU, and 218IFA in one module. The Basic Module has both motion control and sequence control functions. With a slot option slot configuration, Optional Modules can be selected freely and the optimum system can be built for your machine. An outline of the Basic Module functions is shown in the following diagram.



2.2.2 External Appearance, LED Indicators, and Switch Settings

(1) External Appearance



(2) Indicators

The following table shows the indicators that show the operating status of the Basic Module and error information.


	Indicator	Color	Status
RDY ALM MTX TRX ○ ○ ○ ○ RUN ERR BAT IP	RDY	Green	Lights up during normal operation.
	RUN	Green	Lights up during execution of user program.
	ALM	Red	Lights up or blinks when warning occurs.
	ERR	Red	Lights up or blinks when malfunction occurs.
	MTX	Green	Lights up when submitting MECHATROLINK-I/ MECHATROLINK-II data.
	BAT	Red	Lights up during battery alarm.
	TRX	Green	Lights up when transmitting and receiving Ethernet data.
	IP	Green	Lights up when an IP address setting is completed. Blinks when Ethernet port error occurs.

- For details on indicator meanings, refer to 8.2 LED Indicator Meanings on page 8-3.

(3) Switch Settings

The DIP switch sets the operating conditions for the Basic Module when the power is turned ON.

[a] SW1



No.	Name	Setting	Operating Mode	Default	Details
S1-6	STOP	ON	User program stopped	OFF	Stops the user program execution. Enabled only when the power is turned ON.
		OFF	User program running		
S1-5	SUP	ON	System load	OFF	Always leave set to OFF.
		OFF	Normal operation		
S1-4	INIT	ON	Memory clear	OFF	Set to ON to clear the memory. If this switch is set to OFF, the program stored in flash memory will be executed.
		OFF	Normal operation		
S1-3	CNFG	ON	Self-configuration mode	OFF	Set to ON to execute self-configuration for connected devices.
		OFF	Normal operation		
S1-2	MON	ON	System use	OFF	Always leave set to OFF.
		OFF	Normal operation		
S1-1	TEST	ON	System use	OFF	Always leave set to OFF.
		OFF	Normal operation		

[b] SW2

Sets the Ethernet port condition and other operating conditions.
The change of switch setting is invalid after the power is turned ON (read only when the module is initialized by software).



No.	Switch Name	State	Operation Mode	Default	Description
S2-4	—	ON	Reserved	OFF	Reserved for future use
		OFF			
S2-3	—	ON	Reserved	OFF	Reserved for future use
		OFF			
S2-2	E-INIT	ON	Transmission parameter for Ethernet, default	OFF	When ON, transmission parameters such as an IP address are set to default at startup.
		OFF	Normal operation		
S2-1	E-TEST	ON	System use	OFF	Always leave set to OFF
		OFF	Normal operation		

2.2.3 Specifications

(1) Hardware Specifications

The following table shows hardware specifications for the basic module:

Item		Specifications
Classification		Basic Module
Name		MP2400
Model Number		JEPMC-MP2400-E
Power Unit	Input Voltage	24 VDC ($\pm 20\%$)
	Input Current*	1 A max. (during input/output rating)
	Inrush Current*	40 A max. (full discharge state, during output rating, or the secondary output of the external 24 V power supply is turned ON)
	Allowable Power Loss Time	2 ms
	Rated Voltage	5.0 V
	Rated Current	2.0 A
	Output Current Range	0.0 to 2.0 A
	Constant Voltage Precision	$\pm 2\%$ max. (including input voltage and output load fluctuations)
Battery		Battery for memory retention attachable
Flash Memory		8 MBytes (User area 5.5 MBytes)
SDRAM		32 MBytes
SRAM		512 kBytes: M registers, S registers, trace memory, alarm history (battery backup)
Motion Network		MECHATROLINK: 1 channel SERVOPACK and I/O for up to 21 stations connectable (SERVOPACK for up to 16 axes) Baud rate: 4 Mbps (MECHATROLINK-I) or 10 Mbps (MECHATROLINK-II)
Communication Function		Ethernet: 100BASE-TX/10BASE-T
Calendar		Seconds to year timer (Battery backup)
Connectors		POWER: Power supply connector M-I/II: MECHATROLINK connector Ethernet: Ethernet connector RLY OUT: RLY OUT connector
Indicators		RDY(green), RUN(green), ALM(red), ERR(red), MTX(green), BAT(red), TRX(green), IP(green), LINK(yellow), 100M(green)
Switches		STOP, SUP, INIT, CNFG, MON, TEST, E-INIT, and E-TEST
Current Consumption		1 A max.
Dimensions (mm)		45 × 130 × 108 (W × H × D)
Mass		350 g

* For the external 24V power supply, select a power supply which satisfies the specifications below as well as the rated current (not more than 1A):

- ♦ Allowable output load capacity: 1200 μ F or more
- ♦ Overcurrent detection is automatically restored by removing causes

However, except that the primary side (AC side) of the external 24V power supply is turned ON/OFF.

Note: Recommended external 24V power supply: RTW24-2R2 (manufactured by TDK)

2.2.4 218IFA Module (Ethernet)

(1) Overview of 218IFA Module Functions

MP2400 built-in 218IFA module is a 10Base-T/100Base-TX Ethernet interface and a communication interface equipped as standard in MP2400.

- 100Mbps transmission speed is supported (100Base-TX).
- Supports the following various communication protocols:
 - Support for MEMOBUS protocol, Extended MEMOBUS protocol
 - Support for MELSEC protocol
 - Support for MODBUS/TCP protocol
- An I/O message communication function enables you the data exchange in the form of I/O image when communicating with upper PLC, eliminating you from creating a ladder program.
- An automatic receive function eliminates you from creating a ladder program when connected to the indicator and the like.
- Enables you to use as a standard interface with the engineering tool MPE720. In addition, provides a simple function for connecting with the engineering tool, allowing you to connect to MPE720 without the knowledge of MP2400 IP address.

(2) Specification of 218IFA Module

The following table shows the specification of the 218IFA Module.

Items		MP2400/218IFA
Communication Interface (Note1)		10Base-T/100Base-TX
Communication Protocol (Note2)		TCP/UDP/IP/ARP/ICMP
Maximum Number of Communication Connections		1 (automatic receive) +2 (I/O Message communication)
Maximum Number of Communication Channels		1 (automatic receive) +2 (I/O Message communication)
Message Communication (maximum) *When automatic receive is used.	MEMOBUS	Write: 100W Read: 125W
	Extended MEMOBUS	Write: 2043W Read: 2044W
	MELSEC	Write: 1017W Read: 1017W
	MODBUS/TCP	Write: 100W Read: 125W
I/O Message Communication (maximum)	MEMOBUS	Write: 100W Read: 125W
	Extended MEMOBUS	Write: 1024W Read: 1024W
	MELSEC	Write: 256W Read: 256W
	MODBUS/TCP	Write: 100W Read: 125W
Automatic Receive	MEMOBUS	○
	Extended MEMOBUS	○
	MELSEC	○
	MODBUS/TCP	○
Simple Function for Connecting with Engineering Tool		○

Note: 1. Communication Interface

The discrimination between 10Base-T/100Base-TX and full-duplex/half-duplex is done by 218IFA based on the remote equipment. When connecting to an equipment without automatic negotiation function, set the remote equipment to half-duplex mode.

Correspondence of Communication Mode

218IFA Module	Device to be connected				
	Automatic Negotiation	10Base-T Half-duplex	10Base-T Full-duplex	100Base-TX Half-duplex	100Base-TX Full-duplex
Automatic Negotiation	Depends on the remote equip- ment	Communicates in 10Base-T half-duplex mode	Unable to communicate	Communicates in 100Base-TX half-duplex mode	Unable to communicate


2. Communication protocols

- TCP(Transmission Control Protocol): Connection-oriented transport layer protocol
- UDP(User Datagram Protocol): Connectionless transport layer protocol
- IP(Internet Protocol): Protocol for establishing a communication link between computers
- ICMP(Internet Control Message Protocol): Error control protocol for IP protocol
- ARP(Address Resolution Protocol): Address resolving protocol. Protocol for converting IP address into MAC address

(3) Module Configuration Definition

(a) Module Configuration Definition Window Details

Start the MPE720. On the **My Tool** view, click **Module Configuration** to display the Module Configuration Definition Window. The content for the No. 2 cell is the detailed definition for the 218IFA.



Items displayed in the **Module Details** area show the following meanings:


No.	Items		Display/Setting Item	Change
①	Module Type		Displays the module that is set for the slot.	√
②	Function Module/Slave		Displays the function modules and slaves that are used by the module. Changing the name to UNDEFINED enables you to disable 218IFA functions.	√
③	Status		In Online Mode, displays the status of the function modules and the communications status of MECHATROLINK slave devices.	—
④	Circuit No./Address	Start	Displays the first circuit number that is assigned to the function module.	√
		Occupied circuits	Displays the number of circuits that are assigned to the function module.	√
⑤	Motion Register		Not used. Fixed at “— — — —”.	—
⑥	Register (Input/Output)	Disabled	Used to disable inputs or outputs by selecting the check boxes.	√
⑦		Start - End	Displays start to end register of the I/O register used in the I/O message communication of 218IFA. (Setting Range: 0000-7FFF hex, Size: 800 hex words)	√
⑧		Size	Displays the number of words in the I/O area.	√
⑨		Scan	Displays the scan in which the I/O service is performed for the I/O device.	√
⑩	Comment		Displays the user comment. <Setting Conditions> Function module: 16 characters maximum. MECHATROLINK slave: 32 characters maximum.	√

√: Available, —: Not available

(4) 218IFA Module Detail Definition Window

(a) Displaying the 218IFA Module Detail Definition Window

The 218IFA Module Detail Definition Window is displayed by double-clicking the **218IFA** cell in the Module Configuration Definition Window.



(b) 218IFA Module Detail Definition Window

The 218IFA Module Detail Definition Window is composed of **Transmission Parameters** and **Status** Tabs, and each tab is changed with a click.

1. Parameter Setting Tab

The **Transmission Parameters** Tab sets 218IFA transmission parameters. The setting details are as follows:

The screenshot shows the 'Detail - [218IFA]' window. The 'Transmission Parameters' tab is active. It contains fields for IP Address, Subnet Mask, and Gateway IP Address. Below these are 'Connection Parameter' and 'I/O Message Communication' sections. The 'Easy setting' button is visible. The 'Data update timing' is set to 'Low'. The 'Head register number' and 'data size' are set to '00000' and '4' respectively. The 'Node equipment' is set to 'MP2400'.

Transmission Parameters

IP Address : 192 . 168 . 1 . 1 (0-255)
 Subnet Mask : 255 . 255 . 255 . 0 (0-255)
 Gateway IP Address : 0 . 0 . 0 . 0 (0-255)

Module Name Definition
 Equipment name : CONTROLLER NAME

Connection Parameter

Message Communication

Easy setting It is possible to following parameter setting easily that communicate the message.

CNO	Local Port	Node IP Address	Node Port	Connect Type	Protocol Type	Code	Detail
01	---	---	---	---	---	---	Setting
02	---	---	---	---	---	---	Setting
03	---	---	---	---	---	---	Setting
04	---	---	---	---	---	---	Setting

Cannot the overlap to local station port number used by the communicate the I/O message.

I/O Message Communication

Disable
 Enable

Easy setting It is possible to set easily that communicate the I/O message.

Data update timing Low Scan

Read/Write	Local Port	Node IP Address	Node Port	Connect Type	Protocol Type	Code	Detail
Read	---	---	---	---	---	---	Setting
Write	---	---	---	---	---	---	Setting

Head register number data size Head register number data size


MP2400 ☐ input disable [W00000] 4 W < Hold register(MW) 00000 4 W ☐ output disable [W00004] 4 W -> Hold register(MW) 00000 4 W Node equipment

■ Transmission Parameter Setting Items

Sets local transmission parameters for 218IFA.

Transmission Parameters				Module Name Definition	
IP Address	:	192 . 168 . 1 . 1 (0-255)	Equipment name : CONTROLLER NAME		
Subnet Mask	:	255 . 255 . 255 . 0 (0-255)			
Gateway IP Address	:	0 . 0 . 0 . 0 (0-255)	Detail Definition		

The following table shows each setting item.

Item	Setting Range	Details	Default
IP Address	0.0.0.1 to 255.255.255.254	Sets 218IFA IP address. However, the following addresses are excluded: 127.xxx.xxx.xxx xxx.xxx.xxx.000 xxx.xxx.xxx.255	192.168.001.001
Subnet Mask	0.0.0.0 to 255.255.255.254	Sets the 218IFA subnet mask.	255.255.255.000
Gateway IP Address	0.0.0.0 to 255.255.255.254	Sets the 218IFA default gateway IP address. However, the following addresses are excluded: 127.xxx.xxx.xxx xxx.xxx.xxx.000 (except 000.000.000.000) xxx.xxx.xxx.255 When you do not use it, set it to 000.000.000.000.	000.000.000.000
Equipment Name	Up to 16 single-byte characters	218IFA can be any name. The name specified here is displayed as a search result in the module name field of controller search list when running the Search in the communications setting dialog box of MPE720 Ver.7. 	CONTROLLER NAME
Detailed Definition	—	Opens the screen for setting the engineering communication with MPE720 and the MEMOBUS communication.	—

■ Detailed Setting Screen of Transmission Parameter Setting

Sets the engineering communication with MPE720 and the message communication.

The following table shows each setting item.

Item	Setting Range	Details	Default
Engineering Port	256 to 65535	Specify the 218IFA port number used in the engineering communication with MPE720. Note: When changing this setting, you must also change the Engineering Port value in the Port Setting of the MPE720 Communication Platform. The port number cannot be 9998 or 10000.	9999
Response Time	0 to 255 (sec)	Specify the wait time until a remote response is returned after sending a command, when carrying out a message communication using MSG-SND function. (value zero waits infinitely.) If the retransmit number of times is zero, set response monitor period to zero. Note: If no response is returned after the setting period expires, a timeout occurs, retry the transmission the number of times specified by resend number of times.	0
Count of Retry	0 to 255 (time)	Specify the command retransmit number of times when a timeout is detected after response monitor period expires. Note: If no response is returned after as many retries as the retransmit number of times, an error is returned to the MSG-SND function.	0

■ Message Communication Item of Connection Parameter Setting

Sets the connection parameters for the message communication using MSG-SND/MSG-RCV function and the message communication using automatic receive function.

CNO	Local Port	Node IP Address	Node Port	Connect Type	Protocol Type	Code	Detail	
01	10001	192.168.001.002	10001	TCP	Extended MEMOBUS	BIN	Setting	
02	10002	192.168.001.003	10002	TCP	MEMOBUS	ASCII	Setting	
03	10003	192.168.001.004	10003	TCP	None	BIN	Setting	
04	10004	192.168.001.005	10004	TCP	MODBUS / TCP	BIN	Setting	

Cannot the overlap to local station port number used by the communicate the I/O message.

The following table shows each setting item.

Item	Setting Range	Details	Default										
Easy Setting	—	Opens the easy setting screen for the connection parameters. The content of the selected connection is shown.	—										
Connection Number (CNO)	1	In 218IFA Ethernet communication, remote stations are distinguished by their connection numbers. Note: Settings for connection numbers 2 to 4 are invalid.	—										
Local Port	256 to 65535	Specify the 218IFA port number for each connection. 218IFA establishes a message communication with the connection with this port number only. Set an unique channel number for the port number of this connections. Also, to delete the port number, enter zero. Note: When the connection type = UDP, the port number cannot be 9998 or 10000.	0										
Node IP Address	0.0.0.0 to 255.255.255.254	Set the remote IP address for each connection. However, the following addresses are excluded: 127.xxx.xxx.xxx xxx.xxx.xxx.000 (except 000.000.000.000) xxx.xxx.xxx.255 Note: When 0.0.0.0 is set, it will enter into “Unpassive open mode.” When 218IFA is within the network specified by the subnet mask, it responds to the connection request from the remote station regardless of the remote IP address setting.	000.000.000.000										
Node Port	0 and 256 to 65535	Specify the remote port number for each connection. A pair of remote IP address and remote port number must not be duplicated. Note: In case of “Unpassive open mode,” set it to zero.	0										
Connect Type	TCP, UDP	Select a transport layer protocol. TCP: Transmission control protocol UDP: User datagram protocol	TCP										
Protocol Type	Extended MEMOBUS, MEMOBUS, MELSEC, MODBUS/TCP	Select an application layer protocol. <table><tr><th>Protocol Type</th><th>Overview</th></tr><tr><td>Extended MEMOBUS</td><td>Yaskawa’s Extended MEMOBUS protocol.</td></tr><tr><td>MEMOBUS</td><td>Yaskawa’s MEMOBUS protocol.</td></tr><tr><td>MELSEC</td><td>Ethernet I/F protocol for the sequencer (A series) manufactured by Mitsubishi Electric Corporation.</td></tr><tr><td>MODBUS/TCP</td><td>Industrial Ethernet protocol proposed by Modicon, Inc.</td></tr></table>	Protocol Type	Overview	Extended MEMOBUS	Yaskawa’s Extended MEMOBUS protocol.	MEMOBUS	Yaskawa’s MEMOBUS protocol.	MELSEC	Ethernet I/F protocol for the sequencer (A series) manufactured by Mitsubishi Electric Corporation.	MODBUS/TCP	Industrial Ethernet protocol proposed by Modicon, Inc.	Extended MEMOBUS
Protocol Type	Overview												
Extended MEMOBUS	Yaskawa’s Extended MEMOBUS protocol.												
MEMOBUS	Yaskawa’s MEMOBUS protocol.												
MELSEC	Ethernet I/F protocol for the sequencer (A series) manufactured by Mitsubishi Electric Corporation.												
MODBUS/TCP	Industrial Ethernet protocol proposed by Modicon, Inc.												


Item	Setting Range	Details	Default																							
Code	ASCII BIN RTU	Select a code type for the message communication data. Depending on protocol type, available codes are restricted as follows: <table border="1"> <thead> <tr> <th rowspan="2">Protocol Type</th><th colspan="3">Code</th></tr> <tr> <th>ASCII</th><th>BIN</th><th>RTU</th></tr> </thead> <tbody> <tr> <td>Extended MEMOBUS</td><td>√</td><td>√</td><td>—</td></tr> <tr> <td>MEMOBUS</td><td>√</td><td>—</td><td>√</td></tr> <tr> <td>MELSEC</td><td>√</td><td>√</td><td>—</td></tr> <tr> <td>MODBUS/TCP</td><td>—</td><td>√</td><td>—</td></tr> </tbody> </table> √ : Available, — : Not available	Protocol Type	Code			ASCII	BIN	RTU	Extended MEMOBUS	√	√	—	MEMOBUS	√	—	√	MELSEC	√	√	—	MODBUS/TCP	—	√	—	ASCII
Protocol Type	Code																									
	ASCII	BIN	RTU																							
Extended MEMOBUS	√	√	—																							
MEMOBUS	√	—	√																							
MELSEC	√	√	—																							
MODBUS/TCP	—	√	—																							
Detail	—	Opens the automatic receive setting screen. To open the screen, double-click this button. Note: The automatic receive function is valid only for a connection when the connection number = 1.	—																							
Node Name	Up to 32 single-byte characters (16 double-byte characters)	Any text can be entered as a connection comment.	Blank																							

■ Simple Setting Screen for Message Communication

Graphically sets connection parameters for each connection.

Basically, the same content as with message communication items in connection parameter setting can be set.

When connection parameters are not yet set and this screen is opened, the default value for each connection will be automatically stored.



The following table provides the default values for each connection stored when the connection parameters are not yet set and this screen is opened.

Item	Default
	Connection Number 01
Local Port	10001
Node IP Address	192.168.1.2
Node Port Number	10001
Communication Protocol Type	Extended MEMOBUS
Connect Type	TCP
Code	BIN

By clicking the **Default** Button, default values are set for each data code type according to the selected communication protocol type.

The following table shows the default values for each data code type.

Communication Protocol Type	Default for Data Code Type
Extended MEMOBUS	BIN
MEMOBUS	RTU
MELSEC	BIN
MODBUS/TCP	BIN

■ Automatic Receive Setting Screen for Message Communication

The automatic receive function can be enabled only for connections where the connection number = 1.

The automatic receive function enables you to automatically run a function equivalent to the MSG-RCV function.

The following table explains each setting item.

Item	Setting Range	Details	Default
Automatic Reception Enable/Disable	Enable/Disable	Select whether to enable automatic reception. Note: When the local port number is not yet set, it becomes invalid regardless of the enable/disable selection.	Enable
The setting items below can only be set when the Automatic Reception is set to "Enable."			
Transmission Buffer Channel	Cannot be set (fixed at one)	The communication buffer channel is usually used for data exchanged between the MSG-SND/MSG-RCV function and 218IFA. The communication buffer channel is associated with the connection according to the input item "CH-NO" for the MSG-SND/MSG-RCV function and node connection number (PARAM02) setting for the parameter list (PARAM). When automatic reception is running, the function equivalent to the MSG-RCV function is realized by using the communication buffer channel number "1."	1
Readout of Input Relay	IW0000 to IWFFFF	Set a start register of the input relay used for the automatic reception.	IW0000
Readout of Input Register	IW0000 to IWFFFF	Set a start register of the input register used for the automatic reception.	IW0000
Readout/Write-in of Coil	MW00000 to MW65534	Set a start read/write register of the coil used for the automatic reception.	MW00000
Readout/Write-in of Hold Register	MW00000 to MW65534	Set a start read/write register of the holding register used for automatic reception.	MW00000
Write-in Width of Coil/Hold Register (LO)	MW00000 to MW65534	Set a write range (LO) of the coil/holding registers used for automatic reception.	MW00000
Write-in Width of Coil/Hold Register (HI)	MW00000 to MW65534	Set a write range (HI) of the coil/holding registers used for the automatic reception.	MW65534

The following table provides the valid setting items for each communication protocol type.

Setting Item	Communication Protocol Type				
	Extended MEMOBUS	MEMOBUS	MELSEC	Non-procedure	MODBUS/TCP
Readout of Input Relay	√	√	—	—	√
Readout of Input Register	√	√	—	—	√
Readout/Write-in of Coil	√	√	—	—	√
Readout/Write-in of Hold Register	√	√	√	—	√
Write-in Width of Coil/Hold Register (LO)	√	√	√	—	√
Write-in Width of Coil/Hold Register (HI)	√	√	√	—	√

Note: √ : Enable
 — : Disable

■ I/O Message Communication Item Connection Parameter Setting

Sets connection parameters for I/O message communication.

I/O message communication exchanges the data using I/O images with the remote equipment.

I/O Message Communication

☐ Disable
☒ Enable

Easy setting It is possible to set easily that communicate the I/O message.

Data update timing: Low Scan

Read/Write	Local Port	Node IP Address	Node Port	Connect Type	Protocol Type	Code	Detail
Read	10005	192.168.001.007	10005	TCP	Extended MEMOBUS	BIN	Setting
Write	10006	192.168.001.007	10006	TCP	Extended MEMOBUS	BIN	Setting

MP2400

Head register number data size

☐ input disable IW00000 4 W <- Hold register(MW) 00000 4 W

☐ output disable OW00004 4 W -> Hold register(MW) 00004 4 W

Node equipment

The following table explains each setting item.

Item	Setting Range	Details	Default										
I/O Message Communication Enable/Disable	Enable/Disable	Select whether to enable I/O message communications.	Disable										
The setting items below can only be set when the I/O Message Communication is set to “Enable.”													
Easy Setting	—	Opens the Simple Setting screen for the read/write connection parameters.	—										
Data Update Timing	H Scan/ L Scan	Set when to update the I/O data for the controller side when the I/O message communication is established.	L Scan										
Read/Write	—	In 218IFA Ethernet communications, remote stations are distinguished by their connection numbers. I/O message communications have a connection for each read/write.											
Local Port	256 to 65535	Specify the 218IFA port number for each read/write connection. To delete the port number setting, enter zero. To use only a read or a write connection, set the other port number to zero to delete the connection. Note: When the connection type = UDP, the port number cannot be 9998 or 10000.	0										
Node IP Address	0.0.0.1 to 255.255.255.254	Set a remote IP address for both read and write connections. Set a common value for both read and write. However, the following addresses cannot be used: 127.xxx.xxx.xxx xxx.xxx.xxx.000 xxx.xxx.xxx.255	000.000.000.000										
Node Port	256 to 65535	Specify the remote port number for each read/write connection. A pair of a remote IP address and remote port number must not be duplicated.	0										
Connect Type	TCP UDP	Select a transport layer protocol. TCP: Transmission control protocol UP: User datagram protocol	TCP										
Protocol Type	Extended MEMOBUS, MEMOBUS, MELSEC, MODBUS/TCP	Select an application layer protocol. <table><tr><th>Protocol Type</th><th>Overview</th></tr><tr><td>Extended MEMOBUS</td><td>Yaskawa’s Extended MEMOBUS protocol.</td></tr><tr><td>MEMOBUS</td><td>Yaskawa’s MEMOBUS protocol.</td></tr><tr><td>MELSEC</td><td>Ethernet I/F protocol for the sequencer (A series) manufactured by Mitsubishi Electric Corporation.</td></tr><tr><td>MODBUS/TCP</td><td>Industrial Ethernet protocol proposed by Modicon, Inc.</td></tr></table>	Protocol Type	Overview	Extended MEMOBUS	Yaskawa’s Extended MEMOBUS protocol.	MEMOBUS	Yaskawa’s MEMOBUS protocol.	MELSEC	Ethernet I/F protocol for the sequencer (A series) manufactured by Mitsubishi Electric Corporation.	MODBUS/TCP	Industrial Ethernet protocol proposed by Modicon, Inc.	Extended MEMOBUS
Protocol Type	Overview												
Extended MEMOBUS	Yaskawa’s Extended MEMOBUS protocol.												
MEMOBUS	Yaskawa’s MEMOBUS protocol.												
MELSEC	Ethernet I/F protocol for the sequencer (A series) manufactured by Mitsubishi Electric Corporation.												
MODBUS/TCP	Industrial Ethernet protocol proposed by Modicon, Inc.												


Item	Setting Range	Details	Default																							
Code	ASCII BIN RTU	Select a code type for the message communication data. Depending on protocol type, available codes are restricted as follows: <table border="1"> <thead> <tr> <th rowspan="2">Protocol Type</th><th colspan="3">Code</th></tr> <tr> <th>ASCII</th><th>BIN</th><th>RTU</th></tr> </thead> <tbody> <tr> <td>Extended MEMOBUS</td><td>√</td><td>√</td><td>—</td></tr> <tr> <td>MEMOBUS</td><td>√</td><td>—</td><td>√</td></tr> <tr> <td>MELSEC</td><td>√</td><td>√</td><td>—</td></tr> <tr> <td>MODBUS/TCP</td><td>—</td><td>√</td><td>—</td></tr> </tbody> </table> √ : Available —: Not available	Protocol Type	Code			ASCII	BIN	RTU	Extended MEMOBUS	√	√	—	MEMOBUS	√	—	√	MELSEC	√	√	—	MODBUS/TCP	—	√	—	ASCII
Protocol Type	Code																									
	ASCII	BIN	RTU																							
Extended MEMOBUS	√	√	—																							
MEMOBUS	√	—	√																							
MELSEC	√	√	—																							
MODBUS/TCP	—	√	—																							
Node Name	Up to 32 single-byte characters (16 double-byte characters)	Any text can be entered as a connection comment.	Blank																							
Input Disable	Enable/disable	Select whether to update the input data in the I/O message communication.	enable																							
Output Disable	Enable/disable	Select whether to update the output data in the I/O message communication.	enable																							
MP2400 Head Register Number Data Size	IW0000 to IW7FFF	Set a start address of the input register of the MP2400 side for storing the data read from the remote equipment. Note1: “xxxx” represents a start I/O register number specified by the 218IFA cell in the detailed field of the Module Configuration Definition Window.	IW xxxx (Note1)																							
	OW0000 to OW7FFF	Set a start address of the MP2400 side output register for referencing the data written in the remote equipment. Note2: “xxxx” represents a start I/O register number specified by the 218IFA cell in the detailed field of the Module Configuration Definition Window.	OWxxxx + 4 (Note2)																							
Data Size	Varies according to protocol type	Specify the data size (word) read from the remote equipment.	4																							
		Specify the data size (word) written in the remote equipment.	4																							
Head Register Number for the Node Equipment	Varies according to protocol type	Specify the register type and the start register address for the remote equipment to read.	Varies according to protocol type.																							
		Specify the register type and the start register address for the remote equipment to write.																								
Data Size of the Node Equipment	Display only	Generally, the same value specified in MP2400 data size is shown. By way of exception, when MELSEC is selected for communication protocol type and a bit device such as input relay (X)/ output relay (Y)/ internal relay (M)/ link relay (B) is selected for read register, the display is shown in bit size.	4																							
		Generally, the same value specified in MP2400 data size is shown. By way of exception, when MELSEC is selected for communication protocol type and a bit device such as input relay (X)/ output relay (Y)/ internal relay (M)/ link relay (B) is selected for read register, the display is shown in bit size.	4																							

■ Easy Setting Window for I/O Message Communication

Graphically adjusts the setting for the read/write connection parameters.

Generally, the contents are similar to I/O message communication items in connection parameter setting.

When the connection parameters are not yet set and this dialog box is opened, the default values for read/write connection will be automatically stored.



The following table provides the default values for each connection stored when the connection parameters are not yet set and this screen is opened.

Item			Default
MP Series	Local IP Address		Values set in transmission parameter setting items are shown.
	Local Port	Read	10005
		Write	10006
	Input Register (IW xxxx)		Start I/O register number specified by the 218IFA cell in the detailed field of the Module Configuration Definition Window.
	Input Disable		Not checked (enable)
	Output Register (OW xxxx)		Start I/O register number specified by the 218IFA cell in the detailed field of the Module Configuration Definition Window + 4.
	Data Update Timing		Low
Other Device	Node IP Address		192.168.1.2
	Node Port Number	Read	10005
		Write	10006
	Read Register		MW00000
	Write Register		MW00004
Communication Protocol Type			Extended MEMOBUS
Read Size			4
Write Size			4
Connect Type			TCP
Code			BIN

In addition, click the **Default** Button to set the default values for data code type, local I/O register setting, read/write size, and node read/write register setting according to the selected communication protocol type.

The following table provides these default values.

Communication Protocol Type	Default			
	Data Code Type	Local Input/Output Register Setting	Read/Write Size	Node Read/Write Register Setting
Extended MEMOBUS	BIN	IW□□□□ to IW□□□□+3 (input) OW□□□□+4 to OW□□□□+7 (output)	4 (read) 4 (write)	MW0000 to MW0003 (read) MW0004 to MW0007 (write)
MEMOBUS	RTU	Same as above	Same as above	Same as above
MELSEC	BIN	Same as above	Same as above	D0000 to D0003 (read) D0004 to D0007 (write)
MODBUS/TCP	BIN	Same as above	Same as above	4X00001 to 4X00004 (read) 4X00005 to 4X00008 (write)

2. Status tab

In the **Status** Tab, each setting for 218IFA detail definitions and transmission status is shown.
The displayed contents are as follows:

■ Transmission Parameter Item

Item	Displayed Content	Default
Station IP Address	Displays local IP address specified in the Transmission Parameters Tab.	000.000.000.000
Equipment Name	Displays equipment name specified in the Transmission Parameters Tab. When the equipment name is not yet set, nothing is shown.	NULL
Transmission Speed	Displays transmission rate retrieved from the status information. (Fixed at Automatic)	Automatic
Subnet Mask	Displays a subnet mask set in the Transmission Parameters Tab.	000.000.000.000
Gateway IP	Displays a default gateway IP address set in the Transmission Parameters Tab.	000.000.000.000
Engineering Port	Displays a port number set in the detailed definition of the Transmission Parameters Tab.	9999

■ Message Communication and I/O Message Communication Items

Item	Displayed Content	Default
Trans Status	Displays the transmission status for each connection.	—
Error Status	If an error is indicated in the transmission status, the error details are shown.	—
Send Count	Displays the number of packets transmitted to the remote station.	—
Receive Count	Displays the number of packets received from the remote station.	—
Error Count	Displays the number of errors that occurred in each connection.	—
Response Time (ms)	Displays the time taken to receive a response after issuing a command in the I/O message communication.	—
Connection	Displays the connection type set in the Transmission Parameters Tab.	—
Protocol Type	Displays the protocol of the connection parameter set in the Transmission Parameters Tab.	—
Code	Displays the code type of the data set in the Transmission Parameters Tab.	—
Node Name	Displays the remote station name set in the Transmission Parameters Tab.	—

Note: 1. Transmission status

In online mode, displays the transmission status for each connection.

Transmission Status	State
IDLE	IDLE
WAIT	WAIT (waiting for connection)
CONNECT	CONNECT (capable of transmitting and receiving data)
—	Unused connection

2. Error status

If an error is indicated in the transmission status, the error details are shown.

Error Status	State	Remarks
No Error	Normal	—
Socket Generation Error	System error	Socket generation failed
Local Port Number Error	Error in setting the local port number (the same address is bound while disconnecting the TCP connection)	Bind error (duplicated port number)
		A bind error occurred while ending the connection.
		Before the connection was completed, another function issued a command to the same remote station.
Socket Attribute Change Error	System error (in TCP)	An error occurred while setting a socket attribute.
Connection Error (I/O Message Communication)	Connection error (when actively open in TCP, a connection is rejected by the node station)	Tried to connect using the I/O message communication, but the connection was rejected by the remote station, and the command was reset.
		When disconnecting the cable, retried connecting for one minute (default value) without a response.
Connection Error (Automatic receive)	Connection error (when passively open in TCP)	An error occurred while receiving the connection from automatic receive.
System Error	System error	A socket polling (select specification) error occurred while receiving data.
Data Transmit Error (TCP)	Data transmit error (in TCP, either there is no node station or a node station did not startup.)	A response transmit error occurred in automatic receive. An error also occurred in I/O message communication. An error occurred only in TCP when there was no node station to transmit or a node station was rebooted.
Data Transmit Error (UDP)	Data transmit error (in UDP)	A transmit request was issued to a nonexistent socket.
Data Receive Error (TCP)	Data receive error (in TCP, a request to disconnect the connection is received from the node station)	An error occurred when disconnecting the connection from the node station. It also may occur even when close is processed properly.
Data Receive Error (UDP)	Data receive error (in UDP)	A data receive command was issued to a nonexistent socket.
Socket Option Change Error	System error	Error when changing a socket option
Data Change Error	Data change error	Protocol change error


2.2.5 Built-in SVB Module

(1) Overview

[a] About SVB Module

The SVB Module is a motion module used to control SERVOPACKs, stepping motor drivers, inverters, distributed I/O devices, etc. via MECHATROLINK interface MECHATROLINK-I or -II.

The MECHATROLINK-II enables position, speed, torque, and phase control for highly accurate synchronized control. In addition, sophisticated machine operations can be performed by switching the control mode while the axis is moving.



[b] Built-in SVB and Slot-mounting Optional SVB

The SVB Modules are of two types: The built-in SVB (hereinafter referred to as Built-in SVB) and the Slot-mounting Optional SVB (hereinafter referred to as Optional SVB)

A built-in SVB Module is incorporated in the MP2400.


The Optional SVB is one of the optional modules for the Machine Controller. The SVB-01 Module is an Optional SVB that can be mounted on the optional slot of the MP2400.

[c] Features

- Up to 21 slave stations can be connected to a single Module (the SERVOPACKs can be connected up to 16 axes).
- Self-configuration enables automatic allocation of setting data for the slave device that is connected to MECHATROLINK.
- SERVOPACK parameters can be managed over networks.

[d] System Configuration Example

The following diagram shows a system configuration example.



- Use the specified cables and connectors. Refer to 1.1.5 (3) *Cables* in the *Machine Controller MP2000-series SVB/ SVB-01 Motion Module User's Manual* (manual number: SIEP C880700 33) to select appropriate cables and connectors to connect each device.
- The SERVOPACK models that can be connected through MECHATROLINK-I differ from those connected through MECHATROLINK-II. Refer to 1.4 *Devices Connectable to MECHATROLINK* on page 1-6 to select appropriate SERVOPACK models for the MECHATROLINK interface to be used.
- If both MECHATROLINK-I (4 Mbps) compatible devices and MECHATROLINK-II (10 Mbps) compatible devices are connected in a system, make the settings in accordance with MECHATROLINK-I specifications.
- When connecting a servo to an SVB Module via MECHATROLINK, connect signals such as overtravel, zero-point return deceleration limit switch, and external latch to the servo. Refer to the relevant SERVOPACK manual for details on the connections.

(2) Specifications

The specifications of built-in and optional SVB Modules are as follows.

[a] Motion Control Function

Item		Details	
MECHATROLINK Communication	Number of Communication Lines	One line	
	Number of Communication Ports (Connectors)	1 port	
	Terminating Resistor	Built-in terminator	
	Transmission Distance	MECHATROLINK-II Min. distance between stations: 0.5 m Total network length: 50 m (can be extended to 100 m by connecting repeaters) MECHATROLINK-I Min. distance between stations: 0.3 m Total network length: 50 m (can be extended to 100 m by connecting repeaters)	
	Master Functions	Communication Interface	MECHATROLINK-II (2:N synchronous) MECHATROLINK-I (1:N synchronous)
		Baud Rate	10 Mbps 4 Mbps
		Transmission Cycle	0.5 ms, 1 ms, 1.5 ms, or 2 ms 2 ms
		Number of Link Communication Bytes	17 bytes or 32 bytes 17 bytes
		Number of Connectable Stations	Up to 21 stations (SERVOPACK for up to 16 axes) Up to 14 stations
		C1 Messaging (Master Function)	Provided (selectable). Not provided.
		C2 Messaging (Allocations)	Provided (selectable). Not provided.
		Retry Function	Provided (selectable). Not provided.
		Supported Slave Devices	For details, refer to <i>1.4 Devices Connectable to MECHATROLINK</i> on page 1-6.
	Slave Functions*	Communication Interface	MECHATROLINK-II
		Baud Rate	10 Mbps
		Transmission Cycle	The transmission cycle of the master station (0.5 ms min.)
		Number of Link Communication Bytes	17 bytes or 32 bytes
		Messaging (Slave Function)	Supported.

* Only with MECHATROLINK-II

(cont'd)

Item		Details
Servo Control	Communication Method	Single-send (communication cycle = transmission cycle) synchronous communication Transmission/communication error detection (hardware) provided. Synchronous communication error detection (software) provided. Automatic recovery function not provided (recovery when alarm is cleared).
	I/O Registers	Input/output using motion registers (synchronized on high-speed scan)
	Command Mode	Motion Command Mode/MECHATROLINK Transparent Command Mode
	Supported Servomotors	Standard motors, linear motors, and direct-drive motors
	Control Type	Position control, speed control, torque control, and phase control
	Motion Commands	Positioning, External Positioning, Zero Point Return, Interpolation, Interpolation with Position Detection, JOG operation, STEP operation, Speed Reference *, Torque Reference *, Phase Control *, etc.
	Acceleration/Deceleration Method	One-step asymmetric trapezoidal acceleration/deceleration, exponential acceleration/deceleration filter, moving average filter
	Position Unit	pulse, mm, inch, degree, μm
	Speed Unit	Reference units/s, 10^n reference units/min, percentage of rated speed
	Acceleration Unit	Reference units/s ² , ms (acceleration from 0 until rated speed reached)
	Torque Unit	Percentage of rated torque
	Electronic Gear	Provided.
	Position Control Method	Finite length position control, infinite length position control, absolute system infinite length position control, and simple absolute system infinite length position control
	Software Limit	Positive/negative direction for each point
	Zero Point Return Method	13 types
	SERVOPACK Parameter Management	Parameters can be managed in the MPE720's SERVOPACK Parameter Window.
Inverter Control	Communication Method	Single-send (communication cycle = transmission cycle) asynchronous communication Transmission/communication error detection (hardware) provided. Synchronous communication error detection (software) not provided. Automatic recovery function not provided (recovery when alarm cleared).
	I/O Registers	Input/output using motion registers (synchronized on high-speed scan)
	Command Mode	Motion Command Mode/MECHATROLINK Transparent Command Mode
	Control Type	Speed control only (V/F, vector control and other control methods use inverter settings.)
	Motion Commands	Inverter I/O control, etc.
	Speed Unit	The speed unit depends on the inverter settings.
I/O Control	Communication Method	Single-send (communication cycle = transmission cycle) asynchronous communication Transmission/communication error detection (hardware) provided. Synchronous communication error detection not provided. Automatic recovery function provided.
	I/O Registers	Input/output using I/O registers and synchronized on the high-speed scan or low-speed scan (selectable).
Self-configuration Function		Module and slave devices can be automatically allocated.

* Only with MECHATROLINK-II

[b] MECHATROLINK Communication Specifications

Item	MECHATROLINK-I	MECHATROLINK-II
Topology	Bus	Bus
Transmission Media	Twisted-pair cable	Twisted-pair cable
Transmission Distance	50 m max. (can be extended to 100 m by connecting repeaters)	50 m max. (can be extended to 100 m by connecting repeaters)
Minimum Distance between Stations	0.3 m	0.5 m
Baud Rate	4 Mbps	10 Mbps
Communication Cycle	2 ms	0.5 ms, 1 ms, 1.5 ms, or 2 ms
Number of Connectable Stations	Up to 14 stations	Up to 21 stations * (SERVOPACK for up to 16 axes)
Communication Control Method	Cyclic	Cyclic
Media Access Control Method	1:N	2:N
Communication Mode	Control communication	Control communication
Error Control	CRC check	CRC check

* Up to 16 stations can be connected if a JEPMC-REP2000 MECHATROLINK-II Repeater is not used. Refer to *Chapter 8 MECHATROLINK-II Repeater* of the *Machine Controller MP900/MP2000 Series User's Manual MECHATROLINK System* (manual number: SIEZ-887-5.1) for details.

[c] Maximum Number of Slave Stations

The maximum numbers of slave stations that can be connected to the SVB-01 Module are listed below.

■ MECHATROLINK Communication Setting and Maximum No. of Slave Stations

MECHATROLINK Communication Setting			Maximum Number of Slave Stations
Communication Method	Baud Rate	Communication Cycle	
MECHATROLINK-I	4 Mbps	2 ms	14
MECHATROLINK-II (17-byte Mode)	10 Mbps	0.5 ms	6
		1 ms	15
MECHATROLINK-II (32-byte Mode)	10 Mbps	0.5 ms	4
		1 ms	9
		1.5 ms	15
		2 ms	21 (SERVOPACK for up to 16 axes)

• Refer to 8.8.6 MECHATROLINK Definitions of *Machine Controller MP900/MP2000 Series MPE720 Software for Programming Device User's Manual* (manual number: SIEP C880700 05) for information on the settings for MECHATROLINK transmission.

■ Transmission Distance and Maximum No. of Slave Stations

Communication Method	Transmission Distance (Total Network Length)	Maximum Number of Slave Stations
MECHATROLINK-I	50 m (can be extended to 100 m by connecting repeaters)	14
MECHATROLINK-II	30 m (can be extended to 100 m by connecting repeaters)	16 (21)*
	50 m (can be extended to 100 m by connecting repeaters)	15 (21)*


* The values in parentheses apply when a JEPMC-REP2000 Repeater is used.

JEPMC-REP2000 Repeater must be used if 17 or more slave stations are connected when using MECHATROLINK-II communication.

(3) Module Configuration Definitions

[a] Module Configuration Definition Window

Start the MPE720. On the **My Tool** view, click **Module Configuration** to display the Module Configuration Definition Window. The content for the No. 3 cell is the MECHATROLINK detailed definition for the built-in SVB Module.



The following table lists the items shown in the Module Configuration Definition Window.


No.	Items		Display/Setting Item	Change
①	Module Type		Displays the module that is set for the slot.	√
②	Function Module/Slave		Displays the function modules and slaves that are used by the module. Changing the name to UNDEFINED enables you to disable 218IFA functions. Changing the name to UNDEFINED enables you to disable 218IFA functions.	√
③	Status		In Online Mode, displays the status of the function modules and the communications status of MECHATROLINK slave devices.	—
④	Circuit No./Address	Start	Displays the first circuit number that is assigned to the function module.	√
		Occupied circuits	Displays the number of circuits that are assigned to the function module.	√
⑤	Motion Register		Displays the range of registers that can be used as motion parameters. The parameter is automatically set based on the circuit numbers.	—
⑥	Register (Input/Output)	Disabled	Used to disable inputs or outputs by selecting the check boxes.	√
⑦		Start - End	Displays I/O start to end register of the I/O Module to be connected to MECHATROLINK. (Setting range: 0000 to 7FFF hex, max. 400 hex words per SVB Module)	√
⑧		Size	Displays the number of words in the I/O area.	√
⑨		Scan	Displays the scan in which the I/O service is performed for the I/O device.	√
⑩	Comment		Displays the user comment. <Setting Conditions> Function module: 16 characters maximum. MECHATROLINK slave: 32 characters maximum.	√

- “√” in the Change line in the above table means that it is possible to change the setting of the item. Always save the setting to the flash memory after having changed the setting.
 - ♦ When changing the setting, be careful not to set the register numbers overlapped with another module.
 - ♦ I/O Start Register and I/O End Register must be set even though the I/O Module is connected or not connected to MECHATROLINK.

(4) MECHATROLINK Detail Definition

[a] How to Open the MECHATROLINK Detail Definition Window

The MECHATROLINK Detail Definition Window is displayed by double-clicking the **SVB** cell in the Module Configuration Definition Window.



[b] MECHATROLINK Detail Definition Window Details



The MECHATROLINK Detail Definition Window has three tabs: **Transmission Parameters**, **I/O Map**, and **Status**. Click the tab to view each.

1. Transmission Parameters Tab

The parameters required to use the MECHATROLINK transmission system are displayed.

<Communication Method in MECHATROLINK-II>

<Communication Method in MECHATROLINK-I>



The items shown on the **Transmission Parameters** Tab are described in the following table. For items whose input fields are available, the settings can be changed. Always save the settings to the flash memory after changing them.

Item	Display during Self-configuration	Options and Precautions on Settings
Communication Type	Displays the detected communication method.	Select MECHATROLINK-II (32 Byte Mode) , MECHATROLINK-II (17 Byte Mode) , or MECHATROLINK-I .
Master/Slave	Displays whether the selected SVB Module is used as a Master station or Slave station.	Select either Master or Slave .
My station address (Local station address)	Displays the local station address set by using the rotary switches.	For Master station, fixed to 0. For slave stations, set a number between 1 and the number of slave stations.
Transmission Speed	Displays the transmission speed: MECHATROLINK-II (32-byte mode): 10 Mbps MECHATROLINK-II (17-byte mode): 10 Mbps MECHATROLINK-I: 4 Mbps	Cannot be set.
Transmission Byte ^{*1}	Displays the number of transmission bytes. The number of transmission bytes depends on the communication type and the station type, Master or Slave. Refer to ■ <i>Transmission Bytes, Communication Cycle, Number of Retries to Slaves, Number of Slaves</i> for details.	Cannot be set.
Communication Cycle	Displays the communication cycle. The number of transmission bytes depends on the communication type and the station type, Master or Slave. Refer to ■ <i>Transmission Bytes, Communication Cycle, Number of Retries to Slaves, Number of Slaves</i> for details.	Can be set only for the Master station and when MECHATROLINK-II is selected as the communication type. The value that can be set differs depending on whether the SVB Module is a built-in SVB Module or optional SVB Module. Refer to ■ <i>Communication Cycle That Can be Set</i> for details.
Message Confidence Level ^{*2}	Not used for MECHATROLINK transmission.	Set to 0 (default).
SigmaWin ^{*1}	For MECHATROLINK-II communications, displays whether or not to use SigmaWin+ for communication via MECHATROLINK-II adapter such as JUSP-NP115.	Select either use or not use .

(cont'd)

Item	Display during Self-configuration	Options and Precautions on Settings
Number of Retry to Slaves *1	Displays the maximum number of slave stations to which the Master can retry transmission in one transmission cycle when the Master has not received a normal response from a slave.	Only for Master station. Set a number between 0 and 7. Cannot set for Slaves.
Number of Slaves	Displays the number of slave stations that can be connected. The number of slave stations that can be connected is determined by communication type, communication cycle, SigmaWin+ use/not use, and number of retry to slaves.	Cannot be set.
Slave synchronous function *1	When using a built-in SVB module as a slave station, select whether to synchronize with a master station.	Cannot be set.

* 1. Hidden for MECHATROLINK-I.

* 2. Hidden for MECHATROLINK-II.

■ Transmission Bytes, Communication Cycle, Number of Retries to Slaves, Number of Slaves

Transmission bytes, communication cycle, number of retries to slaves, and number of slaves at execution of self-configuration will be automatically set according to conditions including communication type, station type (Master or Slave), and the largest slave station number (the largest number among the detected slave station numbers).

<For Master Station>

Item	MECHATROLINK-II (32-byte mode)				MECHATROLINK-II (17-byte mode)		MECHATROLINK-I
Largest Slave Station Number	1 to 8	9	10 to 16	17 to 21	1 to 14	15	
Transmission Byte	31 bytes				16 bytes		—
Communication Cycle	1 ms	1 ms	2 ms	2 ms	1 ms	1 ms	2 ms
Number of Retry to Slaves	1	0	5	21 (The largest slave station number)	1	0	14
Number of Slaves	8	9	16	The largest slave station number	14	15	14

<For Slave Stations>

Item	MECHATROLINK-II (32-byte mode)	MECHATROLINK-II (17-byte mode)	MECHATROLINK-I
Transmission Byte	—	—	—
Communication Cycle	1 ms	1 ms	2 ms
Number of Retry to Slaves	30	30	15
Number of Slaves	30	30	15

■ Communication Cycle That Can be Set

The communication cycle that can be set will differ depending on the communication type as follows.

MECHATROLINK-II Communication Mode	32-byte mode	17-byte mode
Communication Cycle That Can be Set	0.5 ms, 1 ms, 1.5 ms, or 2 ms	0.5 ms or 1 ms

- Communication Cycle can only be set for Master.
- The communication cycle for MECHATROLINK-I is fixed to 2 ms.

2. Link Assignment

The data of the slave devices (MECHATROLINK connected devices such as SERVOPACK, inverter, and distributed I/O) are displayed on the **Link Assignment**.

Module	Function Module/Slave	Status	Circuit No./Axis Address		Motion Register	Disabled	Register(Input/Output)			Comment
			Start	Occupied circuits			Start - End	Size	Scan	
01 CPU	Driving									
02 2109FA	Driving		Circuit No.1	1		☐ Input ☐ Output	0000 - 07FF[H]	2048		
03 SVB	Driving		Circuit No.1	1	8000 - 87FF[H]	☐ Input ☐ Output	8000 - 8FFF[H]	1024		
04 S0D7S-****I/O	No Alarm	01			8000 - 87FF[H]	☐ Input ☐ Output			High	
05 S0D7S-****I/O	No Alarm	02			8000 - 87FF[H]	☐ Input ☐ Output			High	
06 MP2400[Driving]	Driving									
07 SVB	Driving		Circuit No.2	1	8000 - 87FF[H]	☐ Input ☐ Output				
08 M-DECUTOR	Driving						0C00 - 0C3FD[H]	64		

The items shown on the **Link Assignment** are as follows. You can change the settings or delete the data station by station on this tab. Always save the settings to the flash memory after changing them.

Item		Display/Setting Item	Change
Module Type		Displays the module that is set for the slot.	√
Function Module/Slave		Displays the function modules and slaves that are used by the module.	√
Status		In Online Mode, displays the status of the function modules and the communications status of MECHATROLINK slave devices.	—
Circuit No./Address	Start	Displays the first circuit number that is assigned to the function module.	√
	Occupied circuits	Displays the number of circuits that are assigned to the function module.	√
Motion Register		Displays the range of registers that can be used as motion parameters.	—
Register (Input/Output)	Disabled	Used to disable inputs or outputs by selecting the check boxes.  Disabled	√
	Start - End	Displays the start to end register of the I/O register used in the I/O message communication.	√
	Size	Displays the number of words in the I/O area.	√
	Scan	When the I/O signal is processed is displayed. High: High-speed scan Low: Low-speed scan	√
Comment		Displays the user comment. <Setting Conditions> Function module: 16 characters maximum. MECHATROLINK slave: 32 characters maximum.	√

■ Deleting a Station Assignment

Right-click the cell of the slave device to delete and select **Delete**.

- ♦ Care must be taken when deleting a station assignment. The deletion is irreversible.


■ Wild Card I/O (****I/O) and Wild Card Servo

If the module cannot be automatically detected with self-configuration, “Wild Card I/O (****I/O)” or “Wild Card Servo” will be displayed in the Function **Module/Slave** column.

3. I/O Map Tab


The status allocated to I/O registers is displayed.

- The **I/O Map** Tab is used for monitoring (read-only). Do not change the displayed settings.



[c] Status Tab Page

The MECHATROLINK transmission status is displayed. The displayed settings cannot be changed.




■ STS

In online mode MECHATROLINK transmission status information is displayed in hexadecimal.

- In offline mode, nothing will be displayed.

The meaning of each bit is shown below.




(5) Motion Parameters

The motion parameters are parameters that control motion axes (e.g., SERVOPACKs, inverters, and steppers), and "motion parameter" is used as the general term for fixed parameters, setting parameters, and monitor parameters.
Note: For information on motion parameters, refer to *Machine Controller MP2000-series Built-in SVB/SVB-01 Motion Module User's Manual* (Manual no.: SIEPC88070033)

[a] Opening the Motion Parameters

Open the Motion Parameters Window by the following procedure.

- 1. Select **View - Work Space** from the main menu. Select the check boxes for the axes to set or monitor and double-click the motion parameters.



■ Information

To add or change the axes to display, you can also select the axes from **Display in axis selected** on the **Fixed Parameter** Tab Page.

- Click the **Fixed Parameter**, **Setting Parameter**, or **Monitor Parameter** Tab to display the desired page.

- Fixed Parameter Tab

	Axis0101 Circuit#01 Axis#01 SGD7S-****10*	Axis0102 Circuit#01 Axis#02 SGD7S-****10* (Linear)
0 : Selection of operation modes	0 : Normal operation mode	0 : Normal operation mode
1 : Function selection flag 1	0000[H]	0000[H]
2 : Function selection flag 2	0000[H]	0000[H]
4 : Reference unit selection	0 : pulse	0 : pulse
5 : Number of digits below decimal point	3 : 0.123	3 : 0.123
6 : Travel distance per machine rotation	10000[pulse]	10000[um or nm]
8 : Servo motor gear ratio	1[rev]	1[rev]
9 : Machine gear ratio	1[rev]	1[rev]
10 : Infinite length axis reset position(P...	360000[pulse]	360000[pulse]
12 : Positive software limit value	2147483647[pulse]	2147483647[pulse]
14 : Negative software limit value	-2147483648[pulse]	-2147483648[pulse]

- Setting/Monitor parameter Tab

The setting parameters and monitor parameters are displayed on the same tab page. Switch between the parameters with the tabs at the bottom of the table.

<Setting Parameter>


	Address	Axis0101 Circuit#01 Axis#01 SGD7S-****10*	Axis0102 Circuit#01 Axis#02 SGD7S-****10* (Linear)
0 : Run command setting	0W8000	0000[H]	0000[H]
1 : Mode setting 1	0W8001	0000[H]	0000[H]
2 : Mode setting 2	0W8002	0000[H]	0000[H]
3 : Function setting 1	0W8003	0011[H]	0011[H]
4 : Function setting 2	0W8004	0033[H]	0033[H]
5 : Function setting 3	0W8005	0000[H]	0000[H]
6 : Option Setting	0W8006	0000[H]	0000[H]
8 : Motion command	0W8008	0 : No Command	0 : No Command
9 : Motion command control flag	0W8009	0000[H]	0000[H]
10 : Motion subcommand	0W800A	0 : No Command	0 : No Command
12 : Torque/Thrust reference setting	0L800C	0[0.01%]	0[0.01%]
14 : Speed limit setting at the torque/thr...	0W800E	15000[0.01%]	15000[0.01%]
16 : Speed reference setting	0L8010	3000[1000pulse/min]	3000[1000pulse/min]
20 : Positive side limiting torque/thrust...	0L8014	30000[0.01%]	30000[0.01%]
22 : Secondly Speed Compensation	0L8016	0[1000pulse/min]	0[1000pulse/min]
24 : Override	0W8018	10000[0.01%]	10000[0.01%]
26 : Position reference setting	0L801C	0[pulse]	0[pulse]

<Monitor Parameter>

	Address	Axis0101 Circuit#01 Axis#01 SGD7S-****10*	Axis0102 Circuit#01 Axis#02 SGD7S-****10* (Linear)
0 : Run status	IW8000	-	-
1 : Parameter number when range over r...	IW8001	-	-
2 : Warning	IL8002	-	-
4 : Alarm	IL8004	-	-
8 : Motion command response code	IW8008	-	-
9 : Motion command status	IW8009	-	-
10 : Subcommand response code	IW800A	-	-
11 : Subcommand status	IW800B	-	-
12 : Position management status	IW800C	-	-
14 : Target position in machine coordin...	IL800E	-	-
16 : Calculated position in machine coor...	IL8010	-	-
18 : Machine coordinate system referen...	IL8012	-	-
20 : CPOS for 32 bit	IL8014	-	-
22 : Machine coordinate system feedbac...	IL8016	-	-
24 : Machine coordinate system latch p...	IL8018	-	-
26 : Position error (PERR)	IL801A	-	-
30 : Number of POSMAX turns	IL801E	-	-

- SERVOPACK Parameters Window

To display SERVOPACK parameters, click a servo parameter or servo monitor in the work space and SigmaWin+ will be started using the linking function.



Note: Refer to the relevant SERVOPACK user's manual for information on SERVOPACK parameters.

(6) Precautions when Saving the Servo User Constant

When saving parameters on the Servo Parameters Window in cases other than when the SERVOPACK is changed, always make sure to perform the following operation first.

1. In the **Display Settings** area of SigmaWin+, set **Controller Value** to **ON**.
2. Select the **Controller** tab, and click **Write Servo Values to Controller**.

2.2.6 SVR Virtual Motion Module

(1) Outline


The Virtual Motion Module is a software module provided as a standard feature with the MP2400. It is not connected to a motor, but provides a virtual axis interface.

The SVR is configured in the same way as the MP2400 built-in SVB with fixed parameters, setting parameters, and monitoring parameters, and can be accessed from application programs using I/O registers.

The SVR can be used to control up to 16 virtual axes in the high-speed scan control cycle.


Note: For information on how to use SVR motion parameters and motion commands, refer to *Machine Controller MP2000-series SVB/SVB-01 Motion Module User's Manual* (manual number: SIEP C880700 33).

In the MP2400 Basic Module, slot 4 in the default Module Configuration Definition Window is for SVR.



Module	Function Module/Slave	Status	Circuit No./AxisAddress		Motion Register	Disabled
			Start	Occupied circuits		
01 [MP2400] : ---						
00 MP2400[-----]	01 CPU	----				
	02 218IFA	----	⏏ Circuit No1	1		☐ Input ☐ OutPut
	03 SVB	----	⏏ Circuit No1	1	8000 ~ 87FF[H]	☐ Input ☐ OutPut
	04 SVR	----	⏏ Circuit No2	1	8800 ~ 8FFF[H]	
05	M-EXECUTOR	----				

Note: If the SVR is not used, the MP2400 processing time can be reduced by deleting **SVR** in the Module Configuration Definition Window.



Module	Function Module/Slave	Status	Circuit No.
			Start
01 [MP2400] : ---			
00 MP2400[-----]	01 CPU	----	
	02 218IFA	----	⏏ Circuit No1
	03 SVB	----	⏏ Circuit No1
	04 -- UNDEFINED --	----	
05	M-EXECUTOR	----	

(2) Example SVR Usage

The SVR is used in the following two applications.

- **Program testing:** Results are easily obtained without mounting a motor.
- **Generating commands:** If the SVR is used in applications where motion modules are required only for generating commands, such as master axis for phase control or multi-axis synchronous control, then Motion Modules on real axes are no longer required.


The following table lists application examples of the SVR.

Slot Number	Application Example	Application Method
1	Master axis for phase control	Electronic cam or shaft operation can be achieved by using the SVR for the virtual master axis.
2	Multi-axis synchronous control	Multi-axis synchronous control can be achieved by controlling the SVR from a motion program and then using the ladder program to copy position commands of the SVR to other axes.
3	Sine curve commands	If the motion program is used to perform circular interpolation with the SVR, the axis will operate with a sine curve command.

- The software limit function and machine lock function cannot be used with the SVR. The position error will always be 0.

(3) System Configuration Example


The following figure shows an example system configuration using SVR.



(4) SVR Operation

[a] SVR Execution Timing

The SVR is processed at the beginning of the high-speed scan. SVR processing is performed in the next scan after specifying and the processing results are reflected in the monitoring parameters.



[b] Processing Time

When fixed parameter 0 (Selection of Operation Modes) is set to 0 (Normal Operation Mode), services are started for each of the 16 SVR Module virtual axes.

- The default for the Selection of Operation Modes parameter is 1 (Axis Unused).

The following table gives guidelines for the processing time required for each SVR axis.

Command	MP2400
NOP	$35 + 14 \times \text{Number of axes} (\mu\text{s})$
POSING	$35 + 36 \times \text{Number of axes} (\mu\text{s})$

- Number of axes: The number of axes (1 to 16) when Selection of Operation Modes (fixed parameter 0) is set to Normal Operation Mode (0). The formula listed above do not apply when the number of axes is 0.

■ Differences from SVB Simulation Mode

Simulation mode does not have a positioning function, so the position data is refreshed in one scan to the final target position. The SVR has its own positioning function that performs distribution, so like a real module, position data is refreshed each scan for the final target position.

2.2.7 M-EXECUTOR Module (Motion Program Executor)

This section explains the M-EXECUTOR Module (motion program executor) function and its detail screen.

(1) M-EXECUTOR Module Function Overview

The M-EXECUTOR Module is a software module that executes a motion or sequence program.

The M-EXECUTOR Module enables the following features:

■ Executing a motion program without using a ladder program

Conventionally, in order to execute a motion program, you need to incorporate an MSEE command into a ladder program. The M-EXECUTOR Module allows you to execute the motion program without incorporating the MSEE command into the ladder program.

■ Controlling a motion program without using a ladder program

You can map any register to the control signal of the motion program registered in the M-EXECUTOR Module.

So, without a ladder program, this allows you to directly control a motion program from a host PLC or other device.

■ Describing sequence control in motion language

As a new programming method, a sequence program has been added to the MP2400.

A sequence program is a scan execution type program where a process is completed with one scan. It employs a text language similar to a motion program.

You can use the sequence program as an alternative to the ladder program.

For information about commands available in the sequence program, see *Machine Controller MP900/MP2000 Series Users Manual Motion Programming* (manual number: SIE-C887-1.3).

(2) M-EXECUTOR Module Specification

[a] Programs Capable of Registration in M-EXECUTOR

The following table shows programs capable of registration in M-EXECUTOR.

Program Type		Number of Registrations	Remarks
Motion Program		16	Up to 16 programs in total
Sequence Program	Startup	1	
	Interrupt	Disable	
	H Scan	16	
	L Scan	16	

[b] Program Control Method


The following table shows the program control methods registered in M-EXECUTOR.

Item	Motion Program	Sequence Program
Execution Method	Sequential Execution	Startup: Event driven H Scan: Scan execution L Scan: Scan execution
System Work	1:1 correspondence between the definition number and system work (The number of program definitions is set in the MPE720 screen.)	
	Definition No.	System Work Number
	No. 1	1
	No. 2	2
	.	.
	No. 16	16
Program Designation Method	Direct or indirect designation	Direct designation
Program Startup Method	Registered in the definition, turns start signal ON	Starts up when registered in the definition
Override Setting for Interpolation	Yes	No
I/O Link Definition	Yes	No
S Register Report Function of Motion Program Status	Yes	
Number of Parallels	1 to 8 (4 main parallels × 2 sub parallels)	1
Execute an Error Drawing when Operation Error Occurred	Yes	

(3) Module Configuration Definitions

(a) Details of Module Configuration Definition Window

Start the MPE720. On the **My Tool** view, click **Module Configuration** to display the Module Configuration Definition Window. The content for the No. 5 cell is detailed definition for the M-EXECUTOR.



Items displayed in the Module Configuration Definition Window area show the following:

No.	Items		Display/Setting Item	Change
①	Module Type		Displays the module that is set for the slot.	√
②	Function Module/Slave		Displays the function modules and slaves that are used by the module. Changing the name to UNDEFINED enables you to disable M-EXECUTOR functions.	√
③	Status		M-EXECUTOR Module status in online mode.	—
④	Circuit No./Address	Start	Not used. Fixed at “— — — —”.	—
		Occupied circuits	Not used. Fixed at “— — — —”.	—
⑤	Motion Register		Displays the range of registers that can be used as motion parameters. The parameter is automatically set based on the circuit numbers.	—
⑥	Register (Input/Output)	Disabled	Not used. Fixed at “— — — —”.	—
⑦		Start - End	Displays start to end register of the M-EXECUTOR I/O register (Setting range: 0000 to 7FFF hex, Size: 40 hex words)	√
⑧		Size	Displays the number of words in the I/O area.	√
⑨		Scan	Not used. Fixed at “— — — —”.	√
⑩	Comment		Displays the user comment. <Setting Conditions> Function module: 16 characters maximum. MECHATROLINK slave: 32 characters maximum.	√

√ : Available, — : Not available

■ I/O Register Details

An I/O register assigned to M-EXECUTOR is used to run a motion program and sequence program, and to monitor a sequence program.

M-EXECUTOR I/O register details are as follows:

M-EXECUTOR Input Register

M-EXECUTOR Input Register	Item	
Iwxxxx + 0	Definition No.1	Status
Iwxxxx + 1		Spare
Iwxxxx + 2		Spare
Iwxxxx + 3		Spare
Iwxxxx + 4	Definition No.2	Status
Iwxxxx + 5		Spare
Iwxxxx + 6		Spare
Iwxxxx + 7		Spare
	.	
	.	
	.	
Iwxxxx + 3C	Definition No.16	Status
Iwxxxx + 3D		Spare
Iwxxxx + 3E		Spare
Iwxxxx + 3F		Spare

M-EXECUTOR Output Register

M-EXECUTOR Output Register	Item	
Owxxxx + 0	Definition No.1	Program number
Owxxxx + 1		Control signal
Owxxxx + 2		Override
Owxxxx + 3		Spare
Owxxxx + 4	Definition No.2	Program number
Owxxxx + 5		Control signal
Owxxxx + 6		Override
Owxxxx + 7		Spare
	.	
	.	
	.	
Owxxxx + 3C	Definition No.16	Program number
Owxxxx + 3D		Control signal
Owxxxx + 3E		Override
Owxxxx + 3F		Spare

(4) Detailed Screen


This section describes the M-EXECUTOR detail definition screen.

■ Program Definition Screen (M-EXECUTOR (list display) screen)

The program definition screen allows you to register a motion or sequence program to run.

Programs are executed according to the scan, in ascending numeric order.

A white cell can be set by the user, and a grey cell cannot be set by the user.



- ① Individual display
Shows M-EXECUTOR (individual display) screen.
- ② Program definition number
Sets the number of program definitions registered in the M-EXECUTOR Module.
The valid range is 0-16 (8 by default).
- ③ No.
Shows the program execution order. Processed according to the scan in ascending numeric order.
- ④ D
Enables/disables the definition. Uncheck to enable the definition.

⑤ Execution type

Sets the program execution type.

Execution Type	Program to Execute	Execution Condition
-----	None	None (select this to delete the definition)
Sequence Program (startup)	Sequence program	Power-up (during power-up, run only once)
Sequence Program (L scan)		Periodical startup (run each time a low-speed scan is performed)
Sequence Program (H scan)		Periodical startup (run each time a high-speed scan is performed)
Motion Program	Motion program	Turns ON the program operation start request of the control signal (runs when the program operation start request is ON).

⑥ Setting method

Sets the a program designation.

The way to designate a program may differ according to the program.

Designation Method	Motion Program	Sequence Program	Remarks
Direct Designation	Enable	Enable	The way to designate the program number Example: MPM001, SPM002, and so on
Indirect Designation	Enable	Disable	The way to designate the register for storing the program number Example: OW0C0C, and so on (refers to MPM001 by storing one in OW0C0C)

⑦ Program

Sets a program number.


Execution Type	Remarks
Sequence Program (startup, L scan, H scan)	Enter "1" and press ENT to automatically input "SPM001." You can save an unregistered program or exit this screen without setting (blank), but in these cases, the program will not be executed.
Motion Program	Direct designation: Enter "1" and press ENT to automatically input "MPM001." You can save an unregistered program or exit this screen without setting (blank), but in these cases, the program will not be executed. Indirect designation: O register of M-EXECUTOR Module is automatically set. It cannot be set by the user.

⑧ Execution monitor register (S Register)

When the execution type is set to motion program, the range of the execution monitor registers (S registers) is shown. For more information on the execution monitor register, refer to (6) *Monitor the motion program execution information using S register of 5.2.2 Motion Programs.*

■ Control Register Mapping Window

The control register mapping screen sets a mapping register.
A white cell can be set by the user, and a shaded cell cannot be set by the user.



- ① M-EXECUTOR Control register
Displays an I/O register mapped to the M-EXECUTOR Module.
Controls the motion program and monitors the state, using the M-EXECUTOR control register.

M-EXECUTOR Control Register	Usage
Program Number	Sets a program number. This register is used only when set to an indirect designation.
Status	Monitors the program execution status.
Control Signal	Controls the program.
Override	Sets an override value when running a move command for the interpolation system.

Note: For more information on the M-EXECUTOR control register, refer to 2.2.7 (1) M-EXECUTOR Module Function Overview.

- ② Allocation Disable
Enables/disables the mapping register. Uncheck to enable the definition.
- ③ Direction
Displays the data I/O direction.

④ Allocation register

Data is exchanged between mapping and M-EXECUTOR control registers in real-time.
Any register can be mapped to the mapping register.

Registers that can be set as a Mapping Register
Word type I, O, M (except the motion register)

⑤ Allocation Contact interlock

An allocation contact interlock is used to control the data exchange between the allocation register and M-EXECUTOR control registers. When the allocation contact interlock is ON, data can be exchanged between the allocation register and M-EXECUTOR control registers.
Any register bit can be mapped to the allocation contact interlock.

Registers that can be set as an Allocation Contact Interlock
Bit type I, O, S, M, C (except the motion register)

■ Caution

An allocation contact interlock is used to interlock the operation of a motion program.
When setting an allocation register, be sure to set the allocation contact interlock.

⑥ Status, Control Signal Details

Double-click the status and control register to display the bit detail.
You can check the signal sequence and status here.

• Status

Detail			
Program execution registration No.4			
Control signal Status			
	M-Executor Control register	Allocation register	Status
Program is running	IB00C6C0	OB000100	○ : ON ● : OFF
Program is pausing	IB00C6C1	OB000101	○ : ON ● : OFF
Program stopped with program stop re	IB00C6C2	OB000102	○ : ON ● : OFF
Program stopped under single block m	IB00C6C4	OB000104	○ : ON ● : OFF
Program alarm has been generated	IB00C6C8	OB000108	○ : ON ● : OFF
Stopped at break point	IB00C6C9	OB000109	○ : ON ● : OFF
Debugging mode(EWS debugging)	IB00C6CB	OB00010B	○ : ON ● : OFF
Start request signal history	IB00C6CD	OB00010D	● : ON ○ : OFF
"No system work" error	IB00C6CE	OB00010E	○ : ON ● : OFF
Main program number limit error	IB00C6CF	OB00010F	● : ON ○ : OFF


• Control Signal

Detail			
Program execution registration No.4			
Control signal Status			
	M-Executor Control register	Allocation register	Status
Program start request	OB00C6D0	----	○ : ON ● : OFF
Program pause request	OB00C6D1	----	○ : ON ● : OFF
Program stop request	OB00C6D2	----	○ : ON ● : OFF
Program single block mode selection	OB00C6D3	----	○ : ON ● : OFF
Program single block start request	OB00C6D4	----	○ : ON ● : OFF
Alarm reset request	OB00C6D5	----	○ : ON ● : OFF
Program continuous operation start re	OB00C6D6	----	○ : ON ● : OFF
Skip1 information	OB00C6D8	----	○ : ON ● : OFF
Skip2 information	OB00C6D9	----	○ : ON ● : OFF
System work number setting	OB00C6DD	----	○ : ON ● : OFF
Interpolation override setting	OB00C6DE	----	○ : ON ● : OFF

■ Program Execution Registration Screen (M-EXECUTOR (individual display) screen)

Click the **Individual Display** Button in the M-EXECUTOR (list display) dialog box to display this dialog box.


The items that can be set are similar to those in the program definition window and the control register mapping window.



- ① Program execution registry number
Selects a program execution registration No.
- ② Program number
Sets a program number.
- ③ Execution type
Sets the program execution type.
- ④ Specification
Sets the method of designating a program.
- ⑤ Allocation register
Sets a mapping register.
- ⑥ Status, Control signal
Displays the status and the signal sequence of the control register.
- ⑦ Allocation DISABLE
Enables/disables the allocation register. Uncheck to enable the definition.
- ⑧ List
Displays the M-EXECUTOR (list display) screen.
- ⑨ Delete
Deletes a definition.


(5) Execution Scheduling

Programs registered in M-EXECUTOR are executed on the basis of their priorities (execution type).




An execution example is as follows:

- M-EXECUTOR program definition




- Execution scheduling
- The following diagram shows the execution scheduling when set in the screen above.



2.3 External Appearance

The external appearance of the basic module is as follows:

2.3.1 Basic Module




* 1. The following cable-side connectors are attached to the power and relay connectors.

- Power connector: 721-203 / 026-000
- Relay connector: 734-YE102

Note: Attachment

- Handle for power connector (model: 231-131)
- Handle for relay connector (model: 734-230)
- * These handles are used when connecting a cable to the cable-side connector.
- Terminating resistor for MECHATROLINK (JEPMC-W6022-E)

2.3.2 Basic Module with Metal Fittings



Mounting and Wiring

This chapter explains how to handle MP2400 and the connection methods for each module.

- 3.1 Mounting MP2400 ----- 3-2
 - 3.1.1 Method ----- 3-2
 - 3.1.2 MP2400 Mount Direction ----- 3-7
 - 3.1.3 Space Required for Mounting MP2400 ----- 3-8
- 3.2 Basic Module Connections ----- 3-9
 - 3.2.1 Connectors ----- 3-9
 - 3.2.2 Power Supply Connector ----- 3-10
 - 3.2.3 MECHATROLINK Connectors ----- 3-11
 - 3.2.4 Ethernet Connector Details ----- 3-14
 - 3.2.5 RLY OUT Connector Details ----- 3-18
 - 3.2.6 System Connection Example ----- 3-20

3.1 Mounting MP2400

3.1.1 Method

There are two methods for mounting MP2400.


- Using DIN rail (standard)
- Using screws

(1) DIN Rail Mounting


[a] DIN Rails and Spacer

Several types of DIN rails are available: with 7-mm to 15-mm gap from the mounting base as shown in the following diagram. If mounting an MP2400 using DIN rail with 10 mm gap, install a spacer on the rear of the MP2400 near the bottom to protect the MP2400 from vibration and shock.

Gap from mounting base: 7.0 mm to 15.0 mm




For a 10-mm gap




[b] Procedure for Mounting to DIN Rail

Use the following procedure to attach the DIN rail mounting parts to the MP2400 and then mount the MP2400 to the DIN rail.


1. Insert the DIN rails to the dotted line in the two slots on the rear of the MP2400 as shown in the following figure.



- ♦ The following figure shows the front and back of a mounting clip. Insert each clip so that its front faces outward.




2. Pull the DIN rail mounting clips down to release them.




■ Fixing a DIN Rail


Make sure to fix a DIN rail at 300mm or less pitch as shown in the figure below.




3. Hook the MP2400 to the top of the DIN rail (a), and then push the MP2400 towards the mounting base to secure it in place (b).



4. Push the DIN rail mounting clips to lock them in place.



5. Place end plates on both sides of the MP2400 to secure it to the DIN rail.




This completes the installation procedure.


(2) Screwed Method

Use a panel mounting clamp (optional) by the following procedure to mount MP2400 on the panel.

1. Release the DIN fixing lock (one) at the center of the panel mounting clamp.




2. Insert two convex portions at the top of the panel mounting clamp into holes of the MP2400 case.



3. Push the clamp as indicated by an arrow above onto the MP2400 case and use DIN fixing locks to fix MP2400.

4. Push the MP2400 mounted clamp onto the mounting plate as shown in the figure below, and use four mounting screws to firmly secure the clamp.




Note: Vertically mount it on the wall as shown in the figure above.

3.1.2 MP2400 Mount Direction

Be sure to mount the MP2400 using DIN rail or metal fittings.

View from front,
when attached




3.1.3 Space Required for Mounting MP2400

Install MP2400 so that enough space is left around it as shown in the following figure:

■ Mount condition

- Vertical direction: 20 mm or more
- Horizontal direction: no condition


Note: However, ambient temperature should be 55°C or less.



3.2 Basic Module Connections

3.2.1 Connectors

The following diagram shows the connectors for the Basic Module.




3.2.2 Power Supply Connector

(1) Specifications, Pin Arrangement, and Connection Procedure

Supply a 24-VDC to the MP2400. Connect the power supply connector as shown in the diagram below.

Name	Connector Name	No. of Pins	Connector Model		
			Module	Cable	Manufacturer
Power Supply Connector	POWER	3	721-863	721-203/026	WAGO

Symbol	Signal Name	Description
	24 V	24 VDC input
	0 V	0 V input
	FG	Frame ground (Ground to 100 Ω or less.)




- Use an insulated 24-VDC power supply. Attach the power supply switch on the AC side. If the switch is attached on the 24-VDC side, there will be an inrush current of approximately 40 A when the power is turned ON.

(2) Connection Procedure

The power supply terminal has a removable connector. Use the following procedure to wire the terminal to the power supply connector. Use 0.08 mm² to 2.6 mm² (AWG28 to AWG13) twisted-pair cable.

1. Strip approx. 8 to 9 mm the end of the wire.



2. Open the wire insert opening on the terminal with the tool shown in Fig. A or Fig. B.




Fig. A (with lever)




Fig. B (with screwdriver)

3. Insert the wire into the opening and then close the opening by releasing the lever or removing the screwdriver.

3.2.3 MECHATROLINK Connectors

MECHATROLINK connector is used to connect the MP2400 and the SERVOPACKs and distributed I/O via MECHATROLINK cables.

(1) Specifications and Pin Arrangement



Name	Connector Name	No. of Pins	Connector Model		
			Module	Cable	Manufacturer
MECHATROLINK Connector	M-I / II	4	1903814-1	2040305-1	Tyco Electronics Japan G.K.



M-I/II


No.	Signal Name	Description
1	(NC)	Not used.
2	/DATA	Signal -
3	DATA	Signal +
4	SH	Not used.
Shell	Shield	Connecting the shielded wire.

(2) Cables

Name and Specification	Model Number	Length
MECHATROLINK Cable MECHATROLINK Connector – MECHATROLINK Connector 	JEPMC-W6002-A5-E	0.5 m
	JEPMC-W6002-01-E	1 m
	JEPMC-W6002-03-E	3 m
	JEPMC-W6002-05-E	5 m
	JEPMC-W6002-10-E	10 m
	JEPMC-W6002-20-E	20 m
	JEPMC-W6002-30-E	30 m
	JEPMC-W6002-40-E	40 m
	JEPMC-W6002-50-E	50 m
MECHATROLINK Cable MECHATROLINK Connector – MECHATROLINK Connector (with Ferrite Core) 	JEPMC-W6003-A5-E	0.5 m
	JEPMC-W6003-01-E	1 m
	JEPMC-W6003-03-E	3 m
	JEPMC-W6003-05-E	5 m
	JEPMC-W6003-10-E	10 m
	JEPMC-W6003-20-E	20 m
	JEPMC-W6003-30-E	30 m
	JEPMC-W6003-40-E	40 m
Terminator 	JEPMC-W6022-E	–


(3) Cable Connections between the MP2400 and I/O Units or SERVOPACKs

Use the MECHATROLINK cable JEPMC-W6002-□□-E or JEPMC-W6003-□□-E with a ferrite core for connection between the MP2400 and I/O units or SERVOPACKs.



Standard model: JEPMC-W6002-□□-E and JEPMC-W6003-□□-E

(4) Connection Example between MP2400, SERVOPACK, and IO2310



- ♦ Use MECHATROLINK cables between modules.
- ♦ Use under the conditions that $L1 + L2 + L3 + \dots + Ln \leq 50 \text{ m}$

3.2.4 Ethernet Connector Details


Connects to a personal computer or HMI device by Ethernet (100Base-TX /10Base-T).

(1) Ethernet Connector Specification and Pin Arrangement/ Indicator Light

The following table provides the Ethernet connector specifications.

Name	Connector Name	Number of Pins	Connector Model		
			Module Side	Cable Side	Manufacturer
Ethernet	Ethernet	8	RJ-45 CAT5 Socket	RJ-45 CAT5 Plug	Pulse Engineering

The following table provides Ethernet connector pin arrangement/ indicator light details.



Pin Number	Signal Name	Description
1	TXD+	Transmitted data + side
2	TXD-	Transmitted data – side
3	RXD+	Received data + side
4	—	—
5	—	—
6	RXD-	Received data – side
7	—	—
8	—	—

Display Name	Display Color	Description
LINK	Yellow	Lit: Connect Unlit: Unconnected
100M	Green	Lit: Connected at 100Mbps, or automatically negotiating Unlit: Connected at 10Mbps

(2) Ethernet Cable

For the Ethernet cable, use a twisted pair cable with RJ-45 connector.


Ethernet Type	Category	Remarks
10Base-T	Category 3 or more	- When connecting to remote equipment through a hub: Straight cable - When connecting to remote equipment without using a hub: Cross cable
100Base-TX	Category 5 or more	

(3) Ethernet Connection Example

The following are examples of Ethernet network connections via 10Base-T cable:

■ Connection Example 1


When using a repeater HUB:



Specification

Item	When Connecting to a Re-peater HUB	When Connecting to a Switching HUB
Cable Length between Node-HUB	100 m or less	100 m or less
Cable Length between HUBs	100 m or less	100 m or less
Number of HUBs between Nodes	Up to four	Unlimited


■ Connection Example 2



The following are examples of Ethernet network connections via 100Base-Tx cable:

■ Connection Example 3


When using a repeater HUB:



Specification

Item	When Connecting to a Repeater HUB	When Connecting to a Switching HUB
Cable Length between Node-HUB	100 m or less	100 m or less
Cable Length between HUBs	5 m or less	100 m or less
Number of HUBs between Nodes	Up to two	Unlimited


■ Connection Example 4



■ Caution

High frequency wave noise from other devices in the installation environment may cause error in communications using 100 BASE-Tx or MECHATROLINK connections. When constructing a system, use MP2400 protective measures to avoid the influence of high frequency wave noise as follows:

- 1 Wiring
Wire Ethernet or MECHATROLINK cables so that they are well-separated from other cable systems such as the main circuit or power lines.
- 2 Communication system (100BASE-TX)
 - Communicate data to a remote device through TCP/IP communication.
 - If necessary, increase the number of communication retries.
- 3 Attach a ferrite core.
Attach a ferrite core in the manner described below:
 - Ethernet : Attach it to the communication port side and the external equipment side of the MP2400 main unit.
 - MECHATROLINK : Attach it only to the communication port side of the MP2400 main unit.
(We will provide a standard cable with core. Model: JEPMC-W6003-□□-E)



Note: Recommended ferrite core

Model:	Manufacturer
E04SR301334	Seiwa Electric Mfg. Co., Ltd

3.2.5 RLY OUT Connector Details

The RLY OUT connector is a terminal for outputting state and NO contact relay output. A circuit between terminals is short-circuited when RDY LED is lit, and opens when it is unlit.

Note: A state when RDY LED is lit indicates that a controller is operating normally. It does not indicate that an user program is running.

(1) RLY OUT Connector Specifications and Pin Arrangement

The following table provides the RLY OUT connector specifications.

Name	Connector Name	Number of Pins	Connector Model		
			Module Side	Cable Side	Manufacturer
RLY OUT	RLY OUT	2	734-162	734-YE102	Wago Corporation

The following table shows the RLY OUT connector pin arrangement.



Pin Number	Signal Name	Description
1	OUT	• Operating normally: Short-circuit
2	OUT	• Error occurred: Opened

The following table provides the RLY OUT connector contact ratings.

Input Voltage	Current Capacity
24 VDC	0.5 A (resistance load)
	0.25 A (induced load)
125 VAC	0.4A (resistance load)
	0.2A (induced load)


(2) RLY OUT Connection Cable

For the RLY OUT connection cable, use a cable of line size AWG28 to AWG14 (0.08 mm^2 to 1.5 mm^2), maximum sheath diameter $\phi 3.4 \text{ mm}$.

The RLY OUT connector cable is similar in manufacture to the 24-VDC power supply cable.

(3) RLY OUT Connection Example

The following figure shows how to connect the RLY OUT connector:




3.2.6 System Connection Example

The following diagram shows a connection example of a system using the MP2400.

The following diagram shows a 200-VAC power supply example.

Note: elect the SERVOPACK, 24-VDC power supply to use in accordance with the input power supply specification.



System Start Up and Easy Programming

This chapter explains how to start up a model system using the programming tool MPE720 Ver.6.
Note that the procedure for designing a mechanical system has been omitted here.

4.1 System Startup Overview	4-2
4.2 Preparation (step 1)	4-3
4.2.1 Wiring	4-3
4.2.2 Self Configuration	4-5
4.2.3 Test Operation	4-6
4.3 Programming (step 2)	4-9
4.3.1 Programming Procedure	4-9
4.4 Executing Motion (step 3)	4-11
4.4.1 Registering Program Execution	4-11
4.4.2 Starting a Motion Program Using the Operation Control Panel	4-12
4.5 Starting Motion Program from an External Signal	4-13
4.5.1 Overview	4-13
4.5.2 Required Equipment	4-13
4.5.3 Creation Procedure	4-15

4.1 System Startup Overview

The start-up procedure for a model system is as follows. For detailed information of each step, refer to the cited references.

This chapter explains a procedure where you can easily run and check a program without external signals.

The simple motion program which you create has three lines only, moving and stopping 150,000 pulses from the current position.

INC;	Specify an incremental mode
MOV	[A1]150000, [B1]150000;Position two-axes 150,000 pulses
END;	




4.2 Preparation (step 1)

This section explains the steps of “wiring,” “self-configuration,” and “test operation” for starting up the model system.

4.2.1 Wiring

We use the following layout model to explain the startup of the model system. Prepare each device listed on the next page and connect them as shown in the figure below.

(1) System Layout Model



[a] Required Equipment

Product Name	Model	Q'ty
MP2400	JEPMC-MP2400-E	1
MECHATROLINK cable (0.5m)	JEPMC-W6002-A5-E	2
Terminator (terminating resistor)	JEPMC-W6022-E	1
Σ -III SERVOPACK	SGDS-A5F12A	2
Σ -III servomotor	SGMAS-A5A2A21	2
Motor cable (3m)	JZSP-CSM01-03	2
Encoder cable (3m)	JZSP-CSP05-03	2
HUB (commercial product)	LSW-TX-8EP	1
MPE720 Ver.7	CPMC-MPE780D	1
LAN cable (for Ethernet connection)	Commercial straight cable	2
Personal computer (main unit)	Commercial product	1
24-VDC	Current capacity of power supply 2A or more	1


■ Caution

- Install MPE720 Ver.7 in the personal computer before starting step 1.
For information on its installation, refer to “System Integrated Engineering Tool MPE720 Ver.7 USER’S MANUAL” (manual number: SIEP C880761 03).
- Set the PC Ethernet port in advance. For information on the setup, refer to *Appendix C Simple Connection Function of the Engineering Tool* on page A-31.
- The SERVOPACK station number (SW1) is set to 1 and 2.
- In a 1:1 connection without HUB, use a cross cable as a LAN cable.

4.2.2 Self Configuration

Run the self configuration to automatically recognize devices connected to the MECHATROLINK connector.
Steps for self configuration are as follows.

1. Check that the Σ -III SERVOPACK power supply is ON.
2. Turn OFF the MP2400 24-V power supply.
3. Turn ON "INIT" and "CONFIG" of DIP switch (SW1) on the MP2400 main unit.
4. Turn ON the 24-VDC power supply on the MP2400 main unit, and confirm the LED display changes as follows:



5. Self configuration is complete, and MECHATROLINK slave device information has been written to a definition information file.
6. Turn OFF "INIT" and "CONFIG" of DIP switch (SW1) on the MP2400 main unit.


4.2.3 Test Operation

Confirm that the machine controller can command axis servo ON/OFF and jog operation.

(1) Starting and Connecting MPE720 Ver.7


Launch MPE720 Ver.7 and click “Connection ETHERNET [1] IP192.168.1.1” to connect to the controller.

For more information on the communications settings, refer to *Appendix C Simple Connection Function of the Engineering Tool* on page A-31.




When the connection is complete, the display will change from offline to online.

(2) Operating Manually in the Test Operation Screen





1. Click **System** in the subwindow and double-click **Axis Configuration - Test Run** to display a warning dialog a box for the test run. Click the **Agree** Button.






2. Axis Selection and Servo ON

Set an axis number in the **Axis** Window and click the **Enable** (Servo ON) Button in the **Test Run** Window.



3. Jog Operation

Click the Speed reference icon and set a speed reference value, and check that the axis rotates normally while the **Forward** Button or **Reverse** Button is pressed.



The operation check of the first axis is complete.


Press the **Axis ...** Button to change to "Axis #02" in the axis select screen, and perform the steps 1 to 3 above.

4.3 Programming (step 2)

This section describes the procedure from creating to saving a motion program.


4.3.1 Programming Procedure

1. Click the **Motion** Tab in the subwindow.




2. The motion program subwindow will appear.

When you double-click **Motion Program** and there is not any group definition, the **Group Definition** screen will be shown. For this setting example, you do not need to change it, so accept the default setting and click the **OK** Button. Note that if a group definition already exists, the **Group Definition** screen will not be shown.



3. Right-click **Main Program** and select **New** to display the **Create New Program** Dialog Box. Then click the **OK** Button.




4. Editing Motion Program


Use the command input assist feature to insert INC and MOV Commands into the motion program.

The command input assist feature is made accessible by right-clicking the mouse on the **Motion Editor** Window.


- Call the command input assist feature



- Insert an INC Command



- Insert a MOV Command




Click the save icon to save the motion program.




4.4 Executing Motion (step 3)

4.4.1 Registering Program Execution

1. Click the **Task Allocate** icon.




- Note: 1. This motion program was made with the assumption that **Enable (Servo ON)** was selected in step 2 of 4.2.3 (2) *Operating Manually in the Test Operation Screen*.
2. If the following Dialog Box appears after this operation, allocate the M-EXECUTOR.




The **Task Allocation** window will appear.

2. Check **Program No.** and click **Set** to save the registered contents.




4.4.2 Starting a Motion Program Using the Operation Control Panel

1. Click the **Drive Control Panel** icon.



The **Device Control Panel** Dialog Box will appear.

2. Check Program to run, and click the **ON** Button.



The MPM001's motion program is executed.


■ Caution

- This chapter explains the simple procedure where you can easily run and check a program without external signals. In practice, you need to connect to external signals and create a sequence.
- Registering a program execution enables the M-EXECUTOR definition. The MP2400 automatically controls the motion program, so be aware that changing registers registered in ladder and sequence programs may cause problems.

4.5 Starting Motion Program from an External Signal

4.5.1 Overview

This section explains how to start a motion program created in 4.3 *Programming (step 2)* from external signals. Note that in this section, we show an example which substitutes a touch panel for the external signal.



4.5.2 Required Equipment

Product Name	Model	Q'ty
MP2400	JEPMC-MP2400-E	1
MECHATROLINK cable (0.5 m)	JEPMC-W6002-A5-E	2
Terminator (terminating resistor)	JEPMC-W6022-E	1
Σ -III SERVOPACK	SGDS-A5F12A	2
Σ -III servomotor	SGMAS-A5A2A21	2
Motor cable (3 m)	JZSP-CSM01-03	2
Encoder cable (3 m)	JZSP-CSP05-03	2
Touch panel (manufactured by Digital Electronics Corp.)	AGP3300-T1-D24	1
HUB (commercial product)	LSW-TX-8EP	1
MPE720 Ver.7	CPMC-MPE780D	1
LAN cable (for Ethernet connection)	Commercial straight cable	3
Personal computer (main unit)	Commercial product	1
24-VDC power supply	Current capacity of power supply 2 A or more	1

Mapping of the panel manufactured by Digital Electronics Corp.

No.	Name	Mapping	Category	Description	MP2400 Operation
①	Start	MB5000	Control signal	Starts up a motion program	Sets in M-EXECUTOR
②	Stop	MB5002	Control signal	Displays the running of a motion program	
③	Clear Alarm	MB5005	Control signal	Stops a motion program	
④	Running Program	MB5010	Status	Clears an alarm of a motion program	
⑤	Alarm	MB5018	Status	Indicates an alarm is occurring in a motion program	
⑥	Axis 1 (current position)	IL8016	Monitor parameter	Displays current axis 1 position	Automatic receive function
⑦	Axis 2 (current position)	IL8096	Monitor parameter	Displays current axis 2 position	
⑧	Servo (ON/OFF)	MB5020	External signal	Axis 1, axis 2 servo ON signal	Sequence program is needed
⑨	Reset Axis Alarm	MB5021	External signal	Axis 1, axis 2 alarm reset signal	


- Note: 1. You do not need to create a program for signals and data in ① to ⑦.
 2. You need to create a sequence program for outputting signals of ⑧ and ⑨ to the motion parameters.
 3. For information on creating a program for the panel side, refer to 6.3 *Communication with Touch Panel*.

4.5.3 Creation Procedure


1. Creating a Sequence Program

Now create a sequence program which copies the M register content mapped to “**⑧ Servo (ON/OFF)**” and “**⑨ Axis Alarm Reset**” Buttons on the touch panel to the relevant registers in the motion setting parameter of the embedded SVB.

Follow a procedure similar to creating a motion program from the motion program subwindow.



Output the information of the “**⑧ Servo (ON/OFF)**” Button on the touch panel to the motion setting parameter “Axis 1 and axis 2 servo ON” of the built-in SVB.



Output the information of the “**⑨ Axis Alarm Reset**” Button on the touch panel to the motion setting parameter “Axis 1 and axis 2 alarm clear” of the built-in SVB.



Click the **Task Allocate** Icon.




2. Registering Program Execution

- The **Task Allocation** Dialog Box will appear.
- Click the **Set** Button to set a program definition in the **M-EXECUTOR** Window.
→ Then register the MPM001, SPM001 executions.



For more information on how to set the **M-EXECUTOR** Window, refer to 2.2.7 *M-EXECUTOR Module (Motion Program Executor)* on page 2-48.



- In the **Allocation Control Register** Window, map the M registers allocated to control signals (① **Start** / ② **Stop** / ③ **Alarm Clear**) and status (④ **Running Program** / ⑤ **Alarm**) on the touch panel as an M-EXECUTOR allocation register for the motion program created in 4.3 *Programming (step 2)*.
Status=MW00501, control signal=MW00500, allocation contact interlock =SB000004



- Click **File - Write** to save the M-EXECUTOR definition.




3. Communication Setting with Touch Panel

For information on communication setting with the touch panel, refer to 6.3 *Communication with Touch Panel*.

4. FLASH Save


When all settings are completed, click the **FLASH Save Icon** to save the data to the flash memory.



5. Operation Check

Turn ON MP2400 power again and press “① **Servo**” and “② **Start**” on the panel screen.

Then check that the motion program starts and the two-axes motor begins to operate to change the current position of the axis.



Outline of Motion Control Systems

This chapter describes the basic operation of MP2400 Motion Control Systems and provides an outline of user programs and registers.


5.1 Startup Sequence and Basic Operation	5-2
5.1.1 DIP Switch Settings	5-2
5.1.2 Startup Sequence	5-3
5.1.3 Startup Sequence Operation Details	5-4
5.2 User Programs	5-5
5.2.1 Types and Execution Timing of User Program	5-5
5.2.2 Motion Programs	5-6
5.2.3 Sequence Program	5-22
5.3 Registers	5-25
5.3.1 Types of Registers	5-25
5.3.2 Data Types	5-27
5.4 Self-configuration	5-28
5.4.1 How to Execute Self-Configuration	5-29
5.4.2 Definition Information Updated with Self-Configuration	5-33
5.5 Precaution on Using MP2400	5-36
5.5.1 Precautions when User Definition File is Configured/Changed	5-36
5.5.2 Setting or Changing Module Configuration Definition Files	5-37
5.5.3 Setting and Changing the Scan Time	5-38

5.1 Startup Sequence and Basic Operation

This section describes the MP2400 startup sequence and basic operation together with the DIP switch settings, self-diagnosis at startup, and LED indicator patterns.

5.1.1 DIP Switch Settings


Set the DIP switch (SW1) on the Basic Module to control operations of the startup sequence. The six switches are provided on the DIP switch (SW1) on the Basic Module as shown in the following figure. The following table lists the functions of six switches.



No.	Switch Name	Status	Operating Mode	Default Setting	Remarks
S1-6	STOP	ON	User program stops	OFF	Set to ON to stop user program operation.
		OFF	User program operation		
S1-5	SUP	ON	System load	OFF	Always leave set to OFF.
		OFF	Normal operation		
S1-4	INIT	ON	Memory clear	OFF	Set to ON to clear memory. Programs stored in flash memory will be run when Memory Clear is set to OFF. S and M registers are cleared to all zeros.
		OFF	Normal operation		
S1-3	CNFG	ON	Self-configuration mode	OFF	Set to ON for self-configuration of connected devices.
		OFF	Normal operation		
S1-2	MON	ON	System use	OFF	Always leave set to OFF.
		OFF	Normal operation		
S1-1	TEST	ON	System use Adjusted before Shipment	OFF	Always leave set to OFF.
		OFF	Normal operation		

5.1.2 Startup Sequence

The startup sequence for the MP2400 from the moment when the power has been turned ON is shown in the following flowchart.



* Refer to 5.1.3 *Startup Sequence Operation Details* on the next page for details on (1) to (5).

5.1.3 Startup Sequence Operation Details

(1) Self-diagnosis at Startup

Self-diagnosis is performed on the following items after the power is turned ON.

- Read/write diagnosis of memory (RAM)
- System program (ROM) diagnosis
- Main processor (CPU) function diagnosis
- Floating Point Unit (FPU) function diagnosis

If diagnosis results in an error, the ALM and ERR LED indicators will blink red for the specified number of times. Refer to 8.2 *LED Indicator Meanings* on page 8-3.

(2) Self-configuration

Self-configuration automatically recognizes the connected Optional Modules, and automatically creates a definitions file. For details, refer to 5.4 *Self-configuration* on page 5-28.

The RUN LED indicator will blink green during execution of self-configuration.

(3) Operation Start

When the STOP switch is set to OFF (RUN) or changes from ON (STOP) to OFF (RUN), the CPU starts the watchdog timer and then executes the sequence program set in “Sequence Program (Startup).” Refer to the startup processing drawing and 5.2.2 *Motion Programs* on page 5-6.

First scan processing is executed once the startup process has been completed and the high-speed or low-speed scan time has elapsed. System I/O are executed from the first scan.

(4) Operation Stop

MP2400 stops motion control operation when the STOP switch is ON (STOP) and in the following circumstances.

Cause	Restart method
Power supply turned OFF	Turn ON the power again.
Power interruption	
Fatal error	Check the LED indicator for the cause of the error and then turn the power OFF then ON.
STOP executed from MPE720	Execute RUN from MPE720.

(5) Online Self-diagnosis

Self-diagnosis is performed on the following items when the user logs on online.

- System program (ROM) diagnosis
- Main processor (CPU) function diagnosis
- Floating Point Unit (FPU) function diagnosis

If diagnosis results in an error, the ALM and ERR LED indicators will blink red.

5.2 User Programs

User programs for executing machine control using the MP2400 include ladder programs and motion programs. This section describes the basic operation and other information about user programs.

- For programming details, refer to the following manuals.
Machine Controller MP2000 Series USER'S MANUAL for Motion Programming (SIEP C880700 38)

5.2.1 Types and Execution Timing of User Program

The following table shows the types and execution timing of MP2400 user program.

User Program		Execution Timing
Motion Program	High-speed Scan Process	Turns ON the program operation start request of the control signal (runs when program operation start request is ON)
	Startup Process	Power-up (during power-up, runs only once)
Sequence Program	High-speed Scan Process	Periodical startup (runs each time a high-speed scan is performed)
	Low-speed Scan Process	Periodical startup (runs each time a low-speed scan is performed)

For more information on the user program, refer to the next page and after.

5.2.2 Motion Programs

Motion programs are programs written in a text-based language called motion language. The following table shows the two types of motion programs.


Type	Specification Method	Features	No. of Programs
Main Program	MPM□□□ (□□□ = 1 to 256)	Can be called from M-EXECUTOR program execution definition	Up to 256 programs of the following types can be created: • Main motion program • Sub motion program • Main sequence program • Sub sequence program
Sub-program	MPS□□□ (□□□ = 1 to 256)	Can be called from main programs	

- The program numbers of motion programs are managed in the same manner as the sequence program numbers. Assign a unique number for each program number.
 - Program number of Motion program MPM □□□, MPS □□□
 - Program number of Sequence program SPM □□□, SPS □□□
- The MP2400 can execute up to 16 motion programs simultaneously. An alarm (no system work error) will occur if 17 or more programs are executed simultaneously.
 - No system work error: Bit E of the leading word in the MSEE work registers


(1) Groups

A group of axes with related operations can be treated as one group by motion programs and programs can be executed for each group. This allows one MP2400 to independently control multiple machines using group operation. Group operation can be single group operation or multiple group operation. Definitions for axes to be grouped together are made under *Group Definitions*.


(a) Single Group Operation




(b) Multiple Group Operation




This section explains the Group Definition screen.




- ① **No. of Group**
Set a number for the operation as a group.
Set it to 1 for the operation as one group.
Set it to the number of groups for the operation with multiple groups.
- ② **Group Name**
Define a group name.
- ③ **No. of Control Axes**
Set the number of axes controlled in the group.
- ④ **Circuit**
Set a line number for the used motion module.
The line number can be checked in the module configuration definition.



- ⑤ Axis No.
- Set an axis number for the used axis.
- The axis number can be checked in the Module Configuration Definition Window.




- ⑥ Logical Axis Name
- Define a name for the specified axis number.
- The name defined here is used when programming a motion program.



(2) How to Run a Motion Program

Motion program can be executed by registering it to the M-EXECUTOR program execution definition.
Motion programs are executed in ascending order.

The execution example is shown in the figure below.



The above method is a preparation for running a motion program. When registered in the M-EXECUTOR program execution definition, a motion program does not start up. To start up the motion program, after the motion program registration, use a control signal to turn ON the request for the program operation startup.
The motion program registered in M-EXECUTOR is executed at a scan cycle, but similar to a sequence program, the whole program cannot be executed at a single scan. In case of the motion program, a motion management function in the system carries out an execution control exclusive for the motion programs.

■ Caution

- When registering a motion program to M-EXECUTOR, pay attention to the followings:
- Multiple motion programs with the same number cannot be registered.
 - Multiple motion programs with the same number cannot be referenced using an indirect designation.

(3) How to Designate a Motion Program

The following two methods are available for designating a motion program.

- Using a direct designation to invoke a motion program
- Using a indirect designation to invoke a motion program

Now, this section explains each way to designate a motion program.

[a] Using a Direct Designation to Call a Motion Program

A direct designation method designates a motion program to call using a program number (MPM □□□).

- A motion program registered in the M-EXECUTOR program execution definition

Select **Direct** for the Setting and set a program number (MPM □□□).




Fig. 5.1 Calling a Motion Program Using a Direct Designation

[b] Using an Indirect Designation to Call a Motion Program

An indirect designation method designates a motion program to call using a register.
In this method, a program (MPM □□□) coinciding with value stored in the register is called.

■ A motion program registered in the M-EXECUTOR program execution definition

Select **Indirect** for the Setting. A register for the indirect designation is automatically mapped.




Fig. 5.2 Calling a Motion Program Using an Indirect Designation

(4) Work Register

Configure and monitor a motion program via a work register.
The work register constitution is as follows:

■ The work register constitution

The work register is assigned to a M-EXECUTOR control register. (automatically defined by system)
The M-EXECUTOR control register constitution is as follows:

No.	Item	M-EXECUTOR Control register	
1	Program number	MPM001	
	Status	IW00C00	← Work register (automatically defined by system)
	Control signal	OW00C01	
	Override	OW00C02	

M-EXECUTOR Control Register	Description
Status	Status flag of a motion program
Control Signal	Control Signal of a motion program
Override	Override for interpolation

For more information on the work register, refer to the subsequent pages.

[a] Status Flag of a Motion Program

The motion program status flag shows the execution status of the motion program.
The following table shows details of status flag.

[Status Flag]

Bit No.	Status
0	Program running
1	Program paused
2	Program stopped by stop request (used by system)
3	(Reserved)
4	Single program block operation stopped
5	(Reserved)
6	(Reserved)
7	(Reserved)
8	Program alarm
9	Stopped by brake point
A	(Reserved)
B	In debug mode (EWS debugging operation)
C	Program type 0: Motion program
D	Start request signal history
E	No system work error
F	Main program number exceeded error

- When program alarm has occurred, the error details of the motion program are stored in the error information screen and S registers.

[b] Control Signal

Program control signals (e.g., program operation start requests and program stop requests) need to be entered to execute the motion program.

The following types of signals for controlling motion programs are available.

: Signals with this indication must be kept ON until they are accepted by the system.


: Signals with this indication should be ON for one high-speed scan.

Bit No		Status	Description
0 to 3	Bit 0  	Program operation start request	Request to start a motion program. When this bit status changes from OFF to ON, the motion program will start running. However, this bit is disabled whenever an alarm is occurring in the motion program. 0: Program Operation Start Request OFF 1: Program Operation Start Request ON
	Bit 1 	Program pause request	Request to pause a motion program. Resetting this bit to 0 after pausing the motion program will restart the program from the point it was stopped. 0: Program Pause Request OFF (Cancel the pause request) 1: Program Pause Request ON
	Bit 2 	Program stop request	Request to stop a running motion program. Turning this bit ON while the axis is moving will cause a motion program alarm. 0: Program Stop Request OFF, 1: Program Stop Request ON
	Bit 3 	Program single block mode selection	Request for program single block mode. Use this bit instead of the debugging operation 0: Program Single Block Mode Selection OFF 1: Program Single Block Mode Selection ON
4 to 7	Bit 4  	Program single block start request	Changing this bit status from OFF to ON will start the program single block operation (step-by-step operation). This bit is valid when the control signal bit 3 (Program single block mode selection) is ON. 0: Program Single Block Start Request OFF 1: Program Single Block Start Request ON
	Bit 5 	Alarm reset request	Request to reset a motion program alarm. 0: Alarm Reset Request OFF, 1: Alarm Reset Request ON
	Bit 6  	Program continuous operation start request	Request to restart a program that has been stopped by the Program Stop Request, from the point it was stopped. 0: Program Continuous Operation Start Request OFF 1: Program Continuous Operation Start Request ON
	Bit 7	(Reserved)	—
8 to B	Bit 8 	Skip 1 information	Turning this bit ON while moving the axis using an SKP command (when SS1 is selected for the skip input signal) will decelerate the axis to a stop and cancel the moving amount that remains. 0: SS1 signal OFF, 1: SS1 signal ON
	Bit 9 	Skip 2 information	Turning this bit ON while moving the axis using an SKP command (when SS2 is selected for the skip input signal) will decelerate the axis to a stop and cancel the moving amount that remains. 0: SS2 signal OFF, 1: SS2 signal ON
	Bit A	(Reserved)	—
	Bit B	(Reserved)	—
C to F	Bit C	(Reserved)	—
	Bit D 	System work number setting	Turn this bit ON to specify the system work number. 0: Do not specify the system work number, 1: Specify the system work number
	Bit E 	Override setting for interpolation	Turn this bit ON to enable the interpolation override. 0: Disable the interpolation override. 1: Enable the interpolation override.
	Bit F	(Reserved)	—


■ Timing Chart for Motion Program Control Signals

The following figure shows an example of a timing chart for motion program control signals.


• Program Operation Start Request



• Pause Request



• Stop Request



- An alarm will occur if the stop request is turned ON during axis operation using a motion command.

[c] Interpolation Override

The override when executing interpolation travel commands (setting; unit: 1 = 0.01%) is set.

This interpolation override is enabled only when the motion program control signal bit E (interpolation override setting) is ON.

(5) How to Operate a Work Register

Select either of the following two execution processes as the method of operating a work register.

- A way to immediately control a motion program from external equipment
- A way to control a motion program via a sequence program

Now, this section explains each execution processing in the subsequent pages.

■ A Way to Immediately Control a Motion Program from External Equipment

M-EXECUTOR has a function which allocates any register to an M-EXECUTOR control register.


Using this function allows you to automatically exchange data between an M-EXECUTOR control register and an I/O register connected to an external equipment. This allows you to immediately control the motion program from the external equipment.

The following figure shows a setting example in this method.

Figure for allocating the M-EXECUTOR register

No.	Item	M-EXECUTOR Control register	Allocation Disable	Direction	Allocation register	Allocation Contact interlock
1	Program number	MPM001				
	Status	IW00C00	☐	->	OW00000	IB000020
	Control signal	OW00C01	☐	<-	IW00000	IB000020
	Override	OW00C02	☐	<-	IW00001	IB000020

Specify any registers for mapping register and mapping interlock contact.



- An allocation contact interlock is used to interlock the operation of a motion program. When setting an allocation register, be sure to set an allocation contact interlock.

It is processed, as shown below, by turning ON/OFF an allocation contact interlock:

- When an allocation contact interlock contact is ON, data is exchanged between an allocation register and M-EXECUTOR control register at H scan cycle. Now, the motion program becomes executable.
- When an allocation contact interlock is OFF, data is not exchanged between an allocation register and M-EXECUTOR control register. Now, the motion program becomes unexecutable.
- When an allocation contact interlock is switched from ON to OFF while running a motion program, the running motion program stops and an axis in operation also stops. Now, the motion program falls into the alarm "1Bh: Executing an emergency stop command" state, and the status "Bit8: Program alarm is occurring" is turned ON.

Again, to execute a motion program, follow the procedure below for operation:

1. Switch the interlock contact from OFF to ON.
2. Turn ON a control signal "Bit5: Alarm reset request."
3. Make sure that the status "Bit8: Program alarm is occurring" is turned OFF.
4. Turn OFF the control signal "Bit5: Alarm reset request."
5. Turn ON a control signal "Bit0: Request for the program operation startup."

■ A Way to Control a Motion Program via a Sequence Program

Without using the allocating function of the above mentioned M-EXECUTOR control register, controls a motion program via a sequence program.

To use this execution processing, save the blank Allocation register and the blank Allocation interlock contact as a blank.


In this case, the M-EXECUTOR control register configures and monitors the motion program.

The following figure shows a setting example in this method.

M-EXECUTOR program execution definition

No.	Item	M-EXECUTOR Control register	Allocation Disable	Direction	Allocation register	Allocation Contact interlock
1	Program number	MPM001				
	Status	IW00C00	☐	->		
	Control signal	OW00C01	☐	<-		
	Override	OW00C02	☐	<-		

Save the mapping register and the mapping interlock contact as a blank.



The following is an example of a program for controlling the motion program.

Example using a sequence program

```
OB80000 = IB00000;           "axis 1 servo on"
OB0C010 = PON( IB00001 DB000000 ); "program start"
OB0C011 = IB00002;           "hold"
OB0C012 = IB00003;           "program stop"
OB0C015 = IB00004;           "alarm reset"
OB8000F = IB00005;           "Turn ON a single axis servo"
IF NON( IB0C000 DB000001 ) == 1; "Is the program operation OFF?"
;                             "Process when program operation is stopped"
IEND;

END;
```

(6) Monitor the motion program execution information using S register

Using S register (SW03200 to SW04191) allows you to monitor the motion program execution information.
The way to monitor it is shown as follows:

[a] A motion program registered in the M-EXECUTOR program execution definition

When a motion program is registered in the M-EXECUTOR program execution definition, the same system work number as the definition No. is used.

For example, a motion program is registered as “Definition No.” =3, the used system work number is “System Work”=3. In this case, the execution information for the motion program can be monitored in “Program Information Using Work 3” (=SW03380 to SW03437).

For more information on the register area of the motion program execution information, refer to the subsequent pages.

■ Register Areas for Motion Program Execution Information

Motion program execution information			Executing program number	
SW03200	Executing program number (No. of main program currently executing) 16W	SW03200	Program number used by work 1	
		SW03201	Program number used by work 2	
SW03216	Reserved by the system. 16W	SW03202	Program number used by work 3	
SW03232	Executing Program Bit (Executing when corresponding bit is ON) 16W	SW03203	Program number used by work 4	
		SW03204	Program number used by work 5	
SW03248	Reserved by the system. 16W	SW03205	Program number used by work 6	
SW03264	Program information used by work 1 58W	SW03206	Program number used by work 7	
SW03222	Program information used by work 2 58W	SW03207	Program number used by work 8	
		SW03208	Program number used by work 9	
SW03380	Program information used by work 3 58W	SW03209	Program number used by work 10	
		SW03210	Program number used by work 11	
SW03438	Program information used by work 4 58W	SW03211	Program number used by work 12	
		SW03212	Program number used by work 13	
SW03496	Program information used by work 5 58W	SW03213	Program number used by work 14	
		SW03214	Program number used by work 15	
SW03554	Program information used by work 6 58W	SW03215	Program number used by work 16	
SW03612	Program information used by work 7 58W			
SW03670	Program information used by work 8 58W			
SW03728	Program information used by work 9 58W	SW03232	Executing program bit	
		SW03233	MP□016 (Bit15) to MP□001 (Bit0)	
SW03786	Program information used by work 10 58W	SW03234	MP□032 (Bit15) to MP□017 (Bit0)	
		SW03235	MP□048 (Bit15) to MP□033 (Bit0)	
SW03844	Program information used by work 11 58W	SW03236	MP□054 (Bit15) to MP□049 (Bit0)	
		SW03237	MP□080 (Bit15) to MP□055 (Bit0)	
SW03902	Program information used by work 12 58W	SW03238	MP□096 (Bit15) to MP□081 (Bit0)	
		SW03239	MP□112 (Bit15) to MP□097 (Bit0)	
SW03960	Program information used by work 13 58W	SW03240	MP□128 (Bit15) to MP□113 (Bit0)	
		SW03241	MP□144 (Bit15) to MP□129 (Bit0)	
SW04018	Program information used by work 14 58W	SW03242	MP□160 (Bit15) to MP□145 (Bit0)	
		SW03243	MP□176 (Bit15) to MP□161 (Bit0)	
SW04076	Program information used by work 15 58W	SW03244	MP□192 (Bit15) to MP□177 (Bit0)	
		SW03245	MP□208 (Bit15) to MP□193 (Bit0)	
SW04134	Program information used by work 16 58W	SW03246	MP□224 (Bit15) to MP□209 (Bit0)	
		SW03247	MP□240 (Bit15) to MP□225 (Bit0)	
SW04192	Reserved by the system. 928W			
SW05120	Reserved by the system. 64W			
			Note: □ indicates M or S.	

Note: □ indicates M or S.

■ Details of Program Information Used by Work n

Program information used by work n		
+0	Program status	
+1	Program control signal	
+2	Parallel 0 information	3W
+5	Parallel 1 information	3W
+8	Parallel 2 information	3W
+11	Parallel 3 information	3W
+14	Parallel 4 information	3W
+17	Parallel 5 information	3W
+20	Parallel 6 information	3W
+23	Parallel 7 information	3W
+26	Logical axis #1 program current position	2W
+28	Logical axis #2 program current position	2W
+30	Logical axis #3 program current position	2W
+32	Logical axis #4 program current position	2W
+34	Logical axis #5 program current position	2W
+36	Logical axis #6 program current position	2W
+38	Logical axis #7 program current position	2W
+40	Logical axis #8 program current position	2W
+42	Logical axis #9 program current position	2W
+44	Logical axis #10 program current position	2W
+46	Logical axis #11 program current position	2W
+48	Logical axis #12 program current position	2W
+50	Logical axis #13 program current position	2W
+52	Logical axis #14 program current position	2W
+54	Logical axis #15 program current position	2W
+56	Logical axis #16 program current position	2W

Executing program number
Executing block number
Error code

5.2.3 Sequence Program

A sequence program is a program described with motion language of text format.

The following table shows two types of sequence programs.

Category	Designation Method	Features	Number of Programs
Main program	SPM□□□ (□□□=1 to 256)	Calling from the M-EXECUTOR program execution definition	Up to 256 programs of the following types can be created: • Main motion program • Sub motion program • Main sequence program • Sub sequence program
Sub program	SPS□□□ (□□□=1 to 256)	Calling from the main program	

- The program numbers of sequence programs are managed in the same manner as the motion program numbers. Assign a different number for each program number.


- Motion program MPM□□□: Program number of MPS□□□
- Sequence program SPM□□□: Program number of SPS□□□

(1) How to Run a Sequence Program

A sequence program is executed by registering it in the M-EXECUTOR program execution definition.

Sequence programs are executed in ascending numeric order.

The following figure shows an execution example.



When the execution type is set to “**Sequence Program (H scan)**” or “**Sequence Program (L scan)**”, the program is executed at the time the definition is saved. When the execution type is set to **Sequence Program (Start)**, the program is executed when the power supply is turned ON again next time.

(2) How to Designate a Sequence Program

You can only designate a sequence program directly. Indirect designation is unavailable.
Use the program number (SPM□□□) when designating a sequence program to execute.




Fig. 5.3 Calling a Sequence Program

(3) Work Register

Monitor a sequence program through a work register.

A work register, similar to the motion program registered in M-EXECUTOR, has status flags in the M-EXECUTOR control register.

The following table shows the work register configuration of the sequence program.

Work Register	Content
Status	Status flag of a sequence program

[a] Status Flag of Sequence Program

The status flags of a sequence program allow you to know the execution status of the sequence program.

The following table explains the detailed contents of status flags.

[Status]

Bit No.	Status
0	Program running
1	(Reserved)
2	(Reserved)
3	(Reserved)
4	(Reserved)
5	(Reserved)
6	(Reserved)
7	(Reserved)
8	Program alarm is occurring
9	Stopping at breakpoint
A	(reserved)
B	In debug mode (EWS debug operation)
C	Program type 1: Sequence program
D	Start request history
E	(Reserved)
F	(Reserved)

■ Sequence program alarm

When referencing a sub sequence program (SSEE command execution) and an error is detected, “Bit8: Program alarm is occurring” is turned ON. If the error is cleared, it is turned OFF.

Error details are as follows:

Error Details
Called program is unregistered
Called program is not a sequence program
Called program is not a sub program (main program is called)
Called program number is over
Nest over error

5.3 Registers

This section describes the types of registers used in MP2400 user programs and how to use them.

5.3.1 Types of Registers

(1) Registers

Registers used by user program. Each program can use the registers outlined in the following table.


Type	Name	Specification Method	Range	Details	Characteristics
S	System registers	SB, SW, SL, SFnnnnn (SAnnnnn)	SW00000 to SW08191	Registers provided by the system. SW00000 to SW00049 are cleared to all zeros when the system starts.	Common to all programs
M	Data registers	MB, MW, ML, MFnnnnn (MAnnnnn)	MW00000 to MW65534	Registers shared by all programs. Used, e.g., as an interface between programs.	
I	Input registers	IB, IW, IL, IFhhhh (IAhhhh)	IW0000 to IW13FFF	Registers used for input data.	
O	Output registers	OB, OW, OL, OFhhhh (OAhhhh)	OW0000 to OW13FFF	Registers used for output data.	
C	Constants registers	CB, CW, CL, CFnnnnn (CAnnnnn)	CW00000 to CW16383	Registers that can only be called from programs.	
D	D registers	DB, DW, DL, DFnnnnn (DAnnnnn)	DW00000 to DW16383	Internal registers unique to each program. Can be used only by corresponding program. The usage range is set by the user using MPE720.	Unique to each program

Note: 1. n: Decimal number; h: Hexadecimal number

2. B, W, L, F, and A: Data type (B: Bit, W: Integer, L: Double-length integer, F: Real number, A: Address. Refer to 5.3.2 *Data Types* on page 5-27.)
3. Up to 32 D registers (32 words, DW0000 to DW0031) can be used when creating drawings, but this can be changed in the MPE720 Motion Properties Window. Refer to the *Machine Controller MP900/MP2000 Series User's Manual MPE720 Software for Programming Device* (manual number: SIEP C880700 05) or, refer to *System Integrated Engineering Tool MPE720 Ver.7 USER'S MANUAL* (manual number: SIEPC88076103) for details.
4. S and M register data has a battery backup to ensure the data is held even if the MP2400 power is turned OFF and ON.
It is recommended that data to be held regardless of whether or not the power is turned OFF and ON should be written to M registers if possible.

(2) Register Ranges in Programs

The following figure shows programs and register call ranges.





- (1): Registers that are common to all programs can be called from any drawing or function.
- (2): Registers that are unique to each program can be called only from within the drawing.

5.3.2 Data Types

There are five kinds of data: Bit, integer, double-length integer, real number, and address data. Each is used differently depending on the application. Address data, however, is used only inside functions when specifying pointers. The following table shows the types of data.

Type	Data types	Numeric Value Range	Remarks
B	Bit	0, 1	Used by relay circuits.
W	Integer	−32768 to +32767 (8000H) (7FFFH)	Used for numeric value operations. The values in parentheses () indicate use with logical operations.
L	Double-length integer	−2147483648 to +2147483647 (80000000H) (7FFFFFFFH)	Used for numeric value operations. The values in parentheses () are for use with logical operations.
F	Real number	$\pm (1.175\text{E}-38 \text{ to } 3.402\text{E}+38)$, 0	Used for numeric value operations.
A	Address	0 to 32767	Used only when specifying pointers.




5.4 Self-configuration

The self-configuration function automatically recognizes all slave data for slaves connected to the MECHATROLINK network of MP2400, and automatically generates a definition file.

Self-configuration greatly simplifies the procedure needed to start the system.

Refer to 5.4.2 *Definition Information Updated with Self-Configuration* for items that are automatically generated.

[Execute Self-Configuration]



5.4.1 How to Execute Self-Configuration

The following two methods are available for executing the self-configuration.

- Execute the self-configuration (from DIP switch)
- Execute the self configuration (from MPE720)

Now, this section explains each way to execute the self-configuration:

(1) Procedure Using the DIP Switch

Self-configuration can be executed from the Basic Module DIP switch.

[a] When Executing the Self-Configuration First Time after Connecting Equipment


By performing the operation below, the self-configuration for all modules is newly executed, and all new definition files are created.

Before performing the operation, turn ON the power supply of equipment such as SERVOPACK.

■ Caution

Note that this operation can clear the following data in MP2400.


- All definition files, all user programs, and all registers



[b] Self-configuration after Adding Devices Such as SERVOPACKs

By performing the following operation, a definition for an axis newly detected in the MECHATROLINK transmission is created. The definitions for already mapped axes are not updated.

Before performing the operation, turn ON the power supply of devices such as SERVOPACK.



Note: Since a register mapping was manually changed after the self-configuration was last executed last time, input/output addresses may be changed by executing subsequent self-configurations.

Also, when SVR is set to Disable, SVR may be reset to Enable.

To retain the changed register mapping, etc., manually map a register to the additional devices instead of using self-configuration, and then update the definition file.

■ INIT Switch and RAM Data

RAM data will be cleared if the INIT switch of the DIP switch on the MP2400 Basic Module is ON and the power is turned ON. Flash memory data is read and overwritten when the INIT switch is OFF and the power is turned ON. Therefore, to protect RAM data, always save data to the MP2400 flash memory before turning OFF the power when writing or editing programs.

■ Turning OFF Power After Executing Self-configuration

Do not turn OFF the 24-VDC power supply to the MP2400 after executing self-configuration until the definitions data has been saved to flash memory in the MP2400. If the power is somehow turned OFF before the data is saved to flash memory, re-execute the self-configuration.

(2) Procedure for Self-configuration Using MPE720

Executing self-configuration from the MPE720 allows not only self-configuration for all the Modules but also self-configuration for individual Modules.


[a] Self-configuration for All the Modules

Execute self-configuration for all the Modules when executing self-configuration for the first time after connecting devices.

Note: After having added or removed Modules or devices, use the procedure described in [b] *Self-configuration of Each Module* to detect the configuration. If executing self-configuration for all the Modules, the parameters may be overwritten.

1. Open the Module Configuration Definition Window of MPE720.

Start MPE720, and then open the target project file. Click **Module Configuration** in the main window. Or, double-click **Module configuration** in the System sub programs.



The Module Configuration Definition Window is displayed.

2. Click the **All modules** button to execute self-configuration.



3. On the Module Configuration Definition Window, the devices currently connected to the MP2400 and the station numbers of those devices are displayed.


4. Select **Online - Save to FLASH** from the main menu to save the definitions data to the flash memory.

[b] Self-configuration of Each Module

If devices are added, self-configuration can be executed separately for the Module (port) that has been changed.


1. Open the Module Configuration Definition Window of MPE720.

Start MPE720, and then open the target project file. Click **Module Configuration** in the main window. Or, double-click **Module configuration** in the System sub programs.



The Module Configuration Definition Window is displayed.

2. Select the cell of the module which added the device, and click the **specified module** button to execute self-configuration.



Note: If executing self-configuration for each module when MP2400 is selected as an individual module, all the modules will be self-configured.

3. Select **Online - Save to FLASH** from the main menu to save the definitions data to the flash memory.

5.4.2 Definition Information Updated with Self-Configuration

Now, the definition information updated during executing the self-configuration and the module configuration definition example based on the module combination are as follows:

(1) Definition Data of MP2400 Basic Module

[a] I/O Allocations

Item		Allocation
218IFA		- Start I/O register: IW0000/OW0000 - End I/O register: IW07FF/OW07FF (Input register: IW0000 to IW07FF Output register: OW0000 to OW07FF)
SVB	MECHATROLINK	- Start I/O register: IW0800/OW0800 - End I/O register: IW0BFF/OW0BFF (Input register: IW0800 to IW0BFF Output register: OW0800 to OW0BFF)
	Motion Parameter	- Start motion register: IW8000/OW8000 - End motion register: IW87FF/OW87FF (Input register: IW8000 to IW87FF Output register: OW8000 to OW87FF)
SVR	Motion Parameter	- Start motion register: IW8800/OW8800 - End motion register: IW8FFF/OW8FFF (Input register: IW8800 to IW8FFF Output register: OW8800 to OW8FFF)
M-EXECUTOR		- Start I/O register: IW0C00/OW0C00 - End I/O register: IW0C3F/OW0C3F (Input register: IW0C00 to IW0C3F Output register: OW0C00 to OW0C3F)

[b] 218IFA Definition

Item	Allocation
Local IP Address	192.168.1.1
Subnet Mask	255.255.255.0
Gateway IP Address	0.0.0.0
Module Name Definition	“CONTROLLER NAME”
System Port (engineering port)	9999 (UDP)
Check & Monitor Time of MEMOBUS response	0 s
Retransmit Count	0

Note: The self-configuration allows you to connect with MPE720 for engineering transmission. In order to carry out MEMOBUS message transmission, manually use an automatic reception and I/O message communication separately.

[c] MECHATROLINK Detail Definitions

MECHATROLINK detail definitions are automatically set according to the detected communication method and the number of slaves.

For more information on self-configuration for SVB module, refer to Chapter 3 of *Machine Controller MP2000-series SVB/SVB-01 Motion Module User's Manual* (manual number: SIEP C880700 33).

■ Master

Item		MECHATROLINK-II (32-byte mode)				MECHATROLINK-II (17-byte mode)		MECHATROLINK-I
	Maximum Slave Station Number	1 to 8	9	10 to 16	17 to 21	1 to 14	15	
Number of Transmit Bytes		31 bytes				16 bytes		—
Communication Cycle		1ms	1ms	2ms	2ms	1ms	1ms	2ms
Number of Retry Stations		1	0	5	21: Maximum sta- tion number	1	0	14
Number of Slave Stations		8	9	16	Maximum station number	14	15	14

■ Slave

Item	MECHATROLINK-II (32-byte mode)	MECHATROLINK-II (17-byte mode)	MECHATROLINK-I
Number of Transmit Bytes	—	—	—
Communication Cycle	1ms	1ms	2ms
Number of Slave Stations	30	30	15

Note: To use MP2400/SVB as a Slave, before executing the self-configuration, the parameter setting for MECHATROLINK detail definition must be set to Slave in MPE720.

[d] SVR Definition

Type	No.	Name	Allocation
Fixed Parameter	0	Selection of Operation Modes	Axis unused
	1	Function Selection Flag 1	0000h
	4	Reference Unit Selection	pulse
	5	Number of Digits below Decimal Point	3
	6	Travel Distance per Machine Rotation	10000 reference unit
	8	Servo Motor Gear Ratio	1 rev (rotation)
	9	Machine Gear Ratio	1 rev (rotation)
	10	Infinite Length Axis Reset Position (POS MAX)	360000 reference unit
	34	Rated Motor Speed	3000 min ⁻¹
	36	Number of Pulses per Motor Rotation	65536 pulse/rev
	42	Feedback Speed Movement Averaging Time Constant	10 ms
Setting Parameter	OW□□00	RUN Command Setting	0000h
	OW□□03	Function Setting 1	0011h
	OW□□08	Motion Command	0: No command
	OW□□09	Motion Command Control Flag	0000h
	OW□□0A	Motion Subcommand	0: No command
	OL□□0C	Torque/Thrust Reference Setting	0.00%
	OL□□10	Speed Reference Setting	3000 10**n reference unit/min
	OL□□16	Secondly Speed Compensation	0.00%
	OL□□1C	Position Reference Setting	0 reference unit
	OW□□31	Speed Compensation	0.00%
	OL□□36	Straight Line Acceleration/ Acceleration Time Constant	0 ms
	OL□□38	Straight Line Deceleration/ Deceleration Time Constant	0 ms
	OW□□3A	Filter Time Constant	0.0 ms
	OW□□3B	Bias Speed for Index Deceleration/ Acceleration Filter	0 reference unit/s
	OW□□3D	Width of Starting Point Position Output	100 reference unit
	OL□□44	STEP Travel Distance	1000 reference unit
	OL□□48	Zero Point Position in Machine Coordinate System Offset	0 reference unit
	OL□□4A	Work Coordinate System Offset	0 reference unit
	OL□□4C	Number of POS MAX Turns Presetting Data	0 turn
	OW□□5C	Fixed Parameter Number	0

[e] M-EXECUTOR Definition

Item	Allocation
Number of Program Definitions	8
Program Allocation	None
Control Register Allocation	None


5.5 Precaution on Using MP2400

This section explains precautions when a user definition file is configured/changed and when setting a scan time.


5.5.1 Precautions when User Definition File is Configured/Changed

System settings, scan time settings, and module configuration definitions must be saved in flash memory (flash save). When a system setting, scan time setting, or module configuration definition is configured/changed, be sure to use MPE720 to flash save it. Note that when the MP2400 power supply is turn ON again without flash saving, the configured/changed data may be lost.

- System Setting



- Scan Time Setting



- Module Configuration Definition

The screenshot shows the 'Module Configuration' window. On the left, a tree view shows '01 [MP2400] ---' expanded to show 'MP2400 [Driving]'. The main table lists the following modules:

Module	Function Module/Slave	Status	Circuit No./AxisAddress	Start	Occupied circuits	Motion Register	Disabled	Register(Input/Output)	Start - End	Size	Scan	Comment
	CPU	Driving										
	2107FA	Driving	Circuit No1	1				Input	0000 - 07FF[D]	2048		
	SVB	Driving	Circuit No1	1		8000 - 87FF[D]		Output	0800 - 0BFF[D]	1024		
	SVR	Driving	Circuit No2	1		8000 - 87FF[D]						
	M-DECUTOR	Driving							0C00 - 0C3F[D]	64		

5.5.2 Setting or Changing Module Configuration Definition Files

Observe the following precautions when setting or changing module configuration definition files.

- Always check to make sure that the mounted Module is the one that is defined.
- Be sure to save any new settings or changes to flash memory.
- After the settings or changes have been completed, turn the power supply to the MP2400 OFF and ON.

5.5.3 Setting and Changing the Scan Time

(1) Precautions When Setting or Changing the Scan Time


The scan time can be set and changed in the **Scan Time Setting** Window in the **Environmental Setting** Dialog Box on the MPE720.

Observe the following precautions when setting or changing the scan time.

- Set the set values of the scan time for both the high-speed (H) and low-speed (L) scans to at least the maximum time required to execute the scans. We recommend setting the set values of the scan time using the formula (set value – maximum time to execute scan) $\geq (0.2 \times \text{set values of the scan time})$, i.e., setting the set values of the scan time to at least 1.25 times the maximum times required to execute the scans.

Note: If the scan time is set too close to the maximum execution time for the scan, the refresh time for the screen on the MPE720 will be very slow and communication timeouts may occur. If the maximum execution time exceeds the scan time set value, a watchdog timer timeout error will occur and the MP2400 system will stop.

- Set the set values of the high-speed (H) and low-speed (L) scan time to an integral multiple of the MECHATROLINK communication cycle (1 or 2 ms) set in the MP2400. Always check the set values of the scan time after changing the MECHATROLINK communication cycle.
- Do not change the scan time set value while the Servo is ON. Never change the setting while the axis is moving (while the motor is running). Otherwise an error may occur during motor operation (e.g., high-speed rotation).
- When the scan time is set or changed, be sure to save the data to flash memory.



(2) Scan Time Set Value Examples

■ 0.8-ms Maximum Scan Time and 1-ms Communication Cycle (MECHATROLINK-II Only)

High-speed (or low-speed) scan set value $\geq 1.25 \times 0.8 (= 1 \text{ ms})$

High-speed (or low-speed) scan set value = 1 ms, 2 ms, 3 ms, etc. (an integral multiple of at least 1 ms)

■ 1.4-ms Maximum Scan Time and 1-ms Communication Cycle (MECHATROLINK-II Only)

High-speed (or low-speed) scan set value $\geq 1.25 \times 1.4 (= 1.75 \text{ ms})$

High-speed (or low-speed) scan set value = 2 ms, 3 ms, etc. (an integral multiple of at least 2 ms)

■ 0.8-ms Maximum Scan Time and 2-ms Communication Cycle (MECHATROLINK-I or MECHATROLINK-II)

High-speed (or low-speed) scan set value $\geq 1.25 \times 0.8 (= 1 \text{ ms})$

High-speed (or low-speed) scan set value = 1 ms, 2 ms, 4 ms, etc. (an integral multiple of 2 ms at 1 ms and 2 ms or higher)

■ 1.4-ms Maximum Scan Time and 2-ms Communication Cycle (MECHATROLINK-I or MECHATROLINK-II)

High-speed (or low-speed) scan set value $\geq 1.25 \times 1.4 (= 1.75 \text{ ms})$

High-speed (or low-speed) scan set value = 2 ms, 4 ms, etc. (an integral multiple of 2 ms at 2 ms or higher)

Ethernet Communications

This chapter explains how to communicate with devices (PLC, touch panel, etc.) connected to the MP2400 by Ethernet.

6.1 Communication Methods	6-2
6.2 Communication with Other MP Series	6-3
6.2.1 When the MP2400 Acts as Slave (automatic receive function is used)	6-3
6.2.2 When MP2400 Acts as Master (I/O message communication function is used)	6-16
6.3 Communication with Touch Panel	6-29
6.3.1 When MP2400 Acts as Slave	6-29
6.4 Communication with PLC Manufactured by	
Mitsubishi Electric Corporation (MELSEC protocol)	6-39
6.4.1 When the MP2400 Acts as Slave (automatic receive function is used)	6-39
6.4.2 When the MP2400 Acts as Master (I/O message communication function is used)	6-46

6.1 Communication Methods

The following table provides the appropriate mode of communication for each remote device and purpose.

Remote Equipment	Purpose	Communication Method	Remarks
Other MP Series	When other MP series equipment reads/writes the coil state or register content of MP2400	Uses the Extended MEMOBUS communication protocol. The remote equipment (master) side creates a ladder program using a MSG-SND function. The MP2400 (slave) side uses an automatic receive function. (You do not need to create a ladder program.) ⇒ Refer to 6.2.1 <i>When the MP2400 Acts as Slave (automatic receive function is used)</i>	MP2400 can communicate with only one master using the automatic receive function.
	When MP2400 reads/writes the coil state or register content of other MP series equipment	Uses the Extended MEMOBUS communication protocol. The MP2400 (master) side uses an I/O message communication function. (You do not need to create a ladder program.) The remote equipment (slave) side creates a ladder program using a MSG-RCV function. ⇒ Refer to 6.2.2 <i>When MP2400 Acts as Master (I/O message communication function is used)</i>	Only the holding register (M register) is capable of reading/writing using an I/O message communication function. It can communicate with only one slave.
Touch Panel	When a touch panel reads/writes the coil state or register content of MP2400	Uses the Extended MEMOBUS communication protocol. Set the protocol for the touch panel side to the Extended MEMOBUS protocol. The MP2400 (slave) side uses an automatic receive function. (You do not need to create a ladder program.) ⇒ Refer to 6.3 <i>Communication with Touch Panel.</i>	
PLC Manufactured by Mitsubishi Electric Corporation	When a PLC Manufactured by Mitsubishi Electric Corporation reads/writes the MP2400 register content.	Uses the MELSEC communication protocol. The remote equipment (master) side creates a ladder program using a BUFSND function. The MP2400 (slave) side uses an automatic receive function. (You do not need to create a ladder program.) ⇒ Refer to 6.4.1 <i>When the MP2400 Acts as Slave (automatic receive function is used)</i>	The MP2400 can communicate with only one master when using the automatic receive function.
	When an MP2400 reads/writes the relay state or register content of PLC Manufactured by Mitsubishi Electric Corporation.	Uses the MELSEC communication protocol. The MP2400 (master) side uses an I/O message communication function. (You do not need to create a ladder program.) The remote equipment (slave) side needs to set the network parameters. (You do not need to create a ladder program.) ⇒ Refer to 6.4.2 <i>When the MP2400 Acts as Master (I/O message communication function is used)</i>	The MP2400 can communicate with only one slave when using the I/O message communication function.

6.2 Communication with Other MP Series

When Ethernet communication is carried out between the MP2400 and other MP series, the Extended MEMOBUS protocol is used as a communication protocol. The Extended MEMOBUS protocol allows the master to read/write the slave register contents.

This chapter explains communications when an MP2400 acts as a slave and a master respectively.

When the MP2400 acts as a slave, this chapter explains communications using an automatic receive function.

When the MP2400 acts as a master, this chapter explains communications using an I/O message communication function.

6.2.1 When the MP2400 Acts as Slave (automatic receive function is used)

This section explains how to communicate with the MP2300 message transmit function (MSG-SND) using the MP2400 automatic receive function.





Fig. 6.1 Message Flow with MP2300 when Automatic Receive Function Is Used

■ Setting Example

The following figure illustrates how the content of the MP2300 (master) holding register (MW00000 to MW00099) is written into the MP2400 (slave) holding register (MW00000 to MW00099).




The setup procedure is explained in the following pages.


(1) How to Set up the MP2400 Side

If the setting of transmission parameters (IP address, subnet mask) is already completed, start from step 3.

1. Double-click the **218IFA** Cell in the Module Configuration Definition Window.



2. Set transmission parameters.




How to set up transmission parameters

- ① Set **IP Address** (to “192.168.001.001,” for example).
- ② Set **Subnet Mask** (to “255.255.255.000,” for example).
- ③ Set **Gateway IP Address** (to “000.000.000.000,” for example).


Caution

Set up a unique IP address in the network.
For the IP address, check with your network administrator.

3. Click the **Easy setting** Button in the **Message Communication** area of the Connection Parameter.



4. Set a communication setting in the **Message Communication Easy Setting** Window.



■ How to set up in the **Message Communication Easy Setting** Window

- ① When automatic receive is used, select “1” for the **Connect No.**
- ② Set **Port No.** of the MP2400 side (“10001,” for example).
- ③ Select **Extended MEMOBUS** for the **Communication Protocol Type**, and click **Default** Button.
- ④ Select **Connect Type** (TCP, for example).
- ⑤ Select **Code** (BIN, for example).
- ⑥ Set **Node Port IP Address** for the other device (MP2300) to be connected (to “192.168.001.002,” for example).
- ⑦ Set **Port No.** of the other device (MP2300) to be connected (to “10001,” X for example).
- ⑧ Click **OK** Button.

5. Click **Yes** in the confirmation dialog of the parameter setting.

■ **Caution**

Note that when a parameter with the same connection number is already set and you click **Yes** in the confirmation dialog of the parameter setting, the setting will be overwritten by the parameter configured in the **Message Communication Easy Setting** Window.

6. Check the setting value and double-click the **Setting** Button of the **Detail** area.

CNO	Local Port	Node IP Address	Node Port	Connect Type	Protocol Type	Code	Detail
01	10001	192.168.001.002	10001	TCP	Extended MEMOBUS	BIN	Setting
02	-----						Setting
03	-----						Setting
04	-----						Setting

7. Click **Enable** in the **Automatically Reception** Tab and then click the **OK** Button.

Detail Setting

Automatically Reception

☐ Disable Unable to automated reception, when the protocol type is no control sequence.

☒ **Enable**

Transmission Buffer Channel: 1 The automatic reception is fixed 1ch.

Slave I/F Register Settings

Head REG

Readout of Input Relay: IW00000

Readout of Input Register: IW00000

Readout / Write-in of Coil: MW00000

Readout / Write-in of Hold Register: MW00000

Write - in width of Coil/Hold Register: LQ: MW00000, HZ: MW65534

Automatic input processing delay time: 0 ms (0-100)

The influence on a low-speed scanning can be adjusted according to this parameter.
[Attention] It is not in the setting of the communication period of an automatic reception.

OK Cancel

Note: For more information on Slave Side I/F Register Settings and Automatic input precessing delay time, refer to 2.2.4 (4) (b) ■ **Automatic Receive Setting Screen for Message Communication** on page 2-21.

Now, the automatic receive function is set up when the MP2400 acts as a slave.


■ **Caution**

When any transmission or connection parameter is changed, the change will be reflected after FLASH has been saved and the power is turned ON again.


(2) How to Set up the Remote Device (MP2300) to Be Connected

If the setting of transmission parameters (IP address, subnet mask) is already completed, start from step 3.

1. Double-click the **218IF** Cell in the Module Configuration Definition Window.



2. Set transmission parameters.



■ How to set up transmission parameters

- ① Set **IP Address** ("192.168.001.001," for example).
- ② Select **Edit - Local Port: TCP/IP Setting** in the Detail Definition Window.
- ③ Set **Subnet Mask** ("255.255.255.000," for example).
- ④ Set **Gateway IP Address** ("000.000.000.000," for example).

■ Caution

Set up a unique IP address in the network.
For the IP address, check with your network administrator.

3. Set connection parameters.

CNO	Local Port	Node IP Address	Node Port	Connect Type	Protocol Type	Code	Detail
01	10001	192.168.001.001	10001	TCP	Extended MEMOBUS	BIN	Setting
02	10002	192.168.001.001	10002	TCP	Extended MEMOBUS	BIN	Setting
03	10003	192.168.001.001	10003	TCP	Extended MEMOBUS	BIN	Setting
04	-----						Setting
05	10005	192.168.001.001	10005	TCP	Extended MEMOBUS	BIN	Setting
06	10006	192.168.001.001	10006	TCP	Extended MEMOBUS	BIN	Setting
07	-----						Setting
08	-----						Setting
09	-----						Setting
10	-----						Setting
11	-----						Setting
12	-----						Setting
13	-----						Setting

■ How to set up with a connection number 01 in the connection parameter setting screen

- ① Set **Local Port** to the port number used in the MP2300 side ("10001," for example).
- ② Set **Node IP Address** to the IP address configured in the MP2400 side.
- ③ Set **Node Port** to the port number configured in the MP2400 side ("10001," for example).
- ④ Select **Connect Type** (TCP, for example).
- ⑤ Select **Extended MEMOBUS** for **Protocol Type**.
- ⑥ Select **Code** (BIN, for example).

■ Caution

When any transmission or connection parameter is changed, the change will be reflected after FLASH has been saved and the power turned ON again.

4. Create a ladder program with a message transmit function (MSG-SND).

A ladder program for transmitting messages to/from the remote equipment (MP2300) side is shown as follows:

■ Message transmit function (MSG-SND)

Required for transmitting messages. Message transmission is carried out by describing and executing this message transmit function in a ladder program.

Communication device = Ethernet(218IF)
 Protocol type
 Circuit number = 1
 Communication buffer channel number
 Parameter list start address = DA00000

MSG-SND	
[B] Execute	DB000200
[B] Busy	DB000210
[B] Abort	DB000201
[B] Complete	DB000211
[W] Dev-Typ	00006
[B] Error	DB000212
[W] Pro-Typ	00001
[W] Cir-No	00001
[W] Ch-No	00001
[A] Param	DA00000

Module Configuration
 File Save to project Edit Setting Online Read Write Self Configuration All modules

Module	Function Module/Slave	Status	Circuit No./Axis Address	
			Start	Assigned circuit
01 [MP2300] : ---				
00 [MP2300] [Driving]	01 CPU	Driving	---	---
	02 IO	Driving	---	1
	03 [SVB]	Driving	Circuit No1	1
	04 [SVR]	Driving	Circuit No2	1
01 [218IF-01] [Driving]	01 217IF	Driving	Circuit No1	1
	02 218IF	Driving	Circuit No1	1
02 -- UNDEFINED --[-----]				

Communication device = 218IF
 Circuit number = 1

Fig. 6.2 MPE720 Module Configuration Definition Window

■ Input/output definitions for message transmit functions

The input/output definitions for the message transmit function are explained as follows:

Table 6.1 Input/Output Definitions for Message Transmit Functions

I/O Definition	No.	Name	Setting Example	Explanation
Input Item	1	Execute	DB000200	Executes a transmission When the Execute bit is ON, the message is transmitted.
	2	Abort	DB000201	Aborts a transmission When the Abort bit is ON, the message transmission is forcibly stopped.
	3	Dev-Typ	00006	Communication device type Specify the type of the communication device used in transmission. When Ethernet (218IF) is used, specify "6".
	4	Pro-Typ	00001	Communication protocol Specify the type of the communication protocol. MEMOBUS(*1) = 1, non-procedure 1(*2) = 2, non-procedure 2(*2) = 3
	5	Cir-No	00001	Circuit number Specify the circuit number of the communication device. Specify it in accordance with the circuit number displayed in the MPE720 Module Configuration Definition Window.
	6	Ch-No	00001	Communication buffer channel number Specify the channel number of the communication buffer. When Ethernet (218IF) is used, specify it in the range between "1" and "10". * Set up a unique channel number in the circuit.
	7	Param	DA00000	Parameter list start address Specify the start address of the parameter list. For the Parameter List, 17 words are automatically assigned from the configured address.
Output Item	1	Busy	DB000210	In process Busy is turned ON while executing a message transmission or forced abort process.
	2	Complete	DB000211	Process completed When a message transmission or abort process is properly completed properly, Complete will turn ON only for one scan.
	3	Error	DB000212	Error occurred When an error occurs, the Error bit will turn ON only for one scan.

* 1. When transmitting in MEMOBUS, Extended MEMOBUS, MELSEC, or MODBUS/TCP protocol, set the communication protocol (Pro-Typ) to MEMOBUS(=1). The communication device automatically converts the protocol.

* 2. Non-procedure 1: In non-procedural communications, data is transmitted on a per-word basis.
Non-procedure 2: In non-procedural communications, data is transmitted on a per-byte basis.

■ Parameter list setting example for the message transmit function

An example of a parameter list setting when writing 100 words of data from MW00000 to the destination using the connection with a connection number = 1 follows:


Table 6.2 Sample Parameter List Setting (parameter list start address Param=DA00000)

Register Number	Setting Value	Parameter Number	IN/OUT	Remarks
DW00000	—	PARAM00	OUT	Process result
DW00001	—	PARAM01	OUT	Status
DW00002	00001	PARAM02	IN	Connection number = 1
DW00003	—	PARAM03	IN	Option (Setting unnecessary)
DW00004	000BH	PARAM04	IN	Function code = 0BH (Writes to holding register)
DW00005	00000	PARAM05	IN	Data address = 0 (Starting from MW00000)
DW00006	00100	PARAM06	IN	Data size = 100 (100 words)
DW00007	00001	PARAM07	IN	Remote CPU number = 1
DW00008	00000	PARAM08	IN	Coil offset = 0 word
DW00009	00000	PARAM09	IN	Input relay offset = 0 word
DW00010	00000	PARAM10	IN	Input register offset = 0 word
DW00011	00000	PARAM11	IN	Holding register offset = 0 word
DW00012	—	PARAM12	SYS	Reserved by the system. (Zero clear at startup)
DW00013	—	PARAM13	SYS	Reserved by the system.
DW00014	—	PARAM14	SYS	Reserved by the system.
DW00015	—	PARAM15	SYS	Reserved by the system.
DW00016	—	PARAM16	SYS	Reserved by the system.

Note: N: Input, OUT: Output, SYS: For system use


■ Example of Using the Message Transmit Function in a Ladder Program

Here is one example of the message transmit function through Ethernet (218IF).



6.2 Communication with Other MP Series

6.2.1 When the MP2400 Acts as Slave (automatic receive function is used)



The communication setting and the ladder program creation are now finished, when MP2300 acts as a master.

(3) How to Start Communications

1. The MP2400 side starts to receive the messages.

When the automatic receive function is used, the message receive operation starts automatically.

2. Turn Execute ON for the message transmit function in the MP2300 side to transmit messages.


Messages are transmitted by turning ON the register (DB000200, for example), configured in Execute of the message transmit function, starting communication with the MP2400.

Table 6.3 Input/Output Definition for Message Transmit Function

I/O Definition	No.	Name	Setting Example	Content
Input Item	1	Execute	DB000200	Executes a transmission When Execute is ON, the message transmission will be carried out.

The sample ladder program is created to transmit a message every one second when five seconds have elapsed after the low-speed scan (or high-speed scan) startup.

To change the message transmission interval, change the timer value ①.



6.2.2 When MP2400 Acts as Master (I/O message communication function is used)

This section explains how to communicate with the MP2300 message receive function (MSG-RCV) using the MP2400 I/O message communication function.





Fig. 6.3 Message Flow with MP2300 when I/O Message Communication Function Is Used

■ I/O Message Communication

I/O message communication implements out 1:1 communication.
In addition, you can read and write only the holding register in the case of “Communication Protocol Type: Extended MEMO-BUS” used in the communication with MP series.

■ Setting Example

The following figure illustrates one example of reading the contents of the holding register (MW00200 to MW00299) of MP2300 (slave) into an input register (IW0000 to IW0063) of MP2400 (master) and writing the contents of an output register (OW0064 to OW00C7) of MP2400 (master) into a holding register (MW00300 to MW00399) of MP2300 (slave).




The particular setup procedure is explained in the subsequent pages.


(1) How to Set up the MP2400 Side

If the setting of transmission parameters (IP address, subnet mask) is already completed, start from step 3.

1. Double-click the **218IFA** Cell in the Module Configuration Definition Window.



2. Set transmission parameters.




How to set up transmission parameters

- ① Set **IP Address** ("192.168.001.001," for example).
- ② Set **Subnet Mask** ("255.255.255.000," for example).
- ③ Set **Gateway IP Address** ("000.000.000.000," for example).


Caution

Set up a unique IP address in the network.
For the IP address, check with your network administrator.

3. Click the **Easy setting** Button in the **Message Communication** area of the Connection Parameter.



4. Set a communication setting in the **I/O Message Communication Easy Setting** Window.



■ How to set up in the **I/O Message Communication Easy Setting** Window

- ① Set **Port No.** of the MP2400 side (“10005, 10006,” X for example).
- ② Select **Extended MEMOBUS** for **Communication Protocol Type**, and click the **Default** Button.

■ Caution

When the communication protocol is Extended MEMOBUS, the register type that can select both read and write is fixed at the Holding Register (MW).

- ③ Select **Connect Type** (TCP, for example).
- ④ Select **Code** (BIN, for example).
- ⑤ Set **Remote IP Address** for the other device (MP2300) to be connected (“192.168.001.002,” for example).
- ⑥ Set **Port No.** of the other device (MP2300) to be connected (“10005, 10006,” for example).

■ Caution

In I/O message communication, as a message is transmitted from each port number for register read/write, a connected remote device needs the message receive functions to receive two messages.

6.2.2 When MP2400 Acts as Master (I/O message communication function is used)

- ⑦ Set a storage area (**Input Reg**) of data read by MP2400 (IW0000, for example).
- ⑧ Set the **Read Size** of data to be the read by the MP2400 (“100” W, for example).
- ⑨ Set a storage area (**Output Reg**) of data written by the MP2400 (OW0064, for example).
- ⑩ Set the **Write Size** of data written by the MP2400 (“100” W, for example).
- ⑪ Set an I/O data update timing (**Data update timing**) for CPU and built-in Ethernet (“Low” scan, for example).

■ Data Update Timing

Data update timing indicates when to send and receive data between the CPU and built-in Ethernet. Communication with the remote device is carried out asynchronously, so note that a message is not necessarily transmitted to the remote equipment at each set data update time.

- ⑫ Set the register type and start address (**Read Reg**) of the remote device (MP2300) read by the MP2400 (“MW00200,” for example).
- ⑬ Set the register type and start address (**Write Reg**) of the remote device (MP2300) written by the MP2400 (“MW00300,” for example).
- ⑭ Click **OK**.

5. Click **Yes** in the parameter setting confirmation window.

■ Caution

Note that when a parameter with the same connection number is already set and you click **Yes** in the parameter setting confirmation window, the setting will be overwritten by the parameter configured in the **Message Communication Easy Setting** Window.

6. Check the setting values.

I/O Message Communication

☐ Disable
☒ Enable

Easy setting It is possible to set easily that communicate the I/O message.

Data update timing Low Scan

Read/Write	Local Port	Node IP Address	Node Port	Connect Type	Protocol Type	Code	Detail
Read	10005	192.168.001.002	10005	TCP	Extended MEMOBUS	BIN	Setting
Write	10006	192.168.001.002	10006	TCP	Extended MEMOBUS	BIN	Setting

MP2400

input disable ☐ Head register number IW00000 data size 100 W <- Hold register(MW) 00200 100 W

output disable ☐ Head register number OW00064 data size 100 W -> Hold register(MW) 00300 100 W

Node equipment ☐

The I/O message communication is now set up, when MP2400 acts as a master.


■ Caution

When any transmission or connection parameter is changed, the change will be not reflected after FLASH has been saved and the power supply is turned ON again.


(2) How to Set up the Remote Device (MP2300) to Be Connected

When the setting of transmission parameters (IP address, subnet mask) is already completed, start from step 3.

1. Double-click the **218IF** Cell in the Module Configuration Definition Window.



2. Set transmission parameters.



■ How to set up transmission parameters

- ① Set **IP Address** (“192.168.001.001”, for example).
- ② Select **Edit - Local Port: TCP/IP Setting** in the Detail Definition Window.
- ③ Set **Subnet Mask** (“255.255.255.000”, for example).
- ④ Set **Gateway IP Address** (“000.000.000.000”, for example).

■ Caution

Set up a unique IP address in the network.
For the IP address, check with your network administrator.

3. Set connection parameters.

The screenshot shows the 'CP-218 Connection Parameter' window. It contains a table with columns: CNO, Local Port, Node IP Address, Node Port, Connect Type, Protocol Type, Code, and Detail. Red circles and arrows highlight the following settings:

- ① Local Port: 10001
- ② Node IP Address: 192.168.001.001
- ③ Node Port: 10003
- ④ Connect Type: TCP
- ⑤ Protocol Type: Extended MEMOBUS
- ⑥ Code: BIN

Connections 05 and 06 are circled in red, showing identical settings: Local Port 10005/10006, Node IP Address 192.168.001.001, Node Port 10005/10006, Connect Type TCP, Protocol Type Extended MEMOBUS, and Code BIN.

CNO	Local Port	Node IP Address	Node Port	Connect Type	Protocol Type	Code	Detail
01	10001	192.168.001.001	10001	TCP	Extended MEMOBUS	BIN	Setting
02	10002	192.168.001.001	10002	TCP	Extended MEMOBUS	BIN	Setting
03	10003	192.168.001.001	10003	TCP	Extended MEMOBUS	BIN	Setting
04	-----	-----	-----	-----	-----	-----	Setting
05	10005	192.168.001.001	10005	TCP	Extended MEMOBUS	BIN	Setting
06	10006	192.168.001.001	10006	TCP	Extended MEMOBUS	BIN	Setting
07	-----	-----	-----	-----	-----	-----	Setting
08	-----	-----	-----	-----	-----	-----	Setting
09	-----	-----	-----	-----	-----	-----	Setting
10	-----	-----	-----	-----	-----	-----	Setting
11	-----	-----	-----	-----	-----	-----	Setting
12	-----	-----	-----	-----	-----	-----	Setting
13	-----	-----	-----	-----	-----	-----	Setting

■ How to set up in the CP-218 Connection Parameter Window with connection numbers 05, 06

- ① Set **Local Port** (the port number “10005, 10006” used in the MP2300 side, for example).
- ② Set **Node IP Address** (the IP address “192.168.001.001” configured in the MP2400 side, for example).
- ③ Set **Node Port** (the port number “10005, 10006” configured in the MP2400 side, for example).
- ④ Select **Connect Type** (TCP, for example).
- ⑤ Select **Extended MEMOBUS** for **Protocol Type**.
- ⑥ Select **Code** (BIN, for example).

■ Caution

When any transmission or connection parameter is changed, the change will be reflected after FLASH has been saved and the power supply is turned ON again.


4. Create a ladder program with a message receive function (MSG-RCV) in it.

An example of a ladder program for receiving messages in the remote equipment (MP2300) side follows:

■ Message receive function (MSG-RCV)

Required for receiving messages. Message reception is carried out by inputting and executing this message receive function in a ladder program.

In addition, in order to support Read and Write by MP2400, two message receive functions should be provided. Here, the input item and parameters (Communication buffer channel number and Connection number) of the message receive function need to accord with the MP2400 side settings.



Note: Similarly, a message receive function with the communication buffer channel number = 6 is required.




Fig. 6.4 MPE720 Module Configuration Definition Window

■ Input/output definition contents for message receive functions

The input/output definition content for message receive function is as follows:

Table 6.4 Input/Output Definitions for Message Receive Functions

I/O Definition	No.	Name	Setting Example	Content
Input Item	1	Execute	DB000200	Executes a reception When Execute is ON, message reception is carried out.
	2	Abort	DB000201	Forcibly aborts a reception When Abort is ON, the message reception is forcibly stopped.
	3	Dev-Typ	00006	Communication device type Specify the type of the communication device used in reception. When Ethernet (218IF) is used, specify "6."
	4	Pro-Typ	00001	Communication protocol Specify the type of the communication protocol. MEMOBUS(*1) = 1, non-procedure 1(*2) = 2, non-procedure 2(*2) = 3
	5	Cir-No	00001	Circuit number Specify a circuit number of the communication device. Specify it in accordance with the circuit number displayed in the MPE720 Module Configuration Definition Window.
	6	Ch-No	00005 & 00006	Communication buffer channel number Specify the channel number of a communication buffer. When Ethernet (218IF) is used, specify it in the range between "1" and "10." * Set up a unique channel number in the line.
	7	Param	DA00000	Parameter list start address Specify the start address of the parameter list. For the Parameter List, 17 words are automatically assigned from the configured address.
Output Item	1	Busy	DB000210	In process Busy will be ON while executing a message reception or forced abort process.
	2	Complete	DB000211	Process completed When a message reception or forced abort process is properly completed, Complete will turn ON only for one scan.
	3	Error	DB000212	Error When an error occurs, Error will turn ON only for one scan.

* 1. When transmitting in MEMOBUS, Extended MEMOBUS, MELSEC, or MODBUS/TCP protocol, set the communication protocol (Pro-Typ) to MEMOBUS (=1). The communication device automatically converts the protocol.

* 2. Non-procedure 1: In non-procedural communication, data is received on a per-word basis.
Non-procedure 2: In non-procedural communication, data is received on a per-byte basis.

■ Parameter list setting example for message receive function

An example of a parameter list setting when receiving messages from a transmit source using the connection with connection numbers = 5 and 6 follows:

Table 6.5 Parameter List Setting Example 1 (parameter list start address Param = DA00000)

Register Number	Setting Value	Parameter Number	IN/OUT	Remarks
DW00000	–	PARAM00	OUT	Process result
DW00001	–	PARAM01	OUT	Status
DW00002	00005	PARAM02	IN	Connection number = 5 (For receiving read operation)
DW00003	–	PARAM03	OUT	Option
DW00004	–	PARAM04	OUT	Function code
DW00005	–	PARAM05	OUT	Data address
DW00006	–	PARAM06	OUT	Data size
DW00007	–	PARAM07	OUT	Remote CPU number
DW00008	00000	PARAM08	IN	Coil offset = 0 word
DW00009	00000	PARAM09	IN	Input relay offset = 0 word
DW00010	00000	PARAM10	IN	Input register offset = 0 word
DW00011	00000	PARAM11	IN	Holding register offset = 0 word
DW00012	00000	PARAM12	IN	Writable address lower limit = MW00000
DW00013	65534	PARAM13	IN	Writable address upper limit = MW65534
DW00014	–	PARAM14	SYS	Reserved by the system. (Zero clear at startup)
DW00015	–	PARAM15	SYS	Reserved by the system.
DW00016	–	PARAM16	SYS	Reserved by the system.

Note: N: Input, OUT: Output, SYS: For system use


Table 6.6 Parameter List Setting Example 2 (parameter list start address Param = DA00000)

Register Number	Setting Value	Parameter Number	IN/OUT	Remarks
DW00000	–	PARAM00	OUT	Process result
DW00001	–	PARAM01	OUT	Status
DW00002	00006	PARAM02	IN	Connection number = 6 (For receiving write operation)
DW00003	–	PARAM03	OUT	Option
DW00004	–	PARAM04	OUT	Function code
DW00005	–	PARAM05	OUT	Data address
DW00006	–	PARAM06	OUT	Data size
DW00007	–	PARAM07	OUT	Remote CPU number
DW00008	00000	PARAM08	IN	Coil offset = 0 word
DW00009	00000	PARAM09	IN	Input relay offset = 0 word
DW00010	00000	PARAM10	IN	Input register offset = 0 word
DW00011	00000	PARAM11	IN	Holding register offset = 0 word
DW00012	00000	PARAM12	IN	Writable address lower limit = MW00000
DW00013	65534	PARAM13	IN	Writable address upper limit = MW65534
DW00014	–	PARAM14	SYS	Reserved by the system. (Zero clear at startup)
DW00015	–	PARAM15	SYS	Reserved by the system.
DW00016	–	PARAM16	SYS	Reserved by the system.


Note: N: Input, OUT: Output, SYS: For system use


■ Example of Using the Message Receive Function in a Ladder Program

Here is one example of using the message receive function through Ethernet (218IF). In addition, this ladder program is for receiving read operation. A ladder program for receiving write operations is required separately.



Message Receiving Ladder Program (218IF)





The communication setting and the ladder program creation are now finished, when MP2300 acts as a slave.

(3) How to Start Communication

1. The MP2300 side starts to receive the messages.

As the sample ladder program starts the message receive operation just after the system startup, you are not required to do anything. In normal operation, accept the default.

2. The MP2400 side transmits messages.

When an I/O message communication function is used, message transmit operation status automatically.

6.3 Communication with Touch Panel

This section explains how to communicate with a touch panel supporting for the Extended MEMOBUS protocol using the MP2400 automatic receive function.
In this section, GP3000 series manufactured by Digital Electronics Corp. is used as a touch panel supporting for the Extended MEMOBUS protocol.

6.3.1 When MP2400 Acts as Slave





Fig. 6.5 Message Flow with Touch Panel (GP3000 series) when Automatic Receive Function Is Used


■ Setting Example

The following figure shows an example which displays the content of the MP2400 (slave) holding register (MW00100) on a touch panel and writes values from the touch panel to the same register.




(1) How to Set up the MP2400 Side

1. Double-click the **218IFA** Cell in the Module Configuration Definition Window.



2. Set transmission parameters.




How to set up transmission parameters

- ① Set **IP Address** ("192.168.001.001," for example).
- ② Set **Subnet Mask** ("255.255.255.000," for example).
- ③ Set **Gateway IP Address** ("000.000.000.000," for example).


Caution

Set up a unique IP address in the network.
For the IP address, check with your network administrator.

3. Click the **Easy setting** Button in the **Message Communication** area of the Connection Parameter.



4. Set a communication setting in the **Message Communication Easy Setting** Window.



■ How to set up in the **Message Communication Easy Setting** Window


- ① When automatic receive is used, select "1" for the **Connect No.**
- ② Set **Port No.** of MP2400 side ("10001," for example).
- ③ Select **Extended MEMOBUS** for **Communication Protocol Type**, and click the **Default** Button.
- ④ Select **Connect Type** (TCP, for example).
- ⑤ Select **Code** (BIN, for example).
- ⑥ Set **Node Port IP Address** for the other device (touch panel) to be connected ("192.168.001.002," for example).
- ⑦ Set **Port No.** of the other device (touch panel) to be connected ("10001," for example).
- ⑧ Click **OK**.

5. Click **Yes** in the parameter setting confirmation dialog box.


■ **Caution**

Note that when a parameter with the same connection number is already set and you click **Yes** in the parameter setting confirmation dialog, the setting will be overwritten by the parameter configured in the **Message Communication Easy Setting** Window.

6. Check the setting value and double-click the **Setting** Button in the **Detail** column.



7. Check **Enable** in the **Automatically Reception** Tab and then click the **OK** Button.



Note: For more information on Slave Side I/F Register Setting and Automatic Receive Process Delay Time, refer to 2.2.4 (4) (b) ■ **Automatic Receive Setting Screen for Message Communication** on page 2-21. The automatic receive function for connecting the MP2400 to the touch panel is now set up.

■ **Caution**

When any transmission or connection parameter is changed, the change will be reflected after FLASH has been saved and the power supply is turned ON again.

(2) How to set up a touch panel

This section explains the GP-Pro EX side set up procedure for connecting the MP2400 to an indicator (GP3000 series) and the screen creation example.

Note: The indicator (GP3000 series) and GP-Pro EX are manufactured by Digital Electronics Corp. Contact Digital Electronics Corp. for more information.

[a] How to Set up GP-Pro EX

1. Start up GP-Pro EX.
2. Create a new project.
3. Set its indicator type. Set the indicator type in accordance with the model in use.

Here, we explain the setting when AGP-3600T is used.

Table 6.7 Indicator Type Setting (example)

Series	GP3000 series
	AGP33** series
Model	AGP-3600T
Installation Method	Horizontal model

4. Set up connected equipment.

Table 6.8 Connected Equipment

Manufacturer	YASKAWA Electric Corporation
Series	MEMOBUS Ethernet

5. Set up the way to connect.

Table 6.9 Connection Method

Port	Ethernet (TCP)
------	----------------

6. Select the **Connected Equipment Setting** from the **System** Tab to display the connected equipment setting screen.
7. Set the communication setting.

Table 6.10 Communication Setting

Port Number*	10001
Timeout	3(sec)
Retry	0
Transmit Weight	0(ms)

* For more information on the port number, refer to the following.

■ Port Number

- If you don't check Automatic Assignment of the port number in the communication setting screen, the automatic assignment will be disabled, and the GP3000 series port number will be fixed at the setting value.
- If you check Automatic Assignment of the port number in the communication setting screen, automatic assignment will be enabled, and the GP3000 series port number will be assigned in each case.

When you use Automatic Assignment, set *Unpassive open mode* in the 2181FA screen of MPE720.

For more information about *Unpassive open mode*, refer to 2.2.4 (b) *2181FA Module Detail Definition Window* on page 2-15.

For information on the relationship between GP-Pro EX and MPE720 settings, see the table below.

MPE720 Side Setting \ GP-Pro EX Side Setting	Unpassive open Mode	Fixed Value Setting
Automatic Assignment Enable	√	—
Automatic Assignment Disable	√	√

Note: √: connectable, —: unconnectable

- How to set up *Unpassive open mode* of the MP2400 (reference)
Set **Node IP Address** to 000.000.000.000 and the **Node Port** to 0 to enter into the *Unpassive open mode*.

Transmission Parameters

IP Address : 192 . 168 . 1 . 1 (0-255) Module Name Definition
 Subnet Mask : 255 . 255 . 255 . 0 (0-255) Equipment name : CONTROLLER NAME
 Gateway IP Address : 0 . 0 . 0 . 0 (0-255)

Connection Parameter

Message Communication

It is possible to following parameter setting easily that communicate the message.

CNO	Local Port	Node IP Address	Node Port	Connect Type	Protocol Type	Code	Detail
01	10001	000.000.000.000	00000	CP	Extended MEMOBUS	BIN	Setting
02	-----						Setting
03	-----						Setting
04	-----						Setting

Cannot the overlap to local station port number used by the communicate the I/O message.

8. Click the setup button of the connected PLC1 for each device setting to display the setting screen for each device.
9. Set up the setting screen for each device.

In the setting screen for each device, set up a connected device (in this case, the MP2400).

Set the IP address, port number and data code in the same manner as the 218IFA screen of the MP2400.

Table 6.11 Each Device Setting

IP Address	192.168.001.001
Port Number	10001
Data Code	binary

- 218IFA screen (reference)

The screenshot shows the 218IFA configuration screen. The 'Transmission Parameters' section has fields for IP Address (192.168.1.1), Subnet Mask (255.255.255.0), and Gateway IP Address (0.0.0.0). The 'Module Name Definition' section shows 'Equipment name' as 'CONTROLLER NAME'. The 'Connection Parameter' section includes a table for message communication settings.

CNO	Local Port	Node IP Address	Node Port	Connect Type	Protocol Type	Code	Detail
01	10001	192.168.001.002	10001	TCP	Extended MEMOBUS	BIN	Setting
02							Setting
03							Setting
04							Setting

The setting is finished for now.

Create a screen and transfer the project to an indicator as required.


■ Caution

- Set up a unique IP address in the network.
The MP2400 side IP address is set to "192.168.1.1" in self-configuration.
For the IP address, check with your network administrator.


Note: Set the GP3000 series IP address in the off-line mode of the indicator.
Contact Digital Electronics Corp. for more information.

[b] Screen Creation Example

1. Create a base screen.
2. Select Data Indicator from the toolbar to paste it on the screen.



3. Double-click the Data Indicator pasted on the screen.



4. Set as follows in the detailed setting screen of Data Indicator and click OK.

Table 6.12 Data Indicator Detailed Setting

Display Data	Numeric display
Monitor Word Address	GMW00100

■ Relationship between GP-Pro EX address display and MP2400 register

Device	GP-Pro EX Address Display	MP2400 Register
Coil (bit)	GMB□□□□□□	MB□□□□□□
Coil (word)	GMW□□□□□	MW□□□□□
Input Relay (bit)	GIB□□□□□	IB□□□□□
Input Relay (word)	GIW□□□□	IW□□□□

(3) How to Start Communication

- 1.** The MP2400 side starts to receive the messages.

When the automatic receive function is used, the message receive operation starts automatically, and you are not required to do anything.

- 2.** Start up the touch panel (GP3000 series) to display the main screen.

After the system startup of the touch panel, communication with MP2400 will start.

Note: Contact Digital Electronics Corp. for more information.

6.4 Communication with PLC Manufactured by Mitsubishi Electric Corporation (MELSEC protocol)

In Ethernet communication between the MP2400 and MELSEC (Q, A series) general-purpose PLC manufactured by Mitsubishi Electric Corporation, the MELSEC protocol (MELSEC ACPU common command) is used as a communication protocol.

Using the MELSEC protocol allows a master to read/write the slave register content.

This chapter explains communication when the MP2400 acts as a slave and a master respectively.

For using the MP2400 as a slave, we explain communication using the automatic receive function.

For using the MP2400 as a master, we explain communication using the I/O message communication function.

6.4.1 When the MP2400 Acts as Slave (automatic receive function is used)

This section explains how to carry out a fixed buffer communication with the BUFSND command (with procedure) of the MELSEC Q series using the MP2400 automatic receive function.





Fig. 6.6 Message Flow with the MELSEC Q Series when the Automatic Receive Function Is Used

■ Caution

Communication using the automatic receive function is 1:1 communication.
Also, when “Communication Protocol Type: MELSEC” is used in communication with the MELSEC Q series, the MELSEC Q series (master) side can read/write the holding register of the MP2400 (slave) using fixed buffer communication.
However, when the MP2400 acts as a slave, you cannot use the inter-CPU or random access communication, because of the MELSEC specifications.

■ Setting Example

The following figure illustrates one example of writing the contents of the data register (D00201 to D00300) of MELSEC Q series (master) into the MP2400 (slave) holding register (MW00000 to MW00099).




The particular setup procedure is explained in the subsequent pages.


(1) How to Set up the MP2400 Side

If the setting of transmission parameters (IP address, subnet mask) is already completed, start from step 3.

1. Double-click the **218IFA** Cell in the Module Configuration Definition Window.



2. Set transmission parameters.




■ How to set up transmission parameters

- ① Set **IP Address** ("192.168.001.001," for example).
- ② Set **Subnet Mask** ("255.255.255.000," for example).
- ③ Set **Gateway IP Address** ("000.000.000.000," for example).


■ Caution

Set up a unique IP address in the network.
For the IP address, check with your network administrator.

3. Click the **Easy setting** Button in the **Message Communication** area of the **Connection Parameter**.



4. Set up the communication settings in the **Message Communication Easy Setting** Window.



■ How to set up in the **Message Communication Easy Setting** Window


- ① When automatic receive is used, select “1” for the **Connect No.**
- ② Set **Port No.** of MP2400 side (“10001,” for example).
- ③ Select **MELSEC** for **Communication Protocol Type**, and click the **Default** Button.
- ④ Select **Connect Type** (TCP, for example).
- ⑤ Select **Code** (BIN, for example).
- ⑥ Set **Node port IP Address** for the other device (MELSEC Q series) to be connected (“192.168.001.002,” for example).
- ⑦ Set **Port No.** of the other device (MELSEC Q series) to be connected (“10001,” for example).
- ⑧ Click **OK**.

5. Click **Yes** in the parameter setting confirmation dialog box.


■ **Caution**

Note that when a parameter with the same connection number is already set and you click **Yes** in the parameter setting confirmation dialog, the setting will be overwritten by the parameter configured in the **Message Communication Easy Setting** Window.

6. Check the setting value and double-click the **Setting** Button in the **Detail** column.



7. Click **Enable** in the **Automatically Reception** Tab and then click the **OK** Button.



Note: For more information on Slave Side I/F Register Setting and Automatic Receive Process Delay Time, refer to 2.2.4 (4) (b) ■ **Automatic Receive Setting Screen for Message Communication** on page 2-21.

The automatic receive function is now set up, when MP2400 acts as a slave.

■ **Caution**

When any transmission or connection parameter is changed, the change will be reflected after FLASH has been saved and the power supply is turned ON again.

(2) How to Set up the Remote Device (MELSEC Q series) to Be Connected

This section explains the MELSEC Q series side procedure to set up for connecting the MP2400 with the MELSEC Q series.

Note: MELSEC Q series are manufactured by Mitsubishi Electric Corporation.
Contact Mitsubishi Electric Corporation for more information.

1. Start up GX Developer.
2. Create a new project.
3. Set up network parameters (MELSECNET/Ethernet).

Table 6.13 Network Parameter Setting (example)

Setting Item	Setting Details
Network Type	Ethernet
Start I/O No.	Any
Network No.	Any
Group No.	Any
Exchange Number	Any
Mode	Online

4. Set up Ethernet operation.

Table 6.14 Ethernet Operation Setting (example)

Setting Item	Setting Details
Communication Data Code Setting	Binary code communication
Initial Timing Setting	Any
IP Address	192.168.1.2
Transmit Frame Setting	Ethernet (V2.0)
TCP Alive Check Setting	Any
Permit Writing during RUN	Permitted

5. Set the open setting.

Table 6.15 Open Setting (example)

Setting Item	Setting Details (connection number=1)
Protocol	TCP
Open System	Active
Fixed Buffer	Transmit
Procedure to Communicate with Fixed Buffer	With procedure
Pairing Open	Any
Check Alive	Any
Local Port Number	2711H (10001)
Remote IP Address for Communications	192.168.1.1
Remote Port Number for Communications	2711H (10001)

■ Caution

Set up a unique IP address in the network.
For the IP address, check with your network administrator.

■ Complement

Set up an initial setting and a router relay parameter below, if needed:

- Initial setting
Set a timer relevant configuration when TCP is selected as a protocol. In most cases, accept the default.
Set up if changes such as a shortened a TCP retransmit timer are required.
 - Router relay parameter
Set up when you use a subnet mask pattern or default gateway.
-

6. Create a ladder program for communication.**■ Procedure overview to communicate using a ladder program**

- ① Use an OPEN command to establish a connection with the remote device.
- ② Use a BUFSND command to write the register content configured by parameters below to the MP2400 holding register (M register).
Setting example: When the BUFSND command is used to set the device start number for storing the transmit data to "D00200"
D00200 (transmit data length): 100W
D00201 to D00300 (transmit data): Written into MW00000 to MW00099
- ③ If necessary, use a CLOSE command to close the operation.

Note: Contact Mitsubishi Electric Corporation for more information on the ladder program.

The setting is finished for now. If necessary, transfer the settings to the PLC after setting all parameters.

(3) How to Start Communication**1. The MP2400 side starts to receive the messages.**

When an automatic receive function is used, the message receive operation starts automatically, so you are not required to do anything.

2. Use an OPEN command in the MELSEC Q series side to establish a connection with the MP2400, and use a BUFSND command to transmit messages.

When messages are transmitted from the MELSEC Q series, communication with the MP2400 will start.

6.4.2 When the MP2400 Acts as Master (I/O message communication function is used)

This section explains how to carry out the communications between CPU and the MELSEC Q series using the MP2400 I/O message communication function.




Fig. 6.7 Message Flow with MELSEC Q series when I/O Message Communication Function Is Used

■ Caution

I/O message communication is 1:1 communication.


In addition, you can read and write the registers below using inter-CPU communication when “Communication Protocol Type: MELSEC” is used in the communication with the MELSEC series.

- Bit device register - - - X, Y (read only), M, B
- Word device register - - - D, W, R

Note: A bit device register reads or writes on a per-word (16 bit) basis.

■ Setting Example


The following figure illustrates one example of reading the content of the data register (D00000 to D00099) of the MELSEC Q series (slave) into an input register (IW0000 to IW0063) of the MP2400 (master) and writing the content of an output register (OW0064 to OW00C7) of the MP2400 (master) in a data register (D00100 to D00199) of the MELSEC Q series (slave).




A particular setup procedure is explained in the subsequent pages.

(1) How to Set up the MP2400 Side

If the setting of transmission parameters (IP address, subnet mask) is already completed, start from step 3.

1. Double-click the **218IFA** Cell in the Module Configuration Definition Window.

2. Set transmission parameters.




■ How to set up transmission parameters


- ① Set **IP Address** ("192.168.001.001," for example).
- ② Set **Subnet Mask** ("255.255.255.000," for example).
- ③ Set **Gateway IP Address** ("000.000.000.000," for example).

■ Caution

Set up a unique IP address in the network.
For the IP address, check with your network administrator.

3. Click **Enable** in the **I/O Message Communication** of the connection parameter setting.

4. Set-up a communication settings in the **I/O Message Communication Easy Setting** Window.



■ How to set up in the **I/O Message Communication Easy Setting** Window

- ① Set **Port No.** of MP2400 side ("10005, 10006," for example).
- ② Select **MELSEC** for **Communication Protocol Type**, and click the **Default** Button.

■ Caution

When the communication protocol is MELSEC, the register type for the default read/write is "Word Device Register: D."

- ③ Select **Connect Type** (TCP, for example).
- ④ Select **Code** (BIN, for example).
- ⑤ Set **Node Port IP Address** for the other device (MELSEC Q series) to be connected ("192.168.001.002," for example).
- ⑥ Set **Port No.** of the other device (MELSEC Q series) to be connected ("10005, 10006," for example).

■ Caution

In I/O message communications, since a message is transmitted from each port number for register read/write, a connected remote device needs the two receive connections for receiving messages.

6.4.2 When the MP2400 Acts as Master (I/O message communication function is used)

- ⑦ Set a storage area (**Input Reg**) for data read by the MP2400 (IW0000, for example).
- ⑧ Set **Read Size** of data to be read by the MP2400 (“100” W, for example).
- ⑨ Set a storage area (**Output Reg**) for data written by MP2400 (OW0064, for example).
- ⑩ Set **Write Size** of data written by the MP2400 (“100” W, for example).
- ⑪ Set an I/O data update timing (**Data update timing**) for the CPU and built-in Ethernet (“Low” scan, for example).

■ Data Update Timing

Data update timing indicates when to give and receive data between the CPU and built-in Ethernet. Communication with the remote device is carried out asynchronously, so note that a message is not necessarily transmitted to the remote device at each data update timing.

- ⑫ Set the register type and start address (**Read Reg**) of the remote device (MELSEC Q series) read by the MP2400 (“D00000,” for example).
- ⑬ Set the register type and start address (**Write Reg**) of the remote device (MELSEC Q series) written by the MP2400 (“D00100,” for example).
- ⑭ Click **OK**.

5. Click **Yes** in the parameter setting confirmation dialog box.

■ Caution

Note that when a parameter with the same connection number is already set and you click **Yes** in the parameter setting confirmation dialog, the setting will be overwritten by the parameter configured in the **Message Communication Easy Setting** Window.

6. Check the setting values.

I/O Message Communication
☐ Disable
☒ Enable

Easy setting It is possible to set easily that communicate the I/O message.

Data update timing: Low Scan

Read/Write	Local Port	Node IP Address	Node Port	Connect Type	Protocol Type	Code	Detail
Read	10005	192.168.001.002	10005	TCP	MELSEC(A Compatible)	BIN	Setting
Write	10006	192.168.001.002	10006	TCP	MELSEC(A Compatible)	BIN	Setting

MP2400

input disable ☐ output disable ☐

Head register number: IW00000 data size: 100 W <- Data register(D): 00000 100 W

Head register number: OW00064 data size: 100 W -> Data register(D): 00100 100 W

Node equipment: ☐

The I/O message communication is now set up, when the MP2400 acts as a master.

■ Caution

When any transmission or connection parameter is changed, the change will be reflected after FLASH has been saved and the power supply is turned ON again.

(2) How to Set up the Remote Equipment (MELSEC Q series) to Be Connected

This section explains the MELSEC Q series side procedure to set up for connecting the MP2400 with the MELSEC Q series.

Note: MELSEC Q series are products manufactured by Mitsubishi Electric Corporation.
Contact Mitsubishi Electric Corporation for more information.

1. Start up GX Developer.
2. Create a new project.
3. Set up network parameters (MELSECNET/Ethernet).

Table 6.16 Network Parameter Setting (example)

Setting Item	Setting Details
Network Type	Ethernet
Start I/O No.	Any
Network No.	Any
Group No.	Any
Exchange Number	Any
Mode	Online

4. Set up Ethernet operation.

Table 6.17 Ethernet Operation Setting (example)

Setting Item	Setting Details
Communication Data Code Setting	Binary mode communication
Initial Timing Setting	Always waiting OPEN
IP Address	192.168.1.2
Transmit Frame Setting	Ethernet (V2.0)
TCP Alive Check Setting	Any
Permit Writing during RUN	Permitted

5. Set the open setting.

Table 6.18 Open Setting (example)

Setting Item	Setting Details (connection number=1)	Setting Details (connection number=2)
Protocol	TCP	TCP
Open System	Fullpassive	Fullpassive
Fixed Buffer	Any	Any
Procedure to Communicate with Fixed Buffer	Any	Any
Pairing Open	Any	Any
Check Alive	Any	Any
Local Port Number	2715H (10005)	2716H (10006)
Remote IP Address for Communications	192.168.1.1	192.168.1.1
Remote Port Number for Communications	2715H (10005)	2716H (10006)

■ Caution

Set up a unique IP address in the network.
For the IP address, check with your network administrator.

The setting is finished for now. If necessary, transfer the settings to the PLC after setting all parameters.

■ Complement

Set up an initial setting and a router relay parameter below, if needed:

- Initial setting
Set a timer relevant configuration when TCP is selected as a protocol. In most cases, accept the default.
Set up if changes such as a shortened TCP retransmit timer are required.
 - Router relay parameter
Set up when you use a subnet mask pattern or default gateway.
-

(3) How to Start Communication

1. The MELSEC Q series starts to receive messages.

The message receive operation starts automatically, so you are not required to do anything.

2. The MP2400 side transmits messages.

When an I/O message communication function is used, the message transmit operation starts automatically, so you are not required to do anything.

Maintenance and Inspection

This chapter explains daily and regular inspection items to ensure that the MP2400 can always be used at its best conditions.

- 7.1 Daily Inspections ----- 7-2
- 7.2 Regular Inspections ----- 7-3
- 7.3 Replacing the Basic Module Battery ----- 7-4

7.1 Daily Inspections

The following table lists the daily inspection items.

No.	Inspection Item		Inspection Details	Criteria	Action
1	Installation conditions of Module, etc.		Check the mounting screws for looseness. Check whether the covers are all in place.	The screws and covers must be secured correctly.	Retighten the screws.
2	Connection conditions		Check the terminal screws for looseness.	The screws must be tight.	Retighten the screws.
			Check the connectors for looseness.	The connectors must be tight.	Retighten the connector set screws.
			Check the gap between crimp terminals.	There must be an appropriate gap between the terminals.	Correct as necessary.
3	LED Indicators	RDY	Check whether the indicator is lit.	The indicator must be lit. (It is abnormal if the indicator is not lit.)	Refer to <i>Chapter 8 Troubleshooting</i> .
		RUN	Check whether the indicator is lit while the system is in RUN state.	The indicator must be lit. (It is abnormal if the indicator is not lit.)	
		ERR	Check whether the indicator is not lit.	The indicator must be not lit. (It is abnormal if the indicator is lit.)	
		ALM	Check whether the indicator is not lit.	The indicator must be not lit. (It is abnormal if the indicator is lit.)	
		MTX	Check whether the indicator lights during communication.	The indicator must be lit. (It is abnormal if the indicator is not lit.)	
		BAT	Check whether the indicator is not lit.	The indicator must not be lit. (The battery voltage is too low if the indicator is lit.)	Replace the battery.

7.2 Regular Inspections

This section explains inspection items that must be performed once or twice every six months to one year.

Inspections must also be performed when the equipment is relocated or modified or when the wiring is changed.

 PROHIBITED
Do not replace the built-in fuse. If the customer replaces the built-in fuse, the MP2400 may malfunction or break down. Contact your Yaskawa representative.

No.	Inspection Item		Inspection Details	Criteria	Action
1	Operating Environment	Ambient Temperature	Check the temperature and humidity with a thermometer and hygrometer, respectively. Check for corrosive gases.	0°C to 55°C	If the MP2400 is used inside a panel, treat the temperature inside the panel as the ambient temperature.
		Ambient Humidity		30% to 95% RH	
		Atmosphere		There must be no corrosive gases.	
2	Power Supply Voltage Check	PS Module	Measure the voltage between 24-VDC terminals.	19.2 to 28.8 VDC	Change the power supply as necessary.
3	Installation Conditions	Looseness and Excess Play	Attempt to move the Module.	The Module must be secured properly.	Retighten the screws.
		Dust and Other Foreign Matter	Visually check.	The Module must be free from dust and other foreign matter.	Clean.
4	Connection Conditions	Check the Terminal Screws for Looseness.	Check by retightening the screws.	The screws must be tight.	Retighten.
		Gap between Crimp Terminals	Visually check.	There must be an appropriate gap between the terminals	Correct.
		Looseness of Connectors	Visually check.	The screws must be tight.	Retighten the connector set screws.
5	Battery		Check the BAT indicator on the front panel of the Basic Module.	The BAT indicator must be not lit.	If the BAT indicator is lit, replace the battery.

7.3 Replacing the Basic Module Battery

The Basic Module has one replaceable built-in battery. This battery is used to back up data to prevent the data stored in the memory from being lost when power is interrupted (e.g., when the power supply to the Basic Module is turned OFF).

The built-in battery can retain the contents of the memory until the total time of power interruptions reaches one year. The warranty period of the battery is five years from the date of purchase. These values, however, differ according to the operating conditions, including the ambient temperature.

If the BAT indicator on the Basic Module lights, replace the battery with a replacement battery (JZSP-BA01) within two weeks. Any delay in battery replacement will result in the data stored in the memory being lost.

The appearance of the battery is illustrated below.




Fig. 7.1 JZSP-BA01 (Battery with Cable)

- This battery is not commercially available. Contact your Yaskawa representative.

(1) Procedure



CAUTION

- There is danger of electric shock if the battery is not replaced correctly. Furthermore, machine malfunction may occur, the operator may be injured, or the machine may be damaged. Allow only a qualified technician trained in safety procedures to replace the battery.
- When replacing the battery, always do so with power supplied to the Basic Module. If power to the Basic Module is turned OFF when the battery is replaced, data stored in the memory in the Module may be lost.
- Do not touch the battery electrodes. The battery may be destroyed by the static electricity.
- A lithium battery is built into the MP2400. After replacing the battery, dispose of the old battery separately from regular waste and in accordance with local regulations.

1. Save the data stored in the Motion Board to a compact flash memory, hard disk on an external computer, or other media.

This data is used to restore any data accidentally lost during battery replacement.

- For information on saving methods, refer to the *MPE720 Programming Device Software for MP900/MP2000 Machine Controllers User's Manual* (manual number: SIEP C880700 05).

2. Check that the RDY indicator on the MP2400 Basic Module is lit.
3. Open the battery cover on the unit front surface.
4. Remove the connector on the end of lead of the built-in battery from the connector on the MP2400 Basic Module. Then, remove the built-in battery from the battery holder.
5. Insert securely the connector on the end of the lead of the replacement battery into the connector on the MP2400. Then, insert the replacement battery into the battery holder.
6. Check if the BAT indicator on the MP2400 is unlit.
7. Close the battery cover. This completes replacing the battery.


Troubleshooting

This chapter explains the possible causes of errors and suggests corrective actions.

8.1 Basic Flow of Troubleshooting	8-2
8.2 LED Indicator Meanings	8-3
8.3 Problem Classification	8-4
8.3.1 Overview	8-4
8.3.2 MP2400 Error Check Flowchart	8-5
8.4 Troubleshooting Details	8-6
8.4.1 Operation Errors	8-6
8.4.2 I/O Errors	8-9
8.4.3 Watchdog Timer Timeout Errors	8-10
8.4.4 Module Synchronization Errors (Ver. 2.75 or Later)	8-10
8.4.5 System Errors	8-11

8.1 Basic Flow of Troubleshooting

When problems occur, it is important to quickly find the cause of the problems and get the system running again as soon as possible. The basic flow of troubleshooting is illustrated below.



8.2 LED Indicator Meanings

The following table shows how to use the LED indicators to determine the operating status of the MP2400, as well as relevant error information when the LED indicator status indicates an error.

Classification	LED Indicator					Indicator Details	Countermeasures
	RDY	RUN	ALM	ERR	BAT		
Normal operation	Not lit	Not lit	Lit	Lit	Not lit	Hardware reset status	Usually the CPU will start within 10 seconds. If this status continues for more than 10 seconds, either a program error or hardware failure has occurred.
	Not lit	Not lit	Not lit	Not lit	Not lit	Initialization	
	Not lit	Lit	Not lit	Not lit	Not lit	Drawing A (DWG.A) being executed.	
	Lit	Not lit	Not lit	Not lit	Not lit	User program stopped. (Offline Stop Mode)	This status occurs - When the stop operation is executed from the MPE720 - When the STOP switch is turned ON This status does not indicate an error.
	Lit	Lit	Not lit	Not lit	Not lit	User program being executed normally.	This is the normal status.
Errors	Not lit	Not lit	Not lit	Lit	Not lit	A serious error, watchdog timer timeout error, or module synchronization error has occurred.	A hardware failure, watchdog timer timeout error, or module synchronization error has occurred. Refer to 8.3 <i>Problem Classification</i> on page 8-4.
	Not lit	Not lit	Not lit	Blinking	Not lit	Software Error Number of LED blinks indicates error type. 3: Address error (read) exception 4: Address error (write) exception 5: FPU exception 6: Illegal general command exception 7: Illegal slot command exception 8: General FPU inhibited exception 9: Slot FPU inhibited exception 10: TLB multibit exception 11: TLB error (read) exception 12: TLB error (write) exception 13: TLB protection violation (read) exception 14: TLB protection violation (write) exception 15: Initial page write exception	A system error has occurred. Refer to 8.4.5 <i>System Errors</i> on page 8-11.
	Not lit	Not lit	Blinking	Blinking	Not lit	Hardware Error Number of LED blinks indicates error type. 2: RAM diagnostic error 3: ROM diagnostic error 4: CPU function diagnostic error 5: FPU function diagnostic error	A hardware failure has occurred. Replace the module.
Warnings	–	–	–	–	Lit	Battery alarm	Refer to 7.3 <i>Replacing the Basic Module Battery</i> on page 7-4 and replace the battery.
	Lit	Lit	Lit	Not lit	Not lit	Operation error I/O error	- Operation errors Refer to 8.4.1 <i>Operation Errors</i> on page 8-6. - I/O errors Refer to 8.4.2 <i>I/O Errors</i> on page 8-9.

8.3 Problem Classification

8.3.1 Overview

The following table shows MP2400 problems and LED indicator patterns.


Classification	Details of Problem	LED Indicator		
		ALM	ERR	BAT
Alarm	Battery alarm	Not lit	Not lit	Lit
	Operation error	Lit	Not lit	Not lit
	I/O error	Lit	Not lit	Not lit
	Motion program alarm ^{*1}	Not lit	Not lit	Not lit
	Axis alarm/warning ^{*2}	Not lit	Not lit	Not lit
Error	Watchdog timer timeout error	Not lit	Lit	Not lit
	Module synchronization error	Not lit	Lit	Not lit
	System error	Not lit	Blinking	Not lit
	Hardware failure	Not lit	Lit	Not lit
		Blinking	Blinking	Not lit

* 1. If a motion program alarm occurs, refer to *10. Troubleshooting* in the *Machine Controller MP2000 Series User's Manual for Motion Programming* (manual number: SIEP C880700 38) to remove the alarm.

* 2. If an axis alarm or warning occurs, refer to the user's manual of the Motion Module being used to clear the alarm.

8.3.2 MP2400 Error Check Flowchart

Use the following to troubleshoot a problem using the LED indicators or the system registers.



8.4 Troubleshooting Details

8.4.1 Operation Errors

If an operation error occurs, one of the following may be the cause.

- An incorrect operation was executed in a ladder program.
- An incorrect operation was executed in a motion program.
- An incorrect operation was executed in a sequence program.

If an operation error occurs, use the following procedure to identify the instruction that caused the operation error.

1. Identifying the drawing type and error details by checking SW00080 to SW00089.

The operation error details are stored in the following system registers according to the type of drawing in which the operation error occurred. For motion programs, the details are stored in the system registers for DWG.H.

Drawing Type	Error Details	Register No.	Description		
DWG.A	Error count	SW00080	• Error count Number of errors that occurred.		
	Error code	SW00081			
DWG.I	Error count	SW00082	• Error code Bit15 12 Bit11..... 0		
	Error code	SW00083			
DWG.H	Error count	SW00084	<table border="1"><tr><td>Index error</td><td>Error code</td></tr></table>	Index error	Error code
	Index error	Error code			
Error code	SW00085				
DWG.L	Error count	SW00088	For information on error codes, refer to <i>A.4 User Operation Error Status</i> on page A-9.		
	Error code	SW00089			

Example: SW00085 is a Value Other Than 0000H

This indicates that an operation error occurred in the high-speed scan. In that case, if SW00084 is continuously incremented, it means that the instruction with the operation error has been executed continuously.

2. Identifying the drawing number by checking SW00122, SW00138, SW00154, and SW00186

Name	Register No.	Description
DWG.A error DWG number	SW00122	Parent drawing: FFFFH
DWG.I error DWG number	SW00138	Child drawing: xx00H (Hxx: child drawing number)
DWG.H error DWG number	SW00154	Grandchild drawing: xxyyH (Hyy: Grandchild drawing number)
DWG.L error DWG number	SW00186	Function: 8000H Motion program/sequence program: F0xxH (Hxx: Program number)

3. Identifying the instruction causing the error in the drawing


There are different methods to identify operation errors for integer operations and real-number operations. To identify operation errors using integer operations, refer to *Troubleshooting Procedure Example 1*.

To identify operation errors using real-number operations, refer to *Troubleshooting Procedure Example 2*.


Troubleshooting Procedure Example 1

This section describes the procedures for troubleshooting if an operation error (0002H: Integer operation overflow) has occurred in DWG.H.

- 1. Identify the error DWG number from the system register (SW00154), and then open that drawing.
- 2. Create the following code at the start of the DWG.



- 3. Add the debugging code before and after the instruction that is thought to be in error.



- 4. Check the value of the register number for the debugging code.
If the number has changed from 0 (no error) to 2 (integer operation overflow), an integer operation overflow error has occurred.
- 5. Repeat steps 3 and 4 to identify the instruction that is causing the operation error.

■ Complement

The debugging procedure above can be used only for integer operations and double-length integer operations.
The debugging procedure above cannot be used for real-number operations.

Troubleshooting Procedure Example 2

This section describes the procedures for troubleshooting if an operation error (0030H: Real-number operation - invalid operation (non-numeric)) has occurred in DWG.H.

1. Identify the error DWG number from the system register (SW00154), and then open that drawing.
2. Check the value for the real-number operation in the online monitor.

floating calculatig			
	[WLF] SrcA	[WLF] SrcB	[WLF] Dest
	MF00000	MF00002	MF00004
	*****	1.230000E+00	*****
	---	---	---

In this example, MF000000 for the DIV instruction is *****.

***** Indicates an incorrect (i.e., non-numeric) value for a real-number value. Executing a real-number operation using this value will generate an operation error (0030H: Real number operation - invalid operation (non-numeric)) from the system.

■ Complement

If an operation error occurs, one of the following may be the cause.

- The value has not been set in the registers (undefined data value).
- Bit, integer, and double-length integer operations are executed for a register that has overlapping addresses.

If a real number operation is executed, the real-number value must always be set in advance.

3. Repeat step 2 to identify the register that is causing the operation error.

8.4.2 I/O Errors

An I/O error may occur in the following cases.

- An Optional Module has been allocated, and the detailed settings for the Module have been made in the module configuration definitions.
- A cable has been removed or a Module failure has occurred during system operation.

If an I/O error occurs, you can check the I/O error by checking the following system registers.

Name	Register No.	Description
I/O error count	SW00200	Number of I/O errors (total of SW00201 and SW00203)
Input error count	SW00201	Number of input errors
Output error count	SW00203	Number of output errors

Using the following system registers, you can check the address of the I/O register (IW□□□□/OW□□□□) at which the error occurred.

Example: Detecting an I/O Error at an I/O Device Allocated to IW1234

1234H is reported in SW00202.

Name	Register No.	Description
Input error address	SW00202	Latest input error address (register number IW□□□□)
Output error address	SW00204	Latest output error address (register number OW□□□□)

After you check the I/O register address, identify the module slot on the Module Configuration Definition Window, and then check the I/O status in the following system registers.

Name	Register No.	Description
Input error address	SW00208 to SW00215	CPU Module
	SW00216 to W00223	Reserved by the system.
	SW00224 to W00231	Rack 1, slot 1 error status
	SW00232 to W00239	Rack 1, slot 2 error status
	SW00240 to W00247	Rack 1, slot 3 error status
	SW00248 to W00255	Rack 1, slot 4 error status
	...	...
	SW00496 to W00503	Rack 4, slot 9 error status

8.4.3 Watchdog Timer Timeout Errors

If a watchdog timer timeout error occurs, one of the following may be the cause.


- An infinite loop has occurred in a user program.
- A scan time over has occurred in a user program.
- A motion module ^{*1} has failed.
- A watchdog timer timeout error has occurred in an MPU-01 Module. ^{*2}

* 1. Motion modules: PO-01, SVA-01, SVB-01, SVC-01, MPU-01

* 2. If a watchdog timer timeout error occurs when using an MPU-01 module, refer to 6. *Troubleshooting* in the *Machine Controller MP2000 Series MPU-01 Multiple-CPU Module User's Manual* (manual number: SIEP C880781 05).

If a watchdog timer timeout error occurs, it is important to identify whether the cause is the CPU module itself or another motion module.

To identify the cause, cycle the power with the CPU module program stopped and check if the problem has changed.



When the power is cycled with the STOP switch on the front of the CPU module set to ON, the CPU module will start with execution of the CPU module ladder program stopped.

If a watchdog timer timeout error does not occur after the CPU module program has been stopped, the problem is probably in the CPU module. Check if the program has any infinite loops in it.

If the problem remains, the motion module may have failed. Contact your Yaskawa representative.

8.4.4 Module Synchronization Errors (Ver. 2.75 or Later)

If a module synchronization error occurs, one of the following may be the cause.

- A motion module ^{*1} has failed.
- A watchdog timer timeout error has occurred in an MPU-01 module. ^{*2}

* 1. Motion Modules: PO-01, SVA-01, SVB-01, SVC-01, MPU-01

* 2. If a module synchronization error occurs when using an MPU-01 module, refer to 6. *Troubleshooting* in the *Machine Controller MP2000 Series MPU-01 Multiple-CPU Module User's Manual* (manual number: SIEP C880781 05).

If a module synchronization error occurs (SW00050 = 00051H), the module synchronization error detection slot will be reported in the system registers as shown in the following table.

Register No.	Description
SW00076	Module synchronization error detection slot* □□yyH □□: Rack number (01 to 04) yy: Slot number (01 to 09)

* Module synchronization errors are reported for CPU system software version 2.75 or later.

For version 2.74 or earlier, it is reported as a watchdog timer timeout error.

If a module synchronization error has occurred, contact your Yaskawa representative.

8.4.5 System Errors

If a system error occurs, one of the following may be the cause.

- Incorrect operation has been executed in the user program
- Incorrect installation environment
- Hardware failure

When using embedded C-language programming, a system error will cause the system to crash with the incorrect pointer access or incorrect operation using data with a floating point. Refer to the following table for the possible causes of the errors.

ERR LED No. of flashes	Error	Cause	Countermeasure
Three times	Address error (read) exception	Data of 16-bit words or 32-bit long words were read from an incorrect address.*	Check if the incorrect operations on the left have been executed and if so, make corrections.
Four times	Address error (write) exception	Data of 16-bit words or 32-bit long words were written on an incorrect address.*	
Five times	FPU exception	Incorrect operation (non-numeric operation, division by zero, or overflow) using a floating point was executed.	

* For details, refer to *10 Precautions in Machine Controller MP2000 Series Embedded C-language Programming Package Development Guide* (manual number: SIEP C880700 25)

If embedded C-language programming or an incorrect operation in C-language was not attempted, a hardware error may be the cause of the system crash.

The causes of the hardware error can be divided into two types: installation environment and the hardware failures. For troubleshooting errors caused by the installation environment, refer to *3.2 Basic Module Connections* on page 3-9. If the installation environment is faultless and the same error still occurs after countermeasures were taken, the hardware may be damaged. Contact your Yaskawa representative or nearest office listed in the back cover for assistance.

Appendices

A	System Registers Lists	A-2
A.1	System Service Registers	A-2
A.2	System Status	A-6
A.3	System Error Status	A-7
A.4	User Operation Error Status	A-9
A.5	System Service Execution Status	A-10
A.6	User Operation Error Status Details	A-11
A.7	System I/O Error Status	A-12
A.8	Compact Flash Card-Related System Registers (CPU-02 and CPU-03 Modules for the MP2200 Only)	A-13
A.9	Interrupt Status	A-14
A.10	Module Information	A-15
A.11	MPU-01 System Status	A-16
A.12	Motion Program Information	A-17
B	Motion Parameter Details	A-20
B.1	Fixed Parameter List	A-20
B.2	Setting Parameter List	A-22
B.3	Monitoring Parameter List	A-27
C	Simple Connection Function of the Engineering Tool	A-31
C.1	Preparation	A-31
C.2	Procedure	A-31

Appendix A System Registers Lists

The system registers are prepared by the system of the MP2400. The system registers can be used to read error information, operating status, and other information.

	Contents
SW000000	System Service Registers
SW000030	System Status
SW000050	System Error Status
SW000080	User Operation Error Status
SW000090	System Service Execution Status
SW000110	User Operation Error Status Details
SW000190	Alarm Counter and Alarm Clear
SW000200	System I/O Error Status
SW000504	Reserved by the system.
SW000652	Compact Flash Card-Related System Registers (CPU-02 and CPU-03 Modules for the MP2200 Only)
SW000698	Interrupt Status
SW000800	Module Information
SW001312	Reserved by the system.
SW001411	MPU-01 Module System Status
SW002048	Reserved by the system.
SW003200	Motion Program Information
SW005200~ SW008191	Reserved by the system.

A.1 System Service Registers







(1) Shared by All Drawings

Name	Register No.	Remarks
Reserved by the system	SB000000	(Not used)
High-speed Scan	SB000001	ON for only one scan after high-speed scan is started after turning ON the power supply.
Reserved by the system	SB000002	(Not used)
Low-speed Scan	SB000003	ON for only one scan after low-speed scan is started after turning ON the power supply.
Always ON	SB000004	Always ON (= 1)
High-speed scan 2	SB000005	ON for only one scan after the start of a high-speed scan that is begun after a CPU Module operation starts. *
Low-speed scan 2	SB000006	ON for only one scan after the start of a low-speed scan that is begun after a CPU Module operation starts. *
High-speed Scan Flag	SB000007	ON during execution of the high-speed scan.
Reserved by the system	SB000008 to SB00000F	(Not used)

* Does not include when MPE720 version 2.75 or earlier is used to execute a batch load or to clear the memory before starting the CPU Module.









(2) DWG.H Only

The following relays are reset at the start of the high-speed scan.

Name	Register No.	Remarks
1-scan Flicker Relay	SB000010	
0.5-s Flicker Relay	SB000011	
1.0-s Flicker Relay	SB000012	
2.0-s Flicker Relay	SB000013	
0.5-s Sampling Relay	SB000014	
1.0-s Sampling Relay	SB000015	
2.0-s Sampling Relay	SB000016	
60.0-s Sampling Relay	SB000017	
1.0 s After Start of Scan Relay	SB000018	
2.0 s After Start of Scan Relay	SB000019	
5.0 s After Start of Scan Relay	SB00001A	

(3) DWG.L Only

The following relays are reset at the start of the low-speed scan.

Name	Register No.	Remarks
One-scan Flicker Relay	SB000030	
0.5-s Flicker Relay	SB000031	
1.0-s Flicker Relay	SB000032	
2.0-s Flicker Relay	SB000033	
0.5-s Sampling Relay	SB000034	
1.0-s Sampling Relay	SB000035	
2.0-s Sampling Relay	SB000036	
60.0-s Sampling Relay	SB000037	
1.0 s After Start of Scan Relay	SB000038	
2.0 s After Start of Scan Relay	SB000039	
5.0 s After Start of Scan Relay	SB00003A	

(4) Scan Execution Status and Calendar

Name	Register No.	Remarks
High-speed Scan Set Value	SW00004	High-speed Scan Set Value (0.1 ms)
High-speed Scan Current Value	SW00005	High-speed Scan Current Value (0.1 ms)
High-speed Scan Maximum Value	SW00006	High-speed Scan Maximum Value (0.1 ms)
High-speed Scan Set Value 2	SW00007	High-speed Scan Set Value (1 μ s)
High-speed Scan Current Value 2	SW00008	High-speed Scan Current Value (1 μ s)
High-speed Scan Maximum Value 2	SW00009	High-speed Scan Maximum Value (1 μ s)
Low-speed Scan Set Value	SW00010	Low-speed Scan Set Value (0.1 ms)
Low-speed Scan Current Value	SW00011	Low-speed Scan Current Value (0.1 ms)
Low-speed Scan Maximum Value	SW00012	Low-speed Scan Maximum Value (0.1 ms)
Reserved by the system.	SW00013	(Not used)
Executing Scan Current Value	SW00014	Executing Scan Current Value (0.1 ms)
Calendar: Year	SW00015	1999: 0099 (BCD) (Last two digits only)
Calendar: Month Day	SW00016	December 31: 1231 (BCD)
Calendar: Hours Minutes	SW00017	23 hours 59 minutes: 2359 (BCD)
Calendar: Seconds	SW00018	59 s: 59 (BCD)
Calendar: Day of Week	SW00019	0: Sun., 1: Mon., 2: Tues., 3: Wed., 4: Thurs., 5: Fri., 6: Sat.

(5) Program Software Numbers and Remaining Program Memory Capacity

Name	Register No.	Remarks
System Program Software Number	SW00020	S□□□□ (□□□□ is stored as BCD)
System Number	SW00021 to SW00025	(Not used)
Remaining Program Memory Capacity	SL00026	Bytes
Total Memory Capacity	SL00028	Bytes

A.2 System Status

System operating status and error status is stored in registers SW00040 to SW00048. Checking of system status details are used to determine whether hardware or software is the cause of an error.

Name	Register No.	Description		
Reserved by the system.	SW00030 to SW00039	—		
CPU Status	SW00040	SB000400	READY	0: Failure, 1: Normal
		SB000401	RUN	0: Stopped, 1: Running
		SB000402	ALARM	0: Normal, 1: Alarm
		SB000403	ERROR	0: Normal, 1: Error
		SB000404	Reserved by the system.	—
		SB000405	Reserved by the system.	—
		SB000406	FLASH	1: Flash operation
		SB000407	WEN	0: Write-disabled, 1: Write-enabled
		SB000408 to SB00040D	Reserved by the system.	—
		SB00040E	Operation Stop Request	0: RUN selection, 1: STOP selection
		SB00040F	Run Switch Status at Power ON	0: STOP, 1: RUN
CPU Error Status	SW00041	SB000410	Serious Failure	1: WDGE, undefined command See SW00050 for details.
		SB000411	Reserved by the system.	—
		SB000412	Reserved by the system.	—
		SB000413	Exception Error	—
		SB000414 to SB000417	Reserved by the system.	—
		SB000418	User operation error	1: User operation error
		SB000419	I/O Error	1: I/O error
		SB00041A to SB00041F	Reserved by the system.	—
H Scan Over Counter	SW00044	—	—	—
L Scan Over Counter	SW00046	—	—	—
Reserved by the system.	SW00047	—	Reserved by the system.	—
Hardware Configuration Status	SW00048	SB000480	TEST	DIP switch alarms 0: OFF, 1: ON
		SB000481	MON	
		SB000482	CNFG	
		SB000483	INIT	
		SB000484	SUP	
		SB000485	STOP	
		SB000486	—	
		SB000487	Battery Alarm	—
		SB000488 to SB00048F	Reserved by the system.	—
Reserved by the system.	SW00049	SW000490 to SW00049F	Reserved by the system.	—

A.3 System Error Status

System error status is stored in registers SW00050 to SW00060. The following table shows the details when a system errors occurs.

Name	Register No.	Description		
32-bit Error Code	SW00050	0001H	Watchdog timer over error	
		0041H	ROM diagnosis error	
		0042H	RAM diagnosis error	
		0043H	CPU diagnosis error	
		0044H	FPU diagnosis error	
		0050H	EXIO error	
		0051H	Module synchronous error *1	
		00E0H	Address read exception error	
		0100H	Address write exception error	
		0120H	FPU exception error	
		0180H	Illegal general command error	
		01A0H	Illegal slot command error	
		01E0H	User break after command execution	
		0800H	General FPU inhibited exception error	
		0820H	Slot FPU inhibited exception error	
	SW00051	For system error analysis		
32-bit Addresses Generating Error	SW00052	For system error analysis		
	SW00053			
Error Task	SW00054	0000H: System 0001H: DWG.A	0002H: DWG.I 0003H: DWG.H	0005H: DWG.L
Program Type	SW00055	0000H: System 0001H: DWG.A	0002H: DWG.I 0003H: DWG.H	0005H: DWG.L 0008H: Function 000FH: Motion program/ Sequence program
Error Drawing Num- ber	SW00056	Ladder program parent drawing: FFFFH Ladder program function: 8000H Ladder program child drawing: □□00H (H□□: Child drawing number) Ladder program grandchild drawing: □□yyH (Hyy: Grandchild drawing number) Motion program/Sequence program: F0□□H (H□□: Program number)		
Calling Drawing Type	SW00057	Type of drawing that calls the ladder program function in which an error occurred.		
		0001H: DWG.A 0002H: DWG.I 0003H: DWG.H	0005H: DWG.L 0008H: Ladder program function 000FH: Motion program/ Sequence program	0010H: Reserved by the sys- tem. 0011H: Reserved by the sys- tem.
Calling Drawing Number	SW00058	Number of drawing that calls the ladder program function in which an error occurred. Parent drawing: FFFFH Child drawing: □□00H (H□□: Child drawing number) Function: 0100H Grandchild drawing: □□yyH (Hyy: Grandchild drawing number)		
Calling Drawing STEP Number	SW00059	STEP number of the drawing that calls the ladder program function in which an error occurred. Zero when there is an error in the drawing.		

(cont'd)

Name	Register No.	Description
Error Data	SW00060 and SW00061	Reserved by the system.
	SW00062 to SW00065	Name of Task Generating Error
	SW00066 and SW00067	Reserved by the system.
	SW00068	Year Generated
	SW00069	Month Generated
	SW00070	Day of Week Generated
	SW00071	Day of Month Generated
	SW00072	Hour Generated
	SW00073	Minutes Generated
	SW00074	Seconds Generated
	SW00075	Milliseconds Generated (Not used.)
	SW00076	Number of slot with a module synchronous error ^{*2} □□yyH □□: Rack number (01 to 04) yy: Slot number (01 to 09)
	SW00078 and SW00079	Reserved by the system.

- * 1. The CPU system program version 2.75 or later: 0051H will be reported.
The CPU system program version is earlier than 2.75: 0001H (watchdog timer over error) will be reported.
- * 2. The CPU system program version 2.75 or later: Number of slot with a module synchronous error will be reported.

A.4 User Operation Error Status

Error information for user operation errors in ladder programs is stored in registers SW00080 to SW00089.

(1) User Operation Error Status

	Name	Register No.	Description
DWG.A	Error Count	SW00080	- Error count - Number of error occurrences
	Error Code	SW00081	
DWG.I	Error Count	SW00082	Error code
	Error Code	SW00083	
DWG.H	Error Count	SW00084	Bit15 12 Bit11 0 Index error Error Code
	Error Code	SW00085	
DWG.L	Error Count	SW00088	Refer to (2) <i>User Operation Error Codes 1</i> on page A-9 or (3) <i>User Operation Error Codes 2</i> on page A-10 for details.
	Error Code	SW00089	

(2) User Operation Error Codes 1

	Error Code	Error Contents	System Default Setting	
Integer Operations	0001H	Integer operation - underflow	-32768	
	0002H	Integer operation - overflow	32767	
	0003H	Integer operation - division error	The A register remains the same.	
	0009H	Double-length integer operation - underflow	-2147483648	
	000AH	Double-length integer operation - overflow	2147483647	
	000BH	Double-length integer operation - division error	The A register remains the same.	
Real Number Operation	0010H	Integer storage - non-numeric error	Store not executed. [00000]	
	0011H	Integer storage - underflow	Store not executed. [-32768]	
	0012H	Integer storage - overflow	Store not executed. [+32767]	
	0021H	Real number storage - underflow	Store not executed. [-1.0E+38]	
	0022H	Real number storage - overflow	Store not executed. [1.0E+38]	
	0023H	Real number operation - division-by-zero error	Operation not executed. [The F register remains the same.]	
	0030H	Real number operation - invalid operation (non-numeric)	Operation not executed.	
	0031H	Real number operation - exponent underflow	0.0	
	0032H	Real number operation - exponent overflow	Maximum value	
	0033H	Real number operation - division error (non-numeric 0/0)	Operation not executed.	
	0034H	Real number storage - exponent underflow	Stores 0.0.	
	0035H	Real number operation - stack error	-	
	0040H to 0059H	Standard System Functions Real number operation errors	Interrupt operation and output = 0.0	
		0040H: SQRT	0041H: SIN	0042H: COS
		0044H: ASIN	0045H: ACOS	0046H: ATAN
		0048H: LN	0049H: LOG	004AH: DZA
		004CH: LIM	004DH: PI	004EH: PD
		0050H: LAG	0051H: LLAG	0052H: FGN
		0054H: LAU	0055H: SLAU	0056H: REM
		0058H: BSRCH	0059H: SQRT	-
		1000H, 2000H, or 3000H is added for an index error.		

(3) User Operation Error Codes 2

	Error Code	Error Contents	System Default
Integer - Real Number Operations	1000H	Index error within drawing	Execute again when corresponding to i,j = 0. The i and j registers remain the same.
	2000H	Index error within function	Execute again when corresponding to i,j = 0. The i and j registers remain the same.
	3000H	Index error within motion program or sequence program	Execute again when corresponding to i,j = 0. The i and j registers remain the same.
Integer Operation	□060H to □0C9H (□ = 1, 2, 3)	Integer system functions Index error	Operation stopped and output = input.
		□06DH: PI □06EH: PD	□06FH: PID □070H: LAG
		□071H: LLAG □072H: FGN	□073H: IFGN □074H: LAU
		□075H: SLAU □076H: FGN	□077H: IFGN □08EH: INS
		□08FH: OUTS □090H: ROTL	□091H: ROTR □092H: MOVVB
		□093H: MOVW □094H: SETW	□095H: XCHG □096H: LIMIT
		□097H: LIMIT □098H: DZA	□099H: DZA □09AH: DZB
		□09BH: DZB □09CH: PWM	□09EH: SHFTL □09FH: SHFTR
		□0A0H: BEXTEND □0A1H: BPRESS	□0A2H: SORT □0A4H: SORT
		□0A6H: RCHK □0A7H: RCHK	□0A8H: COPYW □0A9H: ASCII
		□0AAH: BINASC □0ABH: ASCBIN	□0ACH: BSRCH □0ADH: BSRCH
		□0AEH: TIMEADD □0AFH: TIMSUB	□0B1H: SPEND □0C0H: TBLBR
		□0C1H: TBLBW □0C2H: TBL SRL	□0C3H: TBL SRC □0C4H: TBL CL
		□0C5H: TBL MW □0C6H: QTBLR	□0C7H: QTBL RI □0C8H: QTBL W
		□0C9H: QTBL WI –	– –

A.5 System Service Execution Status

System service execution status is stored in registers SW00090 to SW00103. The following tables show the details on the execution status of system service.

(1) Data Trace Execution Status

Name	Register No.	Remarks
Reserved by the system.	SW00090 to SW00097	–
Existence Of Data Trace Definition	SW00098	Bit 0 to 3 = Group 1 to 4 Definition exists = 1, No definition = 0
Data Trace Execution Status	SW00099	Bit 0 to 3 = Group 1 to 4 Trace stopped = 1, Trace executing = 0

(2) Latest Data Trace Record Numbers

Name	Register No.	Remarks
Data Trace Group 1	SW00100	Latest record number
Data Trace Group 2	SW00101	Latest record number
Data Trace Group 3	SW00102	Latest record number
Data Trace Group 4	SW00103	Latest record number

A.6 User Operation Error Status Details

Detailed information about user operation errors in ladder programs is stored in registers SW00110 to SW00189.

Name	Register No.				Description
	DWG.A	DWG.I	DWG.H	DWG.L	
Error Count	SW00110	SW00126	SW00142	SW00174	- Descriptions of the error count and the error code are the same as those in <i>A.4 User Operation Error Status</i> on page A-9. - Error Drawing Number Parent drawing: FFFFH Child drawing: □□00H (H□□: Child drawing number) Grandchild drawing: □□yyH (Hyy: Grandchild drawing number) Function: 8000H Motion program/Sequence program: F0□□H (H□□: Program number) - Reference Source Drawing Number Number of the drawing reference source in which an error occurred. - Reference Source DWG Step Number Step number of the drawing reference source in which an error occurred. Zero when there is an error in the parent drawing.
Error Code	SW00111	SW00127	SW00143	SW00175	
Reserved by the system.	SW00112 to SW00121	SW00128 to SW00137	SW00144 to SW00153	SW00176 to SW00185	
Error Drawing Number	SW00122	SW00138	SW00154	SW00186	
Reference Source Drawing Number	SW00123	SW00139	SW00155	SW00187	
Reference Source DWG Step Number	SW00124	SW00140	SW00156	SW00188	
Reserved by the system.	SW00125	SW00141	SW00157	SW00189	

A.7 System I/O Error Status

Data that show details when a system I/O error occurs are stored in register numbers SW00192 to SW00503.

Name	Register No.	Remarks
Current alarm	SW00190	Cleared when the power is turned ON.
Number of alarm history records	SW00191	Number of alarm history records
Clear alarms	SW00192	1: Alarm cleared. 2: Current alarm and alarm history cleared.
	...	...
I/O error count	SW00200	Number of I/O errors
Input error count	SW00201	Number of input errors
Input error address	SW00202	Latest input error address (register number IW□□□□)
Output error count	SW00203	Number of output errors
Output error address	SW00204	Latest output error address (register number OW□□□□)
Reserved by the system.	SW00205	Not used.
	SW00206	
	SW00207	
I/O error status	SW00208 to SW00215	CPU module error status
	SW00216 to SW00223	Reserved by the system.
	SW00224 to SW00231	Rack 1, slot 1 error status
	SW00232 to SW00239	Rack 1, slot 2 error status
	SW00240 to SW00247	Rack 1, slot 3 error status
	SW00248 to SW00255	Rack 1, slot 4 error status
	...	...
	SW00496 to SW00503	Rack 4, slot 9 error status

A.8 Compact Flash Card-Related System Registers (CPU-02 and CPU-03 Modules for the MP2200 Only)

Information on the operation status of the compact flash card (CF card) is stored in registers SW00652 to SW00659. These registers are used to hold status reports only for a CPU-02 or CPU-03 module used with an MP2200 that is compatible with the CF card.

In other models, these registers are reserved for the system.

Specifications	Register No.		Description	
Whole capacity of Compact Flash Card	SL00652		Unit: Byte	
Card Status	SW00654	SB006540	0: Compact Flash card not mounted	1: Compact Flash card mounted
		SB006541	0: Power not supplied	1: Power being supplied
		SB006542	0: Compact Flash card not identified	1: Compact Flash card being identified
		SB006543	0: No Compact Flash card access	1: Compact Flash card being accessed
		SB006544	0: –	1: FAT file system being checked
		SB006545 to SB00654F	Reserved by the system.	
FAT Type	SW00655	0001H	FAT12	
		0002H	FAT16	
		0003H	FAT32	
Reserved by the system.	SW00656		–	
Reserved by the system.	SW00657		–	
Batch Load/Save	SW00658	SB006580	During batch load	
		SB006581	Compact Flash card read-out error	
		SB006582	Load file model mismatched	
		SB006583	Load file write-in error	
		SB006584	Flash-storage error	
		SB006585	No batch load folder exists.	
		SB006586	Load error due to prohibition of load (program write protection)	
		SB006587	Reserved by the system.	
		SB006588	During a batch save	
		SB006589	Compact Flash card write-in error	
		SB00658A	Save file read-out error	
		SB00658B	Security error	
		SB00658C to SB00658F	Reserved by the system.	
Reserved by the system.	SW00659		–	

A.9 Interrupt Status

A.9.1 Interrupt Status List

Name	Register No.	Remarks
Interrupt information	SW00698	Interrupt detection count
	SW00699	Number of interrupting modules
	SW00700	Interrupting module 1
	SW00701	
	SW00702	
	SW00703	Interrupting module 2
	SW00704	
	SW00705	
	:	Interrupting module 30
	:	
	SW00787	
	SW00788	
	SW00789	

A.9.2 Details on Interrupting Module

	F	8	7	0	(Bit number)
SW00xx+0	Rack		Slot		mmssH
SW00xx+1	Interrupt type				
SW00xx+2	Hardware interrupt cause register value				

(1) Rack

mm = 01 to 04 (01 only for the MP2300 module)

The number of the rack where the module that caused the interrupt is mounted is reported.

(2) Slot

ss = 01 to 09

(3) Interrupt type

1: CPU IO (MP2100, MP2100M, MP2101, MP2101M, MP2101T, MP2101TM, MP2300): DI interrupt

2: LIO-01/LIO-02/LIO-04/LIO-05: DI interrupt

3: LIO-01/LIO-02/LIO-06/CNTR-01: Counter interrupt

A.10 Module Information

Name	Register No.	Remarks
CPU information	SW00800	MP2400 ID (C480H)
	SW00801	CPU hardware version (BCD)
	SW00802	CPU software version (BCD)
	SW00803	Number of subslots (0005H)
	SW00804	CPU function module ID (C410H)
	SW00805	CPU function module status
	SW00806	218IFA function module ID (8623H)
	SW00807	218IFA function module status
	SW00808	SVB function module ID (9114H)
	SW00809	SVB function module status
	SW00810	SVR function module ID (9210H)
	SW00811	SVR function module status
	SW00812	M-EXECUTOR function module ID (8430H)
	SW00813	M-EXECUTOR function module status
	SW00814 to SW00815	Reserved by the system.
Reserved by the system.	SW00816 to SW01095	Reserved by the system.

A.11 MPU-01 System Status

Name	Register No.	Remarks
MPU-01 #1 Status	SW01411	Status of MPU-01 module circuit 1
MPU-01 #1 Error Status	SW01412	Error status of MPU-01 module circuit 1
MPU-01 #2 Status	SW01413	Status of MPU-01 module circuit 2
MPU-01 #2 Error Status	SW01414	Error status of MPU-01 module circuit 2
MPU-01 #3 Status	SW01415	Status of MPU-01 module circuit 3
MPU-01 #3 Error Status	SW01416	Error status of MPU-01 module circuit 3
MPU-01 #4 Status	SW01417	Status of MPU-01 module circuit 4
MPU-01 #4 Error Status	SW01418	Error status of MPU-01 module circuit 4
MPU-01 #5 Status	SW01419	Status of MPU-01 module circuit 5
MPU-01 #5 Error Status	SW01420	Error status of MPU-01 module circuit 5
MPU-01 #6 Status	SW01421	Status of MPU-01 module circuit 6
MPU-01 #6 Error Status	SW01422	Error status of MPU-01 module circuit 6
MPU-01 #7 Status	SW01423	Status of MPU-01 module circuit 7
MPU-01 #7 Error Status	SW01424	Error status of MPU-01 module circuit 7
MPU-01 #8 Status	SW01425	Status of MPU-01 module circuit 8
MPU-01 #8 Error Status	SW01426	Error status of MPU-01 module circuit 8
MPU-01 #9 Status	SW01427	Status of MPU-01 module circuit 9
MPU-01 #9 Error Status	SW01428	Error status of MPU-01 module circuit 9
MPU-01 #10 Status	SW01429	Status of MPU-01 module circuit 10
MPU-01 #10 Error Status	SW01430	Error status of MPU-01 module circuit 10
MPU-01 #11 Status	SW01431	Status of MPU-01 module circuit 11
MPU-01 #11 Error Status	SW01432	Error status of MPU-01 module circuit 11
MPU-01 #12 Status	SW01433	Status of MPU-01 module circuit 12
MPU-01 #12 Error Status	SW01434	Error status of MPU-01 module circuit 12
MPU-01 #13 Status	SW01435	Status of MPU-01 module circuit 13
MPU-01 #13 Error Status	SW01436	Error status of MPU-01 module circuit 13
MPU-01 #14 Status	SW01437	Status of MPU-01 module circuit 14
MPU-01 #14 Error Status	SW01438	Error status of MPU-01 module circuit 14
MPU-01 #15 Status	SW01439	Status of MPU-01 module circuit 15
MPU-01 #15 Error Status	SW01440	Error status of MPU-01 module circuit 15
MPU-01 #16 Status	SW01441	Status of MPU-01 module circuit 16
MPU-01 #16 Error Status	SW01442	Error status of MPU-01 module circuit 16

A.12 Motion Program Information

■ System Work Number 1 to 8

System Work Number		System Work 1	System Work 2	System Work 3	System Work 4	System Work 5	System Work 6	System Work 7	System Work 8
Executing Main Program No.		SW03200	SW03201	SW03202	SW03203	SW03204	SW03205	SW03206	SW03207
Status		SW03264	SW03322	SW03380	SW03438	SW03496	SW03554	SW03612	SW03670
Control Signal		SW03265	SW03323	SW03381	SW03439	SW03497	SW03555	SW03613	SW03671
Parallel 0	Program Number	SW03266	SW03324	SW03382	SW03440	SW03498	SW03556	SW03614	SW03672
	Block Number	SW03267	SW03325	SW03383	SW03441	SW03499	SW03557	SW03615	SW03673
	Alarm Code	SW03268	SW03326	SW03384	SW03442	SW03500	SW03558	SW03616	SW03674
Parallel 1	Program Number	SW03269	SW03327	SW03385	SW03443	SW03501	SW03559	SW03617	SW03675
	Block Number	SW03270	SW03328	SW03386	SW03444	SW03502	SW03560	SW03618	SW03676
	Alarm Code	SW03271	SW03329	SW03387	SW03445	SW03503	SW03561	SW03619	SW03677
Parallel 2	Program Number	SW03272	SW03330	SW03388	SW03446	SW03504	SW03562	SW03620	SW03678
	Block Number	SW03273	SW03331	SW03389	SW03447	SW03505	SW03563	SW03621	SW03679
	Alarm Code	SW03274	SW03332	SW03390	SW03448	SW03506	SW03564	SW03622	SW03680
Parallel 3	Program Number	SW03275	SW03333	SW03391	SW03449	SW03507	SW03565	SW03623	SW03681
	Block Number	SW03276	SW03334	SW03392	SW03450	SW03508	SW03566	SW03624	SW03682
	Alarm Code	SW03277	SW03335	SW03393	SW03451	SW03509	SW03567	SW03625	SW03683
Parallel 4	Program Number	SW03278	SW03336	SW03394	SW03452	SW03510	SW03568	SW03626	SW03684
	Block Number	SW03279	SW03337	SW03395	SW03453	SW03511	SW03569	SW03627	SW03685
	Alarm Code	SW03280	SW03338	SW03396	SW03454	SW03512	SW03570	SW03628	SW03686
Parallel 5	Program Number	SW03281	SW03339	SW03397	SW03455	SW03513	SW03571	SW03629	SW03687
	Block Number	SW03282	SW03340	SW03398	SW03456	SW03514	SW03572	SW03630	SW03688
	Alarm Code	SW03283	SW03341	SW03399	SW03457	SW03515	SW03573	SW03631	SW03689
Parallel 6	Program Number	SW03284	SW03342	SW03400	SW03458	SW03516	SW03574	SW03632	SW03690
	Block Number	SW03285	SW03343	SW03401	SW03459	SW03517	SW03575	SW03633	SW03691
	Alarm Code	SW03286	SW03344	SW03402	SW03460	SW03518	SW03576	SW03634	SW03692
Parallel 7	Program Number	SW03287	SW03345	SW03403	SW03461	SW03519	SW03577	SW03635	SW03693
	Block Number	SW03288	SW03346	SW03404	SW03462	SW03520	SW03578	SW03636	SW03694
	Alarm Code	SW03289	SW03347	SW03405	SW03463	SW03521	SW03579	SW03637	SW03695
Logical axis #1 Program Current Position		SL03290	SL03348	SL03406	SL03464	SL03522	SL03580	SL03638	SL03696
Logical axis #2 Program Current Position		SL03292	SL03350	SL03408	SL03466	SL03524	SL03582	SL03640	SL03698
Logical axis #3 Program Current Position		SL03294	SL03352	SL03410	SL03468	SL03526	SL03584	SL03642	SL03700
Logical axis #4 Program Current Position		SL03296	SL03354	SL03412	SL03470	SL03528	SL03586	SL03644	SL03702
Logical axis #5 Program Current Position		SL03298	SL03356	SL03414	SL03472	SL03530	SL03588	SL03646	SL03704
Logical axis #6 Program Current Position		SL03300	SL03358	SL03416	SL03474	SL03532	SL03590	SL03648	SL03706
Logical axis #7 Program Current Position		SL03302	SL03360	SL03418	SL03476	SL03534	SL03592	SL03650	SL03708
Logical axis #8 Program Current Position		SL03304	SL03362	SL03420	SL03478	SL03536	SL03594	SL03652	SL03710
Logical axis #9 Program Current Position		SL03306	SL03364	SL03422	SL03480	SL03538	SL03596	SL03654	SL03712
Logical axis #10 Program Current Position		SL03308	SL03366	SL03424	SL03482	SL03540	SL03598	SL03656	SL03714
Logical axis #11 Program Current Position		SL03310	SL03368	SL03426	SL03484	SL03542	SL03600	SL03658	SL03716

(cont'd)

System Work Number	System Work 1	System Work 2	System Work 3	System Work 4	System Work 5	System Work 6	System Work 7	System Work 8
Logical axis #12 Program Current Position	SL03312	SL03370	SL03428	SL03486	SL03544	SL03602	SL03660	SL3718
Logical axis #13 Program Current Position	SL03314	SL03372	SL03430	SL03488	SL03546	SL03604	SL03662	SL3720
Logical axis #14 Program Current Position	SL03316	SL03374	SL03432	SL03490	SL03548	SL03606	SL03664	SL3722
Logical axis #15 Program Current Position	SL03318	SL03376	SL03434	SL03492	SL03550	SL03608	SL03666	SL3724
Logical axis #16 Program Current Position	SL03320	SL03378	SL03436	SL03494	SL03552	SL03610	SL03668	SL3726

■ System Word Number 9 to 16

System Work Number	System Work 9	System Work 10	System Work 11	System Work 12	System Work 13	System Work 14	System Work 15	System Work 16
Executing Main Program No.	SW03208	SW03209	SW03210	SW03211	SW03212	SW03213	SW03214	SW03215
Status	SW03728	SW03786	SW03844	SW03902	SW03960	SW04018	SW04076	SW04134
Control Signal	SW03729	SW03787	SW03845	SW03903	SW03961	SW04019	SW04077	SW04135
Parallel 0	Program Number	SW03730	SW03788	SW03846	SW03904	SW03962	SW04020	SW04078
	Block Number	SW03731	SW03789	SW03847	SW03905	SW03963	SW04021	SW04079
	Alarm Code	SW03732	SW03790	SW03848	SW03906	SW03964	SW04022	SW04080
Parallel 1	Program Number	SW03733	SW03791	SW03849	SW03907	SW03965	SW04023	SW04081
	Block Number	SW03734	SW03792	SW03850	SW03908	SW03966	SW04024	SW04082
	Alarm Code	SW03735	SW03793	SW03851	SW03909	SW03967	SW04025	SW04083
Parallel 2	Program Number	SW03736	SW03794	SW03852	SW03910	SW03968	SW04026	SW04084
	Block Number	SW03737	SW03795	SW03853	SW03911	SW03969	SW04027	SW04085
	Alarm Code	SW03738	SW03796	SW03854	SW03912	SW03970	SW04028	SW04086
Parallel 3	Program Number	SW03739	SW03797	SW03855	SW03913	SW03971	SW04029	SW04087
	Block Number	SW03740	SW03798	SW03856	SW03914	SW03972	SW04030	SW04088
	Alarm Code	SW03741	SW03799	SW03857	SW03915	SW03973	SW04031	SW04089
Parallel 4	Program Number	SW03742	SW03800	SW03858	SW03916	SW03974	SW04032	SW04090
	Block Number	SW03743	SW03801	SW03859	SW03917	SW03975	SW04033	SW04091
	Alarm Code	SW03744	SW03802	SW03860	SW03918	SW03976	SW04034	SW04092
Parallel 5	Program Number	SW03745	SW03803	SW03861	SW03919	SW03977	SW04035	SW04093
	Block Number	SW03746	SW03804	SW03862	SW03920	SW03978	SW04036	SW04094
	Alarm Code	SW03747	SW03805	SW03863	SW03921	SW03979	SW04037	SW04095
Parallel 6	Program Number	SW03748	SW03806	SW03864	SW03922	SW03980	SW04038	SW04096
	Block Number	SW03749	SW03807	SW03865	SW03923	SW03981	SW04039	SW04097
	Alarm Code	SW03750	SW03808	SW03866	SW03924	SW03982	SW04040	SW04098
Parallel 7	Program Number	SW03751	SW03809	SW03867	SW03925	SW03983	SW04041	SW04099
	Block Number	SW03752	SW03810	SW03868	SW03926	SW03984	SW04042	SW04100
	Alarm Code	SW03753	SW03811	SW03869	SW03927	SW03985	SW04043	SW04101
Logical axis #1 Program Current Position	SL03754	SL03812	SL03870	SL03928	SL03986	SL04044	SL04102	SL04160
Logical axis #2 Program Current Position	SL03756	SL03814	SL03872	SL03930	SL03988	SL04046	SL04104	SL04162
Logical axis #3 Program Current Position	SL03758	SL03816	SL03874	SL03932	SL03990	SL04048	SL04106	SL04164
Logical axis #4 Program Current Position	SL03760	SL03818	SL03876	SL03934	SL03992	SL04050	SL04108	SL04166
Logical axis #5 Program Current Position	SL03762	SL03820	SL03878	SL03936	SL03994	SL04052	SL04110	SL04168
Logical axis #6 Program Current Position	SL03764	SL03822	SL03880	SL03938	SL03996	SL04054	SL04112	SL04170

(cont'd)

System Work Number	System Work 9	System Work 10	System Work 11	System Work 12	System Work 13	System Work 14	System Work 15	System Work 16
Logical axis #7 Program Current Position	SL03766	SL03824	SL03882	SL03940	SL03998	SL04056	SL04114	SL04172
Logical axis #8 Program Current Position	SL03768	SL03826	SL03884	SL03942	SL04000	SL04058	SL04116	SL04174
Logical axis #9 Program Current Position	SL03770	SL03828	SL03886	SL03944	SL04002	SL04060	SL04118	SL04176
Logical axis #10 Program Current Position	SL03772	SL03830	SL03888	SL03946	SL04004	SL04062	SL04120	SL04178
Logical axis #11 Program Current Position	SL03774	SL03832	SL03890	SL03948	SL04006	SL04064	SL04122	SL04180
Logical axis #12 Program Current Position	SL03776	SL03834	SL03892	SL03950	SL04008	SL04066	SL04124	SL04182
Logical axis #13 Program Current Position	SL03778	SL03836	SL03894	SL03952	SL04010	SL04068	SL04126	SL04184
Logical axis #14 Program Current Position	SL03780	SL03838	SL03896	SL03954	SL04012	SL04070	SL04128	SL04186
Logical axis #15 Program Current Position	SL03782	SL03840	SL03898	SL03956	SL04014	SL04072	SL04130	SL04188
Logical axis #16 Program Current Position	SL03784	SL03842	SL03900	SL03958	SL04016	SL04074	SL04132	SL04190

Appendix B Motion Parameter Details

The motion parameters (fixed parameters, setting parameters, and monitoring parameters) for SVB and SVR Modules are listed below.

For information on how to use each motion parameter, refer to *Machine Controller MP2000 Series Built-in SVB/SVB-01 Motion Modules User's Manual* (manual number: SIEP C880700 33).

- The Yes in the SVB or SVR column indicates that the motion parameter is supported by the corresponding module.
- The parameters whose register numbers are marked with an asterisk (*) are valid only when using an MP2400 Ver 2.61 or later and Σ -V series servo drive.

B.1 Fixed Parameter List

Slot Number	Name	Contents	SVB	SVR
0	Selection of Operation Modes	0: Normal Operation Mode	Yes	Yes
		1: Axis Unused	Yes	Yes
		2: Simulation Mode	Yes	
		3: Servo Driver Transmission Reference Mode	Yes	
		4 and 5: Reserved	—	—
1	Function Selection Flag 1	Bit 0: Axis Selection (0: Finite length axis/1: Infinite length axis) • Set to 0 for linear type.	Yes	Yes
		Bit 1: Soft Limit (Positive Direction) Enable/Disable	Yes	
		Bit 2: Soft Limit (Negative Direction) Enable/Disable	Yes	
		Bit 3: Overtravel Positive Direction Enable/Disable	Yes	
		Bit 4: Overtravel Negative Direction Enable/Disable	Yes	
		Bits 5 to 7: Reserved	—	—
		Bit 8: Interpolation Segment Distribution Processing	Yes	
		Bit 9: Simple ABS Rotary Pos. Mode (Simple Absolute Infinite Axis Position Control) (0: Disabled/1: Enabled) • Set to 0 for linear type.	Yes	
		Bit A: User Constants Self-writing Function	Yes	
		Bits B to F: Reserved	—	—
2	Function Selection Flag 2	Bit 0: Communication Abnormality Detection Mask	Yes	
		Bit 1: WDT Abnormality Detection Mask	Yes	
		Bits 2 to F: Reserved for system use.	—	—
3	—	Reserved	—	—
4	Reference Unit Selection	0: pulse, 1: mm, 2: deg, 3: inch, 4: μ m • For linear type, only valid for 0: pulse, 1: mm, 4: μ m. When 2: deg, 3: inch is set, converted into 1: mm.	Yes	Yes
5	Number of Digits below Decimal Places	1 = 1 digit	Yes	Yes
6	Travel Distance per Machine Rotation (Rotary Motor)	1 = 1 reference unit	Yes	Yes
	Linear Scale Pitch (Linear Type)	1 = 1 reference unit	Yes	Yes
8	Servo Motor Gear Ratio	1 = 1 rotation (This setting is ignored if a linear motor is selected.)	Yes	Yes
9	Machine Gear Ratio	1 = 1 rotation (This setting is ignored if a linear motor is selected.)	Yes	Yes
10	Infinite Length Axis Reset Position (POSMAX)	1 = 1 reference units (This setting is ignored if a linear motor is selected.)	Yes	Yes
12	Positive Software Limit Value	1 = 1 reference unit	Yes	
14	Negative Software Limit Value	1 = 1 reference unit	Yes	
16	Backlash Compensation Amount	1 = 1 reference unit	Yes	
18 to 29	—	Reserved	—	—

(cont'd)

Slot Number	Name	Contents	SVB	SVR
30	Encoder Selection	0: Incremental Encoder 1: Absolute Encoder 2: Absolute Encoder (Incremental encoder is used.) 3: Reserved	Yes	
31 to 33	–	Reserved	–	–
34	Rated Motor Speed (Rotary Motor)	1 = 1 rpm	Yes	Yes
	Rated Speed (Linear Type)	1 = 0.1 m/s, 0.1 mm/s	Yes	Yes
36	Number of Pulses per Motor Rotation (Rotary Motor)	1 = 1 pulse/rev Set the value after multiplication.	Yes	Yes
	Number of Pulses per Linear Scale Pitch (Linear Type)	1 = 1 pulse/scale pitch	Yes	Yes
38	Maximum Number of Absolute Encoder Turns Rotation	1 = 1 rotation • Set to 0 when a direct drive motor is being used. • Invalid for linear type.	Yes	
40 to 41	–	Reserved	–	–
42	Feedback Speed Movement Averaging Time Constant	1 = 1 ms	Yes	Yes

B.2 Setting Parameter List

Register No.	Name	Contents	SVB	SVR
OW□□00	RUN Command Setting	Bit 0: Servo ON (0: OFF/1: ON)	Yes	Yes
		Bit 1: Machine Lock (0: Normal operation/1: Machine locked)	Yes	
		Bits 2 to 3: Reserved	—	—
		Bit 4: Latch Detection Demand (0: OFF/1: ON)	Yes	
		Bit 5: Reserved for system use.	—	—
		Bit 6: POSMAX Turn Number Presetting Demand (0: OFF/1: ON) • Set to 0 for linear type.	Yes	Yes
		Bit 7: Request ABS Rotary Pos. Load (Absolute System Infinite Length Position Information LOAD) (0: OFF/1: ON) • Set to 0 for linear type.	Yes	
		Bit 8: Forward Outside Limiting Torque/Thrust Input (Forward External Limiting Torque/Thrust Input) (0: OFF/1: ON)	Yes	
		Bit 9: Reverse Outside Limiting Torque/Thrust Input (Reverse External Limiting Torque/Thrust Input) (0: OFF/1: ON)	Yes	
		Bit A: Reserved	—	—
		Bit B: Integration Reset (0: OFF/1: ON)	Yes	
		Bit C: Reserved	—	—
		Bit D*: Latch Completion Status Clear Request (0: OFF/1: ON)	Yes	
		Bit E: Communication Reset (0: OFF/1: ON)	Yes	
		Bit F: Alarm Clear (0: OFF/1: ON)	Yes	Yes
OW□□01	Mode Setting 1	Bit 0: Excessive Deviation Error Level Setting (0: Alarm/1: Warning)	Yes	
		Bits 1 and 2: Reserved	—	—
		Bit 3: Speed Loop P/PI Switch	Yes	
		Bit 4: Gain Switch	Yes	
		Bit 5: Gain Switch 2	Yes	
		Bit 6*: Latch Mode Selection (0: Usual latch/1: Continuous latch)	Yes	
		Bits 7 to F: Reserved	—	—
OW□□02	Mode Setting 2	Bit 0: Monitor 2 Enabled	Yes	
		Bits 1 to 7: Reserved	—	—
		Bits 8 to F: Stop Mode Selection	Yes	
OW□□03	Function Setting 1	Bits 0 to 3: Speed Unit Selection 0: Reference unit/s 1: 10 ⁿ reference unit/min 2: Percentage of rated speed (1 = 0.01%) 3: Percentage of rated speed (1 = 0.0001%)	Yes	Yes
		Bits 4 to 7: Acceleration/Deceleration Degree Unit Selection 0: Reference units/s ² 1: ms	Yes	Yes
		Bits 8 to B: Filter Type Selection 0: No filter 1: Exponential acceleration/deceleration filter 2: Moving average filter	Yes	Yes
		Bits C to F: Torque Unit Selection 0: Percentage of rated torque (1 = 0.01%) 1: Percentage of rated torque (1 = 0.0001%)	Yes	Yes

(cont'd)

Register No.	Name	Contents	SVB	SVR
OW□□04	Function Setting 2	Bits 0 to 3: Latch Detection Signal Selection 0: – 1: – 2: Phase-C Pulse Input Signal 3: /EXT1 4: /EXT2 5: /EXT3	Yes	
		Bits 4 to 7: External Positioning Signal Setting 0: – 1: – 2: Phase-C Pulse Input Signal 3: /EXT1 4: /EXT2 5: /EXT3	Yes	
		Bits 8 to B: Reserved	–	–
		Bits C to F: Bank Selector	Yes	
OW□□05	Function Setting 3	Bit 1: Phase Reference Creation Calculation Disable (0: Enabled/1: Disabled)	Yes	
		Bits 2 to A: Reserved	–	–
		Bit B: Zero Point Return Input Signal (0: OFF/1: ON)	Yes	
		Bits C to F: Reserved	–	–
OW□□06 to OW□□07	–	Reserved	–	–
OW□□08	Motion Command	0: NOP (No Command) 1: POSING (Position Mode)(Positioning) 2: EX_POSING (Latch Target Positioning)(External Positioning) 3: ZRET (Zero Point Return) 4: INTERPOLATE (Interpolation) 5: END_OF_INTERPOLATE (Last Interpolation Segment) 6: LATCH (Interpolation Mode with Latch Input) 7: FEED (Jog Mode) 8: STEP (Relative Position Mode)(Step Mode) 9: ZSET (Set Zero Point) 10: ACC (Change Acceleration Time) 11: DCC (Change Deceleration Time) 12: SCC (Change Filter Time Constant) 13: CHG_FILTER (Change Filter Type) 14: KVS (Change Speed Loop Gain) 15: KPS (Change Position Loop Gain) 16: KFS (Change Feed-Forward) 17: PRM_RD (Read User Constant)(Read SERVOPACK Parameter) 18: PRM_WR (Write User Constant)(Write SERVOPACK Parameter) 19: ALM_MON (Alarm Monitor) 20: ALM_HIST (Alarm History Monitor) 21: ALMHIST_CLR (Clear Alarm History) 22: ABS_RST (Absolute Encoder Reset) 23: VELO (Speed Reference) 24: TRQ (Torque/Thrust Reference) 25: PHASE (Phase Reference) 26: KIS (Change Position Loop Integral Time Constant) 27: PPRM_WR (Stored Parameter Write)	Yes	Yes

(cont'd)

Register No.	Name	Contents	SVB	SVR
OW□□09	Motion Command Control Flag	Bit 0: Holds a Command. (0: OFF/1: ON)	Yes	Yes
		Bit 1: Interrupt a Command. (0: OFF/1: ON)	Yes	Yes
		Bit 2: Moving Direction (JOG/ STEP) (0: Forward rotation/1: Reverse rotation)	Yes	Yes
		Bit 3: Zero Point Return Direction Selection (0: Reverse rotation/1: Forward rotation)	Yes	
		Bit 4: Latch Zone Effective Selection (0: Disabled/1: Enabled)	Yes	
		Bit 5: Position Reference Type (0: Incremental Addition Mode/1: Absolute Mode)	Yes	Yes
		Bit 6: Phase Compensation Type (0: Incremental Addition Mode/1: Absolute Mode)	Yes	
		Bits 7 to F: Reserved	—	—
OW□□0A	Motion Subcommand	0: NOP (No Command)	Yes	Yes
		1: PRM_RD (Read User Constant)(Read SERVOPACK Parameter) 2: PRM_WR (Write User Constant)(Write SERVOPACK Parameter) 3: Reserved 4: SMON (Status Monitor)	Yes	
		5: FIXPRM_RD (Read Fixed Parameters)	Yes	Yes
OW□□0B	—	Reserved	—	—
OL□□0C	Torque/Thrust Reference Setting	Unit is according to OW□□03, bits 12 to 15 (Torque Unit).	Yes	Yes
OW□□0E	Speed Limit Setting at the Torque/Thrust Reference	1 = 0.01% (percentage of rated speed)	Yes	
OW□□0F	—	Reserved	—	—
OL□□10	Speed Reference Setting	Unit is according to OW□□03, bits 0 to 3 (Speed Unit).	Yes	Yes
OW□□12 to OW□□13	—	Reserved	—	—
OL□□14	Positive Side Limiting Torque/Thrust Setting at the Speed Reference	Unit is according to OW□□03, bits C to F (Torque Unit).	Yes	
OL□□16	Secondly Speed Compensation	Unit is according to OW□□03, bits 0 to 3 (Speed Unit).	Yes	Yes
OW□□18	Override	1 = 0.01%	Yes	
OW□□19 to OW□□1B	—	Reserved	—	—
OL□□1C	Position Reference Setting	1 = 1 reference unit	Yes	Yes
OL□□1E	Width of Positioning Completion	1 = 1 reference unit	Yes	
OL□□20	NEAR Signal Output Width	1 = 1 reference unit	Yes	
OL□□22	Error Count Alarm Detection	1 = 1 reference unit	Yes	
OL□□24	—	Reserved for system use.	—	—
OW□26	Position Complete Cheek Time	1 = 1 ms	Yes	
OW□□27	—	Reserved for system use.	—	—
OL□□28	Phase Correction Setting	1 = 1 reference unit	Yes	
OL□□2A	Latch Zone Lower Limit Setting	1 = 1 reference unit	Yes	

(cont'd)

Register No.	Name	Contents	SVB	SVR
OL□□2C	Latch Zone Upper Limit Setting	1 = 1 reference unit	Yes	
OW□□2E	Position Loop Gain	1 = 0.1/s	Yes	
OW□□2F	Speed Loop Gain	1 = 1 Hz	Yes	
OW□□30	Speed Feedforward Amends	1 = 0.01% (percentage of distribution segment)	Yes	
OW□□31	Speed Compensation	1 = 0.01% (percentage of rated speed)	Yes	Yes
OW□□32	Position Integration Time Constant	1 = 1 ms	Yes	
OW□□33	–	Reserved	–	–
OW□□34	Speed Integration Time Constant	1 = 0.01 ms	Yes	
OW□□35	–	Reserved	–	–
OL□□36	Straight Line Acceleration/ Acceleration Time Constant	Unit is according to OW□□03, bits 4 to 7 (Speed Unit).	Yes	Yes
OL□□38	Straight Line Deceleration/ Deceleration Time Constant	Unit is according to OW□□03, bits 4 to 7 (Speed Unit).	Yes	Yes
OW□□3A	Filter Time Constant	1 = 0.1 ms	Yes	Yes
OW□□3B	Bias Speed for Index Deceleration/Acceleration Filter	Unit is according to OW□□03, bits 0 to 3 (Speed Unit).		Yes
OW□□3C	Zero Point Return Method	0: DEC1 + C (DEC 1 and C-Phase) 1: ZERO (Zero signal) 2: DEC1 + ZERO (DEC 1 and zero signal) 3: C (C-pulse)	Yes	
		4 to 10: Reserved	–	–
		11: C Pulse 12: POT & C Pulse 13: POT Only 14: HOME LS & C Pulse 15: HOME Only	Yes	
		16: NOT & C Pulse 17: NOT Only 18: INPUT & C Pulse 19: INPUT Only	Yes	
OW□□3D	Width of Starting Point Position Output	1 = 1 reference unit	Yes	Yes
OL□□3E	Approach Speed	Unit is according to OW□□03, bits 0 to 3 (Speed Unit).	Yes	
OL□□40	Creep Rate	Unit is according to OW□□03, bits 0 to 3 (Speed Unit).	Yes	
OL□□42	Zero Point Return Travel Distance	1 = 1 reference unit	Yes	
OL□□44	STEP Travel Distance	1 = 1 reference unit	Yes	Yes
OL□□46	External Positioning Final Travel Distance	1 = 1 reference unit	Yes	
OL□□48	Zero Point Position in Machine Coordinate System Offset	1 = 1 reference unit	Yes	Yes
OL□□4A	Work Coordinate System Offset	1 = 1 reference unit	Yes	Yes
OL□□4C	Number of POSMAX Turns Presetting Data	1 = 1 reference unit • Invalid for linear type.	Yes	Yes

(cont'd)

Register No.	Name	Contents	SVB	SVR
OW□□4E	Servo User Monitor Setting	Bits 0 to 3: Monitor 1 (Setting impossible) Bits 4 to 7: Monitor 2 Bits 8 to B: Monitor 3 (Setting impossible) Bits C to F: Monitor 4	Yes	
OW□□4F	Servo Driver Alarm Monitor No.	Set the number of the alarm to monitor.	Yes	
OW□□50	Servo Driver User Constant No.	Set the number of the SERVOPACK parameter.	Yes	
OW□□51	Servo Driver User Constant Number Size	Set the number of words in the SERVOPACK parameter.	Yes	
OL□□52	Servo Driver User Constant Set Point	Set the setting for the SERVOPACK parameter.	Yes	
OW□□54	Servo Driver for Assistance User Constant No.	Set the number of the SERVOPACK parameter number.	Yes	
OW□□55	Servo Driver for Assistance User Constant Size	Set the number of words in the SERVOPACK parameter.	Yes	
OL□□56	Servo Driver for Assistance User Constant Set Point	Set the setting for the SERVOPACK parameter.	Yes	
OW□□58 to OW□□5B	–	Reserved	–	–
OW□□5C	Fixed Parameter Number	Set the number of the fixed parameter to read with the FIXPRM_RD motion subcommand.	Yes	Yes
OW□□5D	–	Reserved	–	–
OL□□5E	Encoder Position When Power is OFF (Lower 2 Words)	1 = 1 pulse • Do not set in the linear type.	Yes	
OL□□60	Encoder Position When Power is OFF (Upper 2 Words)	1 = 1 pulse • Do not set in the linear type.	Yes	
OL□□62	Pulse Position When Power is OFF (Lower 2 Words)	1 = 1 pulse • Do not set in the linear type.	Yes	
OL□□64	Pulse Position When Power is OFF (Upper 2 Words)	1 = 1 pulse • Do not set in the linear type.	Yes	
OL□□66 to OL□□6E	–	Reserved	–	–
OW□□70 to OW□□7F	Command Buffer for Transparent Command Mode	This area is used for command data when MECHATROLINK servo commands are specified directly.	Yes	

B.3 Monitoring Parameter List

Register No.	Name	Contents	SVB	SVR
IW□□00	RUN Status	Bit 0 Motion Controller Operation Ready	Yes	Yes
		Bit 1: Running (At Servo ON)	Yes	Yes
		Bit 2: System Busy	Yes	
		Bit 3: Servo Ready	Yes	
		Bit 4: Latch Mode	Yes	
		Bits 5 to F: Reserved	—	—
IW□□01	Parameter Number When Range Over is Generated	Setting parameters: 0 or higher Fixed Parameters: 1000 or higher	Yes	Yes
IL□□02	Warning	Bit 0: Excessive Deviation	Yes	
		Bit 1: Set Parameter Error (Setting Parameter Error)	Yes	Yes
		Bit 2: Fixed Parameter Error	Yes	Yes
		Bit 3: Servo Driver Error	Yes	
		Bit 4: Motion Command Set Error	Yes	Yes
		Bit 5: Reserved (AD Conversion Error)	—	—
		Bit 6: Positive Direction Overtravel	Yes	
		Bit 7: Negative Direction Overtravel	Yes	
		Bit 8: Servo ON Incomplete	Yes	
		Bit 9: Servo Driver Communication Warning	Yes	
		Bit A*: Servo Driver Stop Signal Input	Yes	
		Bits B to 1F: Reserved	—	—
IL□□04	Alarm	Bit 0: Servo Driver Error	Yes	
		Bit 1: Positive Direction Overtravel	Yes	
		Bit 2: Negative Direction Overtravel	Yes	
		Bit 3: Positive Direction Software Limit	Yes	
		Bit 4: Negative Direction Software Limit	Yes	
		Bit 5: Servo OFF	Yes	Yes
		Bit 6: Positioning Time Over	Yes	
		Bit 7: Excessive Positioning Moving Amount	Yes	
		Bit 8: Excessive Speed	Yes	
		Bit 9: Excessive Deviation	Yes	
		Bit A: Filter Type Change Error	Yes	
		Bit B: Filter Time Constant Change Error	Yes	
		Bit C: Reserved	—	—
		Bit D: Zero Point Unsetting • Invalid for linear type.	Yes	
		Bit E and F: Reserved	—	—
		Bit 10: Servo Driver Synchronization Communications Error	Yes	
		Bit 11: Servo Driver Communication Error	Yes	
		Bit 12: Servo Driver Command Time-out Error	Yes	
		Bit 13: Excessive ABS Encoder Rotations • Invalid for linear type.	Yes	
		Bits 14 to 1D: Reserved	—	—
		Bit1E: Motor Type Set Error	Yes	—
		Bit1F: Connected Encoder Type Error	Yes	—
IL□□06	—	Reserved	—	—
IW□□08	Motion Command Response Code	Same as OW□□08 (Motion Command).	Yes	Yes

(cont'd)

Register No.	Name	Contents	SVB	SVR
IW□□09	Motion Command Status	Bit 0: Command Execution Flag	Yes	Yes
		Bit 1: Command Hold Completed	Yes	Yes
		Bit 2: Reserved	—	—
		Bit 3: Command Error Completed Status (Command Error Occurrence)	Yes	Yes
		Bits 4 to 6: Reserved	—	—
		Bit 7: Reset Absolute Encoder Completed	Yes	
		Bit 8: Command Execution Completed	Yes	Yes
		Bits 9 to F: Reserved	—	—
IW□□0A	Subcommand Response Code	Same as OW□□0A (Motion Subcommand).	Yes	Yes
IW□□0B	Subcommand Status	Bit 0: Command Execution Flag	Yes	Yes
		Bits 1 and 2: Reserved	—	—
		Bit 3: Command Error Completed Status (Command Error Occurrence)	Yes	Yes
		Bits 4 to 7: Reserved	—	—
		Bit 8: Command Execution Completed	Yes	Yes
		Bits 9 to F: Reserved	—	—
IW□□0C	Position Management Status	Bit 0: Distribution Completed	Yes	Yes
		Bit 1: Positioning Completed	Yes	Yes
		Bit 2: Latch Completed	Yes	
		Bit 3: NEAR Position	Yes	Yes
		Bit 4: Zero Point Position	Yes	Yes
		Bit 5: Zero Point Return (Setting) Completed	Yes	Yes
		Bit 6: During Machine Lock	Yes	
		Bit 7: Reserved	—	—
		Bit 8: ABS Rotary Pos. Load Complete (ABS System Infinite Length Position Control Information Load Completed) Invalid for linear type.	Yes	
		Bit 9: POSMAX Turn Preset Complete (TPRSE) • Invalid for linear type.	Yes	Yes
		Bits A to F: Reserved	—	—
IW□□0D	—	Reserved	—	—
IL□□0E	Target Position in Machine Coordinate System (TPOS)	1 = 1 reference unit	Yes	Yes
IL□□10	Calculated Position in Machine Coordinate system (CPOS)	1 = 1 reference unit	Yes	Yes
IL□□12	Machine Coordinate System Reference Position (MPOS)	1 = 1 reference unit	Yes	Yes
IL□□14	CPOS for 32 bit	1 = 1 reference unit	Yes	Yes
IL□□16	Machine Coordinate System Feedback Position (APOS)	1 = 1 reference unit	Yes	Yes
IL□□18	Machine Coordinate System Latch Position (LPOS)	1 = 1 reference unit	Yes	
IL□□1A	Position Error (PERR)	1 = 1 reference unit	Yes	
IL□□1C	Target Position Difference Monitor	1 = 1 reference unit		Yes
IL□□1E	Number of POSMAX Turns	1 = 1 turn • Invalid for linear type.	Yes	Yes

(cont'd)

Register No.	Name	Contents	SVB	SVR
IL□□20	Speed Reference Output Monitor	pulse/s	Yes	
IL□□22 to IL□□2A	–	Reserved	–	–
IW□□2C	Servo Driver Status	Bit 0: Alarm (ALM) Bit 1: Warning (WARNG) Bit 2: Command Ready (CMDRDY) Bit 3: Servo ON (SVON) Bit 4: Main Power Supply ON (PON) Bit 5: Machine Lock (MLOCK) Bit 6: Zero Position (ZPOINT) Bit 7: Locating Completed (Positioning Completed)(PSET) Bit 8: Command Profile Complete (Distribution Completed) (DEN) Bit 9: Torque Restriction (T_LIM) Bit A: Latch Complete (L_CMP) Bit B: Locating Neighborhood (NEAR Position) (NEAR) Bit C: Positive Software Limit (P_SOT) Bit D: Negative Software Limit (N_SOT) Bits E to F: Reserved	Yes	
IW□□2D	Servo Driver Alarm Code	Stores the alarm code from the SERVOPACK.	Yes	
IW□□2E	Servo Driver I/O Monitor	Bit 0: Forward Side Limit Switch Input Bit 1: Reverse Side Limit Switch Input Bit 2: Deceleration Dog Switch Input Bit 3: Encoder Phase-A Signal Input Bit 4: Encoder Phase-B Signal Input Bit 5: Encoder Phase-C Signal Input Bit 6: EXT1 Signal Input Bit 7: EXT2 Signal Input Bit 8: EXT3 Signal Input Bit 9: Brake State Output Bit A*: Stop Signal (HWBB) Bit B: Reserved Bit C: CN1 Input Signal (IO12) Bit D: CN1 Input Signal (IO13) Bit E: CN1 Input Signal (IO14) Bit F: CN1 Input Signal (IO15)	Yes	
IW□□2F	Servo Driver User Monitor Information	Bits 0 to 3: Monitor 1 Bits 4 to 7: Monitor 2 Bits 8 to B: Monitor 3 Bits C to F: Monitor 4	Yes	
IL□□30	Servo Driver User Monitor 2	Stores the result of the selected monitor.	Yes	
IL□□32	Servo Driver User Monitor 3	Reserved	–	–
IL□□34	Servo Driver User Monitor 4	Stores the result of the selected monitor.	Yes	
IW□□36	Servo Driver User Constant No. (SERVOPACK Parameter No. for MECHATROLINK Command Area)	Stores the number of the parameter being processed.	Yes	
IW□□37	Supplementary Servo Driver User Constant No. (SERVOPACK Parameter No. for MECHATROLINK Subcommand Area)	Stores the number of the parameter being processed.	Yes	

(cont'd)

Register No.	Name	Contents	SVB	SVR
IL□□38	Servo Driver User Constant Reading Data (SERVOPACK Parameter Reading Data for MECHATROLINK Command Area)	Stores the data of the parameter being read.	Yes	
IL□□3A	Supplementary Servo Driver User Constant Reading Data (SERVOPACK Parameter Reading Data for MECHATROLINK Subcommand Area)	Stores the data of the parameter being read.	Yes	
IW□□3F	Motor Type	Stores the type of motor actually connected. 0: Rotation type motor 1: Linear motor	Yes	
IL□□40	Feedback Speed	Unit is according to OW□□03, bits 0 to 3 (Speed Unit).	Yes	Yes
IL□□42	Feedback torque/thrust	Unit is according to OW□□03, bits 12 to 15 (Torque Unit).	Yes	Yes
IW□□44 to IW□□55	—	Reserved	—	—
IL□□56	Fixed Parameter Monitor	Stores the data of the fixed parameter when FIXPRM-RD has been specified in the Motion Subcommand.	Yes	Yes
IW□□58 to IW□□5C	—	Reserved	—	—
IL□□5E	Encoder Position When the Power is OFF (Lower 2 Words)	1 = 1 pulse	Yes	
IL□□60	Encoder Position When the Power is OFF (Upper 2 Words)	1 = 1 pulse	Yes	
IL□□62	Pulse Position When the Power is OFF (Lower 2 Words)	1 = 1 pulse	Yes	
IL□□64	Pulse Position when the Power is OFF (Upper 2 Words)	1 = 1 pulse	Yes	
IW□□66 to IW□□6F	—	Reserved	—	—
IW□□70 to IW□□7F	Response Buffer for Transparent Command Mode	Stores the response data when MECHATROLINK Servo commands are specified directly.	Yes	

Appendix C Simple Connection Function of the Engineering Tool

This section explains how to set up a communication process connecting the MPE720 and MP2400.
In MPE720 Ver.7, set the communication process on the MPE720 screen.
Prepare the following equipment to carry out this procedure:

C.1 Preparation

(1) Controller

Product Name	Model	Q'ty
MP2400	JEPMC-MP2400-E	1

(2) Personal Computer


Product Name	Model	Q'ty
MPE720 Ver.7	CPMC-MPE780D (All versions)	1
Ethernet Communication Cable	Any Commercial product Ethernet cross cable (category 5 or more)	1
Personal Computer Main Unit	Any Commercial product	1

(3) Necessary Others


Name	Specification	Q'ty
24-VDC Power Supply	Current capacity 2A or more	1

C.2 Procedure

1. Turn OFF the MP2400 24-VDC power supply.
2. Wire MPE720 and MP2400.




3. Turn ON E-INIT of DIP switch (SW2) in the MP2400 main unit.



4. Turn ON the 24-VDC power supply of the MP2400, and confirm that the RDY, RUN, and IP LEDs are lit on the MP2400 main unit.


When the IP LED is lit, you can confirm that the MP2400 side has successfully retrieved an IP address.



5. Double-click the icon on the personal computer desktop to start up MPE720 Ver.7.



6. Create a new project in the desired location.




7. Click **Communications Setting**.



8. Select **ETHERNET[1] (IP: 192.168.1.100)** as the communication port.

Personal computer IP address

Note: You can check the personal computer IP address in the control panel.




- When there are multiple LAN ports on the personal computer

If there are multiple LAN ports on the personal computer, multiple IP addresses will be shown in the communication port. Select the IP address of the LAN port to which the cable is connected.

- Controller search function


When Ethernet is selected in the communication port, the controller search function will be unavailable.

9. Click the **Search** Button.




A controller search list will appear.

10. A controller search list will appear. Select the found controller and click the **Connection** Button.



Controller IP address

MPE720 will be connected to the controller.



INDEX

Symbols

*****I/O ----- 2-40

Numerics

100Base-TX ----- 3-14
 10Base-T ----- 3-14
 17-byte mode ----- 2-38
 218IFA module ----- 2-12
 configuration definition ----- 2-14
 detailed screen ----- 2-15
 functions ----- 2-12
 Specification ----- 2-13
 32-byte mode ----- 2-38

A

accessories ----- 1-8
 address ----- 5-27
 alarm code ----- A-17
 alarm reset request ----- 5-14
 allocation contact interlock ----- 5-17
 ARP ----- 2-13
 automatic negotiation ----- 2-13
 automatic receive setting screen ----- 2-21

B

basic flow of troubleshooting ----- 8-2
 basic module ----- 2-7
 appearance ----- 1-3
 connections ----- 3-9
 indicators ----- 2-8
 specifications ----- 2-11
 switch settings ----- 2-9
 battery ----- 1-8
 bit ----- 5-27
 block number ----- A-17
 built-in SVB module ----- 2-29

C

cables ----- 1-8, 3-12
 calling a motion program ----- 5-10
 calling a sequence program ----- 5-23
 communication cycle ----- 2-38
 communication interface ----- 2-13
 communication protocols ----- 2-12
 communication with other MP series ----- 6-3
 communication with PLC manufactured by Mitsubishi Electric Corporation ----- 6-39
 communication with touch panel ----- 6-29
 compact flash card-related system registers (CPU-02 and CPU-03 modules for the MP2200 only) ----- A-13
 Compatible
 Inverters ----- 1-6
 Modules ----- 1-6
 SERVOPACKs ----- 1-6
 connection parameter ----- 2-18, 2-23
 connection procedure ----- 3-11
 constants registers ----- 5-25
 control signal ----- 5-14, A-17

D

D registers ----- 5-25
 daily inspections ----- 7-2
 data registers ----- 5-25
 data types ----- 5-27
 definition information updated with self-configuration ----- 5-33
 details of program information used by work n ----- 5-21
 details on interrupting module ----- A-14
 differences from SVB simulation mode ----- 2-47
 DIN rail mounting ----- 3-2
 DIN rail mounting clips ----- 3-3
 DIN Rail Mounting Parts ----- 1-8
 DIP switch settings ----- 5-2
 direct designation ----- 5-10
 double-length integer ----- 5-27

E

encoder cable ----- 4-4
 Ethernet ----- 2-12
 communication methods ----- 6-2
 Ethernet cable ----- 3-14
 Ethernet connection example ----- 3-15
 Ethernet connector details ----- 3-14
 executing main program No. ----- A-17
 executing motion ----- 4-11

F

fixed parameter list ----- A-20

G

groups ----- 5-6

H

how to operate work register ----- 5-16

I

I/O errors ----- 8-9
 I/O map tab ----- 2-41
 I/O message ----- 2-23, 2-25
 ICMP ----- 2-13
 indirect designation ----- 5-11
 INIT ----- 5-30
 INIT switch and RAM data ----- 5-30
 input registers ----- 5-25
 integer ----- 5-27
 interpolation override ----- 5-15
 interrupt status list ----- A-14
 IP ----- 2-13

J

jog operation ----- 4-8
 JZSP-BA01 ----- 7-4

L

LAN cable ----- 4-4
 LED indicator meanings ----- 8-3
 link assignment tab page ----- 2-40

M

main program ----- 5-6, 5-22
 maximum number of slave stations ----- 2-33
 MECHATROLINK
 cable ----- 3-12
 communication specifications ----- 2-33
 connector ----- 3-11
 MECHATROLINK detail definition ----- 2-36

MECHATROLINK-compatible devices	1-6
MELSEC protocol	6-39
message communication	2-17, 2-18, 2-20
metal fittings	2-60
metal fittings for attachment	1-8
M-EXECUTOR module	2-48
configuration definition	2-50
control register mapping window	2-54
execution scheduling	2-57
function overview	2-48
program definition screen	2-52
program execution registration screen	2-56
specification	2-49
module synchronization errors (ver.2.75 or later)	8-10
monitor the motion program execution information	5-19
monitoring parameter list	A-27
motion control function specifications	2-5
motion control functions	2-31
motion parameter details	A-20
motion program	5-6
motion program executor	2-48
mounting clamp	3-5
mounting to DIN rail	3-3
MP2400	
appearance	2-59
error check flowchart	8-5
features	1-2
general specifications	2-2
method	3-2
modules	1-3
mount direction	3-7
product specifications	2-3
space required for mounting	3-8
MPE720 Ver. 6	1-8
MPE720 Ver. 6 Lite	1-8
MPE720 Ver. 7	1-8
MPE720 Ver. 7 Lite	1-8
multiple group operation	5-6

O

online self-diagnosis	5-4
operation errors	8-6
operation start	5-4
operation stop	5-4
optional SVB	2-29
options	1-8
output registers	5-25
override setting for interpolation	5-14

P

PLC function specifications	2-4
power supply connector	1-8, 3-10
precaution on using MP2400	5-36
precautions when setting or changing the scan time	5-38
precautions when user definition file is configured/changed	5-36
problem classification	8-4
processing time	2-47
program continuous operation start request	5-14
program control method	2-49
program current position	A-17
program number	A-17
program numbers	5-6, 5-22
program operation start request	5-14
program pause request	5-14
program single block mode selection	5-14

program single block start request	5-14
program stop request	5-14
programming	4-9
programming tool	1-8

R

real number	5-27
recommended ferrite core	3-17
registers	5-25
regular inspections	7-3
repeater	2-33
repeater HUB	3-15
replacing the basic module battery	7-4
RLY OUT Connector	1-8
RLY OUT connector	
connection cable	3-18
details	3-18

S

S register	5-19
scan time set value examples	5-39
screwed method	3-5
self configuration of each module	5-32
self-configuration	5-4, 5-28
procedure using MPE720	5-31
procedure using the DIP switch	5-29
self-configuration for all the modules	5-31
self-diagnosis at startup	5-4
sequence program	2-48, 5-22
sequence program alarm	5-24
setting and changing scan time	5-38
setting or changing module configuration definition files	5-37
setting parameter list	A-22
simple connection function of the engineering tool	A-31
simple setting screen	2-20, 2-25
single group operation	5-6
Skip 1 information	5-14
Skip 2 information	5-14
starting motion program from an external signal	4-13
startup sequence	5-2
status	A-17
status flag of a motion program	5-13
status flag of sequence program	5-24
status tab page	2-41
sub program	5-6, 5-22
SVB	
features	2-29
specifications	2-31
SVB definition	2-42
SVB definition window	2-42
SVR	2-45
SVR execution timing	2-47
system	
error status	A-7
register lists	A-2
service registers	A-2
status	A-6
work	A-17
system configuration example	1-4, 2-30
system connection example	3-20
system error	
I/O error status	A-12
if a system error occurs	8-11
module information	A-15
service execution status	A-10

system registers -	5-25
system startup -	4-2
executing motion -	4-11
programming -	4-9
self configuration -	4-5
test run -	4-6
wiring -	4-3
system work number setting -	5-14

T

TCP -	2-13
terminating resistor -	1-8
terminator -	1-8, 3-12
transmission bytes -	2-38
transmission distance -	2-34
transmission parameters tab -	2-37
troubleshooting details -	8-6

U

UDP -	2-13
user operation error codes 1 -	A-9
user operation error codes 2 -	A-10
user operation error status -	A-9
user operation error status details -	A-11
user programs -	5-5

V

virtual motion module	
SVR -	2-45

W

watchdog timer timeout errors -	8-10
when MP2400 acts as master	
(I/O message communication function is used) -	6-16
when the MP24000 acts as slave	
(automatic receive function is used) -	6-3
Wild Card I/O (****I/O) -	2-40
Wild Card Servo -	2-40
without using a ladder program -	2-48
work register -	5-12, 5-24

Revision History

The date of publication, revision number, and web revision number are given at the bottom right of the back cover. Refer to the following example.

MANUAL NO. SIEP C880742 00A <0>-1
 Published in Japan September 2009

WEB revision number
 Revision number
 Date of publication

Date of Publication	Rev. No.	WEB Rev. No.	Section	Revised Contents
August 2022	<4>	0	All chapters	Revision: MPE720 windows changed to Ver.7
			Back cover	Revision: Address
May 2020	<3>	1	1.5, 3.2, 4.2.1 [a], 4.5.2, A.2	Partly revised.
			Back cover	Revision: Address
March 2018		0	2.1.1	Revision: Noise resistance
January 2018	<2>	0	–	Printed version of the manual that is available on the web (web version: SIEP C880742 00B <1>-5)
			1.4 (3)	Revision: Model numbers
			1.5.1	Partly revised
			2.1.1	Revision: Pollution Level, Noise Resistance
			Back cover	Revision: Address

Date of Publication	Rev. No.	WEB Rev. No.	Section	Revised Contents
February 2017	<1>	5	5.3.1 (1)	Revision: Notes for DWG Registers
			Back cover	Revision: Address
July 2016		4	Front cover	Revision: Format
			1.4	Revision: Devices Connectable to MECHATROLINK
			Back cover	Revision: Address and format
February 2015		3	1.5.2	Revision: Description of RLY OUT connector and DIN rail mounting parts
			Back cover	Revision: Address
November 2013		2	2.2.4 (4)	Revision: Description of message communication item of connection parameter setting
			Back cover	Revision: Address
April 2012		1	3.2.3 (1)	Revision: Connector Model
			Back cover	Revision: Address
September 2011		0	–	Based on the Japanese user's manual, SIJP C880742 00D<4>-3, published in April 2011
			Front cover	Revision: Format
			1.5.3	Deletion: CPMC-MPE720
			2.2.7	Revision: Screen shots of status and of control signal details
			4.3.1	Revision: Screen shot of calling the command input assist feature in step 4
			4.4.1	Revision: Screen shots in steps 1 and 2
			4.4.2	Revision: Screen shots in steps 1 and 2
			4.5.3	Revision: Screen shots of creation of sequence program in step1 and of Task Allocation dialog box in step 2
			5.1	Deletion: 5.1.4 LED Indicator Details
			Chapter 7	Revision: Structure Deletion: 7.2 Troubleshooting
			Chapter 8	Addition: New chapter
			Appendix A	All revised.
			Appendices D1, D2, D3 (1), and D3 (2)	Addition: Step 6
			Appendix E	Addition: Descriptions of motion parameter details Addition: Latch completion status clear request (Bit D) of RUN command setting (register no. OW□□00) Addition: Latch mode selection (Bit 6) of Mode setting 1 (register no. OW□□01) Addition: Servo driver stop signal input (Bit A) of Warning (register no. IL□□02) Addition: Stop signal (Bit A) of Servo driver I/O monitor (register no. IW□□2E)
			Appendix F	Revision: Title
			Back cover	Revision: Address, format
September 2010	<0>	5	2.2.2 (3), 5.1.1	Revision: Details of SUP switch
			Back cover	Revision: Address
June 2010		4	2.2.2 (2)	Revision: Description of status of IP
April 2010		3	Preface	Addition: Terms Used to Describe “Torque” Addition: PL on fumigation and halogen gases
			1.5.1	Revision: Application of MP2400 Basic Module Revision: Model of MP2400 Basic Module JEPMC-W6011-□□ → JEPMC-W6010-□□ Addition: Model of terminator
			2.2.3	Addition: Allowable Power Loss Time
			2.2.7 (1)	Deletion: Description of Note
			4.2.2	Addition: Step 6
			4.4.1	Addition: Description of Note
			6.3.1 (1)	Revision: The other device to be connected in step 4 ⑥ and ⑦ MP2300 → touch panel
September 2009		2	Preface	Addition: Warranty
		1	5.2.2 (4) (b)	Revision: Table of control signals
			Back cover	Revision: Address
February 2008		0	–	First edition

Machine Controller MP2400

USER'S MANUAL

IRUMA BUSINESS CENTER (SOLUTION CENTER)

480, Kamifujisawa, Iruma, Saitama, 358-8555, Japan
Phone: +81-4-2962-5151 Fax: +81-4-2962-6138
www.yaskawa.co.jp

YASKAWA AMERICA, INC.

2121, Norman Drive South, Waukegan, IL 60085, U.S.A.
Phone: +1-800-YASKAWA (927-5292) or +1-847-887-7000 Fax: +1-847-887-7310
www.yaskawa.com

YASKAWA ELÉTRICO DO BRASIL LTDA.

777, Avenida Piraporinha, Diadema, São Paulo, 09950-000, Brasil
Phone: +55-11-3585-1100 Fax: +55-11-3585-1187
www.yaskawa.com.br

YASKAWA EUROPE GmbH

Hauptstraße 185, 65760 Eschborn, Germany
Phone: +49-6196-569-300 Fax: +49-6196-569-398
www.yaskawa.eu.com E-mail: info@yaskawa.eu.com

YASKAWA ELECTRIC KOREA CORPORATION

18F, Hi Investment & Securities Building, 66 Yeoui-daero, Yeongdeungpo-gu, Seoul, 07325, Korea
Phone: +82-2-784-7844 Fax: +82-2-784-8495
www.yaskawa.co.kr

YASKAWA ASIA PACIFIC PTE. LTD.

30A, Kallang Place, #06-01, 339213, Singapore
Phone: +65-6282-3003 Fax: +65-6289-3003
www.yaskawa.com.sg

YASKAWA ELECTRIC (THAILAND) CO., LTD.

59, 1F-5F, Flourish Building, Soi Ratchadapisek 18, Ratchadapisek Road, Huaykwang, Bangkok, 10310, Thailand
Phone: +66-2-017-0099 Fax: +66-2-017-0799
www.yaskawa.co.th

YASKAWA ELECTRIC (CHINA) CO., LTD.

22F, Link Square 1, No.222, Hubin Road, Shanghai, 200021, China
Phone: +86-21-5385-2200 Fax: +86-21-5385-3299
www.yaskawa.com.cn

YASKAWA ELECTRIC (CHINA) CO., LTD. BEIJING OFFICE

Room 1011, Tower W3 Oriental Plaza, No.1, East Chang An Avenue,
Dong Cheng District, Beijing, 100738, China
Phone: +86-10-8518-4086 Fax: +86-10-8518-4082

YASKAWA ELECTRIC TAIWAN CORPORATION

12F, No. 207, Section 3, Beishin Road, Shindian District, New Taipei City 23143, Taiwan
Phone: +886-2-8913-1333 Fax: +886-2-8913-1513 or +886-2-8913-1519
www.yaskawa.com.tw

YASKAWA

YASKAWA ELECTRIC CORPORATION

In the event that the end user of this product is to be the military and said product is to be employed in any weapons systems or the manufacture thereof, the export will fall under the relevant regulations as stipulated in the Foreign Exchange and Foreign Trade Regulations. Therefore, be sure to follow all procedures and submit all relevant documentation according to any and all rules, regulations and laws that may apply. Specifications are subject to change without notice for ongoing product modifications and improvements.

© 2008 YASKAWA ELECTRIC CORPORATION

MANUAL NO. SIEP C880742 00C <4>-0

Published in Japan August 2022

22-4-18

Original instructions